

DIRECTIONS
for CARE and
CLEANING

Styles 1T and 1U
Sorts Casting
Molds

STYLE 1T MOLD FOR CASTING SORTS,
HIGH AND LOW QUADS AND SPACES OF
ANY WIDTH SET-WAYS UP TO THIRTY-
SIX POINTS INCLUSIVE IN TWELVE-,
FOURTEEN-, AND EIGHTEEN-POINT
SIZES.

STYLE 1U MOLD FOR CASTING SORTS,
HIGH AND LOW QUADS AND SPACES OF
ANY WIDTH SET-WAYS UP TO THIRTY-
SIX POINTS INCLUSIVE IN TWENTY-
FOUR-, THIRTY-, AND THIRTY-SIX-
POINT SIZES.

TRADE MARK

MONOTYPE

Reg. U. S. Pat. Off.

LANSTON MONOTYPE
MACHINE COMPANY
PHILADELPHIA

Directions for Care and Cleaning

STYLES 1T AND 1U

SORTS CASTING MOLDS

1 The Styles 1T and 1U Molds are furnished with three BLADES each for casting, as sorts, type and high and low quads and spaces of any width set-ways up to thirty-six points inclusive and of any point-size as follows:

Style 1T MOLD for twelve-, fourteen-, and eighteen-point bodies.

Style 1U MOLD for twenty-four-, thirty-, and thirty-six-point bodies.

The twelve-point size in the 1T MOLD is used for quads and spaces and for a few very extended twelve-point faces made in SORTS MATRICES. Composition MATRICES cannot be used on these MOLDS. The earlier 1T MOLDS were equipped for casting twenty-point instead of twelve-point.

CAUTIONS

2 **Taking Apart:** As long as the MOLD produces good type let it alone. When necessary to clean the MOLD do so in accordance with the following directions.

3 **Assembling:** Be sure parts are of same point-size. These parts are clearly marked.

4 **Mold Blades** must be inserted or removed by sliding them along the SQUARING PLATE straight to the front or rear. Never lift the rear end of the BLADES when passing them between the TYPE BLOCKS nor try to force them over the NICK PIN. Following this caution prevents injury to the BLADES or to the NICK PIN.

5 **Fitting a Gate Pusher:** Do not attempt to fit a GATE PUSHER. This can be done only in our factory.

6 **Protect the Gate Pusher** by holding it in the CROSS BLOCK with the finger, while putting the CROSS BLOCK in place or taking it out.

7 **Insert the Gate Pusher with beveled end to the rear.**

8 **A new or repaired Mold requires special attention** until the CROSS BLOCK has found its true bearing against the TYPE BLOCKS while running under actual working conditions. After the MOLD has run an hour, test the setting of the CROSS BLOCK. If loose, readjust it. Repeat this test after the MOLD has run half a day and also a full



day. If this is not done, the mold will be damaged, causing the type to be set in the wrong position.

9 **Screws** should be tightened after the mold has been run for a short time.

10 **After** the mold has been run for a short time, these parts should be inspected. This special measuring instrument repairs all defects and produces and a

11 **Water** should be used to cool the mold and water as possible and bleeding as hot as can be

12 **Water** should be used to cool the MOLD and blowing oil to the MOLD is

13 **Oiling** should be done every two or three days except for the by hand.

14 **Temp** should never exceed 100 degrees; the most metal standard Mo

with the P...
not to dama...
do not force...
the MOLD.




FIGURE 1

MOLD assembled ready for use.
Top view from rear left corner.

day. If this test be not made, the MOLD may become leaded, causing wear of the Cross Block and Type Blocks or forcing them out of alignment.

9 Screws holding left Type Block must never be loosened. This Block is adjusted in our factory.

10 Alterations: Never alter any part of the MOLD. These parts are made by experienced workmen trained for this special work and supplied with the finest gages and measuring instruments. When returning a MOLD for repairs always enclose with it samples of the type it produces and a memorandum giving details of the defects.

11 Water regulation: Molds are built to use as little water as possible; use just enough to avoid blistered bodies and bleeding feet. The water from the MOLD should be as hot as can be borne on the hand.

12 Water passages must be kept clean. Whenever the MOLD is taken off the machine, force all water out with the air blast and oil the water passages thoroughly by blowing oil through them.

13 Oiling: Our MOLD OILER, regulated to give a drop every two or three minutes, will give sufficient oiling, except for the Cross-block Coupling which must be oiled by hand.

14 Temperature: The temperature of the metal should never be over 725 degrees nor cooler than 675 degrees; the larger bodies (that is, the ones requiring the most metal) take the lower temperature. This is for standard Monotype metal. For metals other than this,



Bottom view

special care
ture by trial

15 Brid
MOLD on t
with the C
for all Mo
adjustments b
lightly on th

16 Matr
be in posit
quads or sp

17 First
proper bear
everything
not before.

18 Bodie
ways requi
pound Lever
the MOLD B
ways the no

19 Thirt
casting type
a body with
the MOLD B

20 When
it rests flat o
in this posit

with the POINT BLOCK (Z) in place. CAUTION: Be careful not to damage the corners of the MOLD BLADE (H), and do not force the MOLD BLADE over the NECK PIN. TURN

and (S) unt
Cross Block
the left side



FIGURE 3

MOLD BLADES and POINT BLOCK.

MOLD-BLADE SHIELD and MOLD-BLADE TOP GUIDE are put in place.

21 Adjustment of the Front-abutment Shoe should never be broken. If it works loose, adjust it as given in the following directions (¶41).

22 Bodies containing more than 144 square points, require proportionately slower speed than 140 r.p.m.; the PUMP capacity must be increased and the CENTERING PIN must exert an extra pressure on the MATRIX (all of which are provided by the Display-type Attachment).

23 The stroke of the Type Carrier must be increased.

24 The display Type Channel Blocks must be used in place of the standard Type Channels Blocks.

TAKING APART: Re-read Cautions

(See the "direction arrow" on each figure)

25 Prepare a suitable place for taking the MOLD apart. Spread down a clean sheet of paper and as the parts are taken off the MOLD, place them on this paper. Have the hands clean and free from particles of metal.

26 Slide the CROSS BLOCK (A) out of the MOLD to the right being careful not to drop its GATE PUSHER (V). Take out the FRONT-ABUTMENT SHOE (P).

27 Swing the SPRING BOX (M) out to the right so that it is not operative. Remove MOLD-BLADE-LEVER FULCRUM STUD (J); MOLD-BLADE LEVERS (K) and (L); MOLD-BLADE SHIELD (E); MOLD-BLADE STOP (G); MOLD-BLADE TOP GUIDE (C); upper MOLD BLADE (O).

28 Turn the MOLD upside-down and take out one long SCREW (X) and two short SCREWS (Y) which hold the right

this would injure
right TYPE BLOCK
SQUARING PLATE toward

ENT
ION:
KS as
of the
off the

CLEANING

30 Clean carefully all parts of the MOLD which have been removed and also the parts which have been left assembled, being especially careful to remove all particles of metal. Use a clean white cloth for this purpose. Do not use waste, as this will leave lint which is very hard to remove. In case little particles of metal stick to any part of the MOLD so that they cannot be wiped off they must be carefully scraped off with a wooden stick or piece of brass rule.

31 Be sure that all the corners in around the left TYPE BLOCK where the MOLD BLADE works are perfectly clean.

32 Thoroughly clean the GATE PUSHER (V) and its slot between the CROSS-BLOCK GATE BLOCKS (U) and (W).

ASSEMBLING

33 Be sure all parts are clean. (Re-read the preceding directions under the heading "Cleaning".) Be sure the hands are clean and free from particles of metal.

34 Slide the right TYPE BLOCK (N) into position putting a slight pressure on it to remove any dirt from the surfaces of the SQUARING PLATE (F). Remove the TYPE BLOCK (N), wipe it off and replace it, this time keeping it in position. Slide in the lower MOLD BLADE (H) from the rear without the POINT BLOCK (Z) while with the thumb and first two fingers the right TYPE BLOCK (N) is held so that the BLADE (H) can just be pushed through. Have the BLADE (H) flat down on the SQUARING PLATE and push it forward to remove any particles of dirt. Take out BLADE (H) and, while still holding the right TYPE BLOCK (N) in position, insert the two SCREWS (I) at the back, bringing them just up to bearing (be sure the SCREW with the WASHER is nearest the MOLD BLADE). Wipe the lower MOLD BLADE (H) clean and slide it in from the rear

with the
not to d
do not fo
the MOL
and (Y)
Bring the
(H) down
up to bear
of the ri
SCREW (I

35 Pu
to get it
the rear.

BLADE (C
top of the
(O) back
them.

36 Pu
tighten it
making su
bind, loos
them, the

there is c
BLADE an
BLOCK (B

37 Put
BLADES ag
in. Put c
the LEVER
(these LE
Insert and

38 By
BLOCK GA
adjusted,
but witho
GATE BLO

39 Mak
bearings a
in position
from the ri

40 The
(S) should
any way;
adjustment

41 If th
the FRONT-
PUSHER (V
interfere wi
the LOCK M

with the POINT BLOCK (Z) in place. CAUTION: Be careful not to damage the corners of the MOLD BLADE (H), and do not force the MOLD BLADE over the NICK PIN. Turn the MOLD bottom up and insert the three SCREWS (X) and (Y) in the bottom of the right TYPE BLOCK (N). Bring them just up to bearing. See that the MOLD BLADE (H) does not bind. Insert the SCREW (D) and bring it up to bearing. Tighten the five SCREWS (I), (X), and (Y) of the right TYPE BLOCK (N) alternately. Tighten the SCREW (D).

35 Put on the upper MOLD BLADE (O) being careful to get it resting properly on the lower BLADE (H) at the rear. The best way to do this is to slide the upper BLADE (O) in until its rear end drops into the slot in the top of the lower BLADE (H). Work the BLADES (H) and (O) back and forth separately to be sure no dirt is between them.

36 Put on the MOLD-BLADE TOP GUIDE (C) and tighten its SCREWS. Put on the MOLD-BLADE STOP (G), making sure it is on square. Test the BLADES; if they bind, loosen the TOP GUIDE (C). If this does not free them, there is dirt in the MOLD. If it does free them, there is dirt between the BLADES or between the TOP BLADE and GUIDE (C) or between GUIDE (C) and TYPE BLOCK (B) at the left end.

37 Put on the MOLD-BLADE SHIELD (E). Test the BLADES again to see that they are free. Push the BLADES in. Put on the MOLD-BLADE LEVERS (K) and (L), having the LEVER (K), with SPRING BOX (M) attached, on top (these LEVERS will not work if in any other position). Insert and tighten the LEVER FULCRUM STUD (J).

38 By loosening the SCREWS holding the right Cross-BLOCK GATE BLOCK (W), the GATE PUSHER (V) may be adjusted. Adjust so that the PUSHER will move smoothly but without looseness, and so that it will be flush with the GATE BLOCKS on the bottom edge.

39 Make sure the Cross BLOCK (A) (complete) and its bearings are clean. Put the FRONT-ABUTMENT SHOE (P) in position in the MOLD and slide in the Cross BLOCK from the right.

40 The FRONT-ABUTMENT ADJUSTING SCREWS (Q) and (S) should not be loosened or their adjustment changed in any way; if, however, they become loosened so that the adjustment must be made proceed as follows:

41 If the Cross BLOCK does not fit properly readjust the FRONT-ABUTMENT SHOE as follows: Remove the GATE PUSHER (V) so that any tightness in its action will not interfere with the feel of the Cross BLOCK sliding. Loosen the LOCK NUTS (R) and (T) and slack off the SCREWS (Q)

and
CROSS
the M
until
finger
right
the M
After
to set
SCRE
all th
his fi
it has
Lock
and (C
Try t
its ad
(V) a

42.

that
with t
MOLD
(C) be

43.

Apart
TYPE
Instea
only k
(H) w
dirt sh
into pe
time h
the M
POINT
damag
MOLD
and br
(Y) up
the SCR
"Assem
the M
(C), an
for the

and (S) until the Cross Block slides freely. Slide the Cross Block to the left so that its left end comes flush with the left side of the MOLD and set up the left SCREW (Q) until the Cross Block requires some little pressure of the fingers to slide it. Now slide the Cross Block to the right until its right end comes flush with the right side of the MOLD and set up the right SCREW (S) in the same way. After sliding the Cross Block back and forth a few times to settle it to bearing repeat the above adjustment of the SCREWS until the Cross Block fits very tightly, requiring all the pressure the operator can bring to bear upon it with his fingers to slide it; be careful, however, to note that it has an even bearing and does not bind at any point. Lock the SCREWS (S) and (Q) with their LOCK NUTS (T) and (R), holding the SCREWS to keep them from turning. Try the Cross Block again to see that this has not affected its adjustment. Don't forget to replace the GATE PUSHER (V) as described in ¶38.

CHANGING MOLD BLADES

42. To change from one point-size to another requires that the upper and lower MOLD BLADES (O) and (H) with their POINT BLOCK (Z), the MOLD-BLADE STOP (G), MOLD-BLADE SHIELD (E), and MOLD-BLADE TOP GUIDE (C) be changed.

43. To make this change proceed as under "Taking Apart" up to the removal of the SCREWS holding the right TYPE BLOCK to the SQUARING PLATE (¶25, ¶26 and ¶27). Instead of removing these SCREWS, as described in ¶28, only loosen them. Then take out the lower MOLD BLADE (H) with its POINT BLOCK. To remove any particles of dirt slide the lower MOLD BLADE of the point-size desired into position (without the POINT BLOCK) while at the same time holding the TYPE BLOCK (N) up against it. Remove the MOLD BLADE, wipe it clean, and replace it with the POINT BLOCK in position. CAUTION: Be careful not to damage the corners of the MOLD BLADE and never force the MOLD BLADE over the NICK PIN. Insert SCREW (D) and bring it up to bearing, then bring SCREWS (I), (X), and (Y) up to bearing; tighten first the SCREW (D) and then the SCREWS (I), (X), and (Y). Continue with ¶35 under "Assembling," substituting the upper MOLD BLADE (O), the MOLD-BLADE SHIELD (E), MOLD-BLADE TOP GUIDE (C), and MOLD-BLADE STOP (G) of the point-size to be used for those just removed.

ve
h
)
ve
re
of
y.
es
ve
ag
th
at
t.
)
e.
d
x

es
)
)
e

g
at
)
)
8.
ve
of
d
ve
ve
ve
o
ve
)
d
n
er
)
e
d

Names and Symbols of Parts of the Styles 1T and 1U Molds

This list is for all styles 1T and 1U Molds.

The names in the following list are alike for both 1T and 1U Molds but the symbols here given are for the 1T Mold; when ordering a part for the 1U Mold change the letter T to the letter U in the symbol.

All parts which can be furnished for applying to a Mold outside our factory are designated by an asterisk (*) preceding the symbol. (See also special note following Cross-Block Coupling 1MB1T2 and Mold-Blade Stop 7MC1T1.)

For 1U Molds change
letter T to letter U.

BASE PLATE.....	1MA1T1
bushing ($\frac{3}{8}$ " long).....	1MA1T2
" ($\frac{1}{4}$ " long).....	1MA1T3
BASE-PLATE FRONT ABUTMENT.....*	2MA1T1
adjusting screw (left, blunt).....	2157.* 2MA1T2
" " (right, pointed).....	2193.* 2MA1T3
" " lock nut (2).....	386.* 2MA1T4
screw (3).....	321.* 2MA1T5
BASE - PLATE - FRONT - ABUTMENT NUMBER	
PLATE.....	3MA1T1
screw (2).....	251.* 3MA1T2
BASE - PLATE - FRONT - ABUTMENT PACKING	
BLOCK.....	4MA1T1
BASE-PLATE-FRONT-ABUTMENT STOP.....*	5MA1T1
BASE-PLATE-GATE-PUSHER.....*	6MA1T1
screw (3).....	6MA1T2
Cross-Block Coupling.....	1MB1T1
	1MB1T2

(1U2)
broken
sh
a

Cross-Block
coupling
dowel (to
screw (to

Cross-Block
screw (4)

Cross-Block
oil pad (to
screw (4)

Cross-Block

Mold Blade

Mold Blade

Mold-Blade

Mold-Blade
screw (2)

Mold-Blade
screw (2)

† Note:
be broken, the
pieces of the
dition that th

Mold-Blade
size of
screw (2)

Mold-Blade
(upper).
spring)

" bo
"
"

Mold-Blade

Mold-Blade
screw (2)

* Can be
factory.

For 1U Molds change
letter T to letter U.

Cross Block (continued)

coupling screw.....	2165..*	1MB1T3
dowel (to 3MB1T1).....		1MB1T4
screw (to adjust 2MB1T1).....	2167..*	1MB1T5
CROSS-BLOCK GATE BLOCK (right).....		2MB1T1
screw (4).....	236..*	2MB1T2
CROSS-BLOCK GATE BLOCK (left).....		3MB1T1
oil pad (felt).....*		3MB1T2
screw (4).....	236..*	3MB1T3
CROSS-BLOCK GATE PUSHER.....		4MB1T1
MOLD BLADE (bottom) (give point-size) . . .		1MC1T1
MOLD BLADE (top) (give point-size)		2MC1T1
MOLD-BLADE POINT BLOCK (give point-size)		5MC1T1
MOLD-BLADE SHIELD.....		6MC1T1
screw (2).....	2208..*	6MC1T2
MOLD-BLADE STOP.....	‡	7MC1T1
screw (2).....	246..*	7MC1T2
‡ NOTE: If the MOLD-BLADE STOP 7MC1T1 (or 7MC1U1) be broken, this part can be replaced by returning to us the broken pieces of the Stop, provided these broken pieces are in such condition that the required measurements can be obtained from them.		
MOLD-BLADE TOP GUIDE (designate point-size of MOLD BLADE).....		8MC1T1
screw (2).....	2220..*	8MC1T2
MOLD-BLADE LEVER (lower).....*		12MC1T1
(upper).....*		12MC1T2
spring.....	6152..*	12MC1T3
" box.....*		12MC1T4
" " pin.....*		12MC1T5
" " plug.....*		12MC1T6
MOLD-BLADE-LEVER FULCRUM STUD.....*		13MC1T1
MOLD-BLADE-LEVER-SPRING-BOX PLATE.....*		14MC1T1
screw (2).....	247..*	14MC1T2


* Can be applied without returning the Mold to our factory.


TYPE BL
bushin
oil pad
plug s
"
pin (fo
screw
"
"
"
"
TYPE BL
plug s
screw
"
nick p
"
TYPE-BL
nut...
spring
washer
TYPE-BL
TYPE-BL
screw
TYPE-BL
adjust
bushin
"
"
plug s
screw
* Can
factory.

For 1U Molds change
letter T to letter U.

TYPE BLOCK (large).....	a1MD1T1
bushing (2).....	1MD1T16
oil pad.....	* 1MD1T5
plug screw (3).....	2239 * 1MD1T7
" " (5).....	2235 * 1MD1T8
pin (for 3MD1T1).....	* 1MD1T9
screw (from 9MD1T1, short).....	* 1MD1T10
" (from 1MA1T1, short) (2).....	2162 * 1MD1T11
" (from 9MD1T1, long).....	231 * 1MD1T12
" (from 1MA1T1, long).....	231 * 1MD1T13
" washer (5).....	435 * 1MD1T14
TYPE BLOCK (small).....	a2MD1T1
plug screw (3).....	2239 .. 2MD1T6
screw (from 1MA1T1) (3).....	2162 .. 2MD1T7
" (from 9MD1T1, rear).....	231 .. 2MD1T9
nick pin.....	2MD1T18
" " plug.....	2MD1T19
TYPE-BLOCK CLAMP BOLT.....	* 3MD1T1
nut.....	31 * 3MD1T2
spring.....	6155 * 3MD1T3
washer.....	436 * 3MD1T4
TYPE-BLOCK-CLAMP-BOLT SCREW.....	* 4MD1T1
TYPE-BLOCK GATE KNOCK OFF	6MD1T1
screw (2).....	247 .. 6MD1T2
TYPE-BLOCK SQUARING PLATE.....	9MD1T1
adjusting screw (6).....	2159 .. 9MD1T2
bushing (1/2" long).....	9MD1T4
" (3/4" long).....	9MD1T9
" (2).....	9MD1T10
plug screw (3).....	2235 * 9MD1T6
screw (2) (from 1MA1T1).....	2161 .. 9MD1T8

* Can be applied without returning the Mold to our factory.





It
Mou
nor t

If
this
the c
shoul
the d
the J
parts
and v
Mou
detai

Th
whic
serve
Mou
dress
the o

Mold Repairs

It is not possible for operators to repair MOLDS for they have neither the special tools nor the necessary training.

If any defects occur in the type produced by this MOLD, that cannot be corrected by following the directions in this folder, the *complete Mold* should be at once returned to us with samples of the defective type; enclose these in the box with the *Mold and all its parts* (be sure to include all parts for all point-sizes), prepay express charges and write us stating (a) point size and number of MOLD; (b) date of shipment and route; (c) details of trouble.

IMPORTANT

This MOLD is held in its box by two SCREWS which pass through the bottom of the box. Preserve this box and its SCREWS for returning MOLD. In reshipping reverse the lid; our address is printed on the under side. Do not nail the cover—tie it on.

LANSTON MONOTYPE
MACHINE COMPANY

PHILADELPHIA

S
So

STY
HIG
ANY
SIX
FOU

STY
HIG
ANY
SIX
FOU

L
M

7-18-2M

* Can be applied without returning the Mold to our factory.

..... screw (2) * JANCI12 247 * JANCI12