

OIL ENGINES.

UC-NRLF



QB 271 989




A. H. GOLDINGHAM, M. E.

REESE LIBRARY
OF THE
UNIVERSITY OF CALIFORNIA.

Received , 190 .

Accession No. **82934** . *Class No.*



THE
DESIGN AND CONSTRUCTION
OF
OIL ENGINES

WITH FULL DIRECTIONS FOR
ERECTING, TESTING, INSTALLING
RUNNING AND REPAIRING

INCLUDING DESCRIPTIONS OF AMERICAN AND ENGLISH
KEROSENE OIL ENGINES

By A. H. GOLDINGHAM, M.E.

Fully Illustrated



NEW YORK :
SPON & CHAMBERLAIN, 12 CORTLANDT ST.

LONDON :
E. & F. N. SPON, LTD., 125 STRAND
1900

TJ 785
66

Entered According to Act of Congress in the Year 1900, by
ARTHUR HUGH GOLDINGHAM
In the Office of the Librarian of Congress, Washington, D. C.

PREFACE

THIS work has been written with the intention of supplying practical information regarding the kerosene or oil engine, and in response to frequent requests received by the writer to recommend such a book.

Whilst many works have been published on the subject of gas engines, some of which refer to or describe the working of the oil engine, no other book, it is believed, is devoted entirely to the oil engine in detail.

The work, it is hoped, will be found useful to the draughtsman, the engine attendant, as well as to those who own or are about to install Oil Engines.

The classification of vaporizers has been adhered to as made some few years ago, and a representative engine with each type is described.

The matter on design and construction is founded on practical experience, the formulæ, it is believed, being in accordance with the best modern practice.

Chapter III. on Testing is based on the writer's personal experience in the testing-room.

The writer is particularly indebted to Mr. George Richmond for many valuable suggestions, and also for reading the proof-sheets, and he wishes to acknowledge assistance from many firms, amongst which may be mentioned Ingersoll Sargeant Drill Company for Table III., Mr. Frank Richards for Table II., The De La Vergne Company for Table IV., *London Engineer*, Tables V. and VI. Table I. is partly taken from Mr. William Norris's book on the Gas Engine, and Tables VII., VIII., IX., and X., at the end of the book, relating to different oils, are taken (with permission) from Mr. Boverton Redwood's valuable work on Petroleum. And to the *Engineering News* for permission to use Figs. 44*b* and 44*c*. The Crosby Steam Gauge Company have also supplied information relating to the indicator and planimeter.

A. H. GOLDINGHAM.

NEW YORK, November 1, 1900.

CONTENTS.

CHAPTER I.

INTRODUCTORY.

PAGE

Historical—Classification of Oil Engines—Various Vaporizers—Different Igniting and Spraying Devices—The Different Cycles of Valve Movements	1-19
---------------------------------------------------------------------------------------------------------------------------------------------	------

CHAPTER II.

ON DESIGNING OIL ENGINES.

Simplicity in Construction and Arrangement of Parts—Comparison of Oil and Gas Engines—Cylinders, Different Types—Cylinder Clearance—Crank-shaft, Dimensions and Formulæ—Balancing of Crank-shafts Described—Connecting-rods, Strengths, etc.—Piston, Piston-rings—Piston speed—Fly-wheels, Formula for—Air and Exhaust Cams—Cylinder Lubricators—Valves and Valve-boxes—Velocity of Air through Valves—Crank-shaft Bearings—Proportions of Engine Frame—Crank-pin Dimensions—Valve Mechanisms, Gearing and Levers—Governing Devices—Exhaust Bends—Oil-supply Pump—Oil-tank and Filter—Comparison of Horizontal and Vertical Type Engines, with Advantages of Each—Two-cylinder Engines Discussed—Assembling of Oil-engines—Scraping in Bearings—Fitting of Piston and Piston-rings—Fitting Connecting-rod Bearings—Fitting Air and Exhaust Valves—Testing Water-jackets—Fly-wheel Keys—Oil-supply Pipes—Cylinder Made in Two or More Parts, ..	20-58
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------

CHAPTER III.

TESTING ENGINES.

PAGE

Object of Testing—Comparison with Steam-engines— Different Records to be Taken—Diagram for setting Valves—Preparing for Test—Heating of Vaporizer— Starting—Difficulties of Starting—Compression, How to Test—Leakage of Valves and Cylinder— Lubrication of Piston and Bearings—Easing Piston— Synonymous Terms for Power Developed—Indicated Horse-power—Brake, Horse-power—Indicator Fully Described—Reducing Motions—Planimeters—Indicator- cards described in Detail and Analyzed—Defects as Shown by Indicator—How to Remedy Same—Early and Late Ignition, How to Alter—The Compression and Expansion Lines—Choked Exhaust—Mean Effective Pressure, How to Increase—Back Pressure of Exhaust— Tachometers—Fuel-consumption Test Fully Described— Mechanical Efficiency—Thermal Efficiency—Table of Disposition of Heat—Valve Diagram—Exhaust Gases— Complete and Incomplete Combustion—Testing the Flash-point of Kerosene—Viscosometer,	59-95
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------

CHAPTER IV.

COOLING WATER-TANKS AND OTHER DETAILS.

Water Connections—Capacity of Tanks Required— Gravitation System of Circulation—Water-pumps— Connection to City Water Main—Temperature of Outlet Water—Emptying Pipes in Frosty Weather— Salt Water—Exhaust Silencers—Brick Pit, How to Construct—Exhaust-Gas Deodorizer,

CONTENTS.

vii
PAGE

How to Connect—Connecting Circulating Water to Exhaust-pipe—Self-starters, Why Necessary—Utilizing Waste Heat of Exhaust Gases and of Cooling Water, Different Methods—Exhaust Temperature,	96-110
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------

CHAPTER V.

OIL ENGINES DRIVING DYNAMOS.

Isolated Plants—Advantages of Oil Engines as Compared with Gas and Steam Engines—Installation of Plant—Foundation, How to Build, Ingredients—Correct Location of Engine and Dynamo—Belts—Balance-wheel on Armature Shaft—Power Required for Incandescent and Arc Lamps—Losses of Power by Belt and Otherwise—Regulation of Engine Required for Electric Lighting—Direct-connected Plants, Advantages of Same—Variations in Incandescent Lights, Causes, How to Remedy—Silencing Air-suction,	III-122
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------

CHAPTER VI.

OIL ENGINES CONNECTED TO AIR-COMPRESSORS, WATER-PUMPS, ETC.

Direct-connected and Geared Air-compressing Outfits, with Dimensions and Pressures Obtained—Calculations of Horse-power Required—Tables of Pressures and Other Data—Efficiencies at Different Altitudes—Pumping Outfits Described in Detail, with Dimensions—How to Calculate Horse-power Required—Oil Engines Driving Ice and Refrigerating Machines, Calculations of Power Required—Friction-clutches,	123-138
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------

CHAPTER VII.

INSTRUCTIONS FOR RUNNING OIL ENGINES.

PAGE

General Instructions and Remarks—Cylinder Lubricating Oil—Instructions in Detail as to Running Hornsby-Akroyd Type, the Crossley Type, the Campbell Type, and the Priestman Type of Oil Engine—General Remarks—Regulation of Speed—How to Reverse Direction of Running of Engine, with Diagrams of Valve Settings,	139-156
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------

CHAPTER VIII.

REPAIRS.

Drawing Piston—Taking Off Piston-ring—Grinding in of Valves—Adjustment of Crank-shaft and Connecting-rod Bearings—How to Fit New Piston-ring to Cylinder—Fitting New Skew and Spur Gear—Renewing Governor Parts,	157-160
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------


CHAPTER IX.

VARIOUS ENGINES DESCRIBED.

General Description, with Illustrations of Different American and English Oil Engines—Method of Working—Sectional Cuts—The Crossley—The Cundall—The Campbell—The Priestman—The Mietz and Weiss—The Hornsby-Akroyd—The Diesel—Portable Oil Engines Described and Illustrated,	161-183
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------

TABLES.

	PAGE
I. Sizes of Crank-shafts,	27
II. Various Air Pressures,	126-127
III. Efficiencies of Air Compressors at Different Altitudes,	129
IV. Mean Pressure of Diagram of Gas (Ammonia) Compressor,	135
V. { Tests of Various Oil Engines Made in Edin-	
VI. { burgh,	184-185
VII. Calorific Power of Various Descriptions of Petroleum, etc.,	186
VIII. Composition, Physical Properties, etc., of Vari- ous Descriptions of Petroleum,	187
IX. Oil Fuel,	188
X. Calorific Power of Crude Petroleum,	188
Index,	189-196



LIST OF ILLUSTRATIONS.

	PAGE
Abel Oil-tester,	91
American-Thompson Indicator,	65
Apparatus for Open Fire Test,	91
Automatic Air Inlet-Valve,	41
Beau de Rochas Cycle, Diagram,	16
Campbell Diagrams,	167
Campbell Sprayer,	5
Campbell Type Engine,	166
Cams, Air and Exhaust,	37
Connecting-rod,	31
Connecting-rod Bearings,	159
Connecting-rod, Phosphor-bronze,	32
Crank-shaft Bearing,	54
Crank-shafts, Balanced,	28
Crank-shafts, Slab Type,	26
Crosby Indicator,	68
Crossley Diagrams,	163
Crossley Sprayer,	4
Crossley Type Engine,	162
Cundall Type Engine,	164
Cylinder,	22
Cylinder,	24
Diagram of Valve-settings,	60
Diagrams, Reversing Engine and Cams,	155
Diesel Motor,	178
Diesel Motor, Indicator Diagram,	180

	PAGE
Direct-connected Air-compressing Plant,	124
Dynamo Fly-wheel,	116
Electric Spark Igniter,	6
Engine and Dynamo, Belt-driven,	112
Engine and Refrigerating Machine,	132
Engine Connected to Water-pump,	130
Engine Connected to Water-pump, Small Type,	131
Engine foundation,	114
Exhaust Silencing Pit,	101
Exhaust Washing Device,	102
Fly-wheel,	36
Friction-clutch,	138
Geared Air-Compressing Plant,	128
Governor, Centrifugal Type,	45
Governor, Hit-and-miss Type,	47
Hill Self-recording Speed Counter,	85
Heating Lamp,	142
Heating Water-pipe Arrangement,	108
Heating Water-pipe Arrangement,	109
Hornsby-Akroyd Engine and Dynamo, Direct-connected,	118
Hornsby-Akroyd Horizontal Type,	174
Hornsby-Akroyd Sprayer,	10
Hornsby-Akroyd Vaporizer,	3
Hornsby-Akroyd Vertical Type,	175
Indicator Cock,	66
Indicator Diagram,	76
Indicator Diagram,	77
Indicator Diagram,	79
Indicator Diagram,	80
Indicator Diagram,	82
Indicator Diagram, Light Spring,	89
Indicator Diagram, Varying Pressures,	46
Indicator Diagrams, Hornsby-Akroyd,	176
Indicator, Reducing Motion,	67
Mietz and Weiss, Indicator Diagram,	172
Mietz and Weiss Engine and Dynamo, Direct-connected,	120

LIST OF ILLUSTRATIONS.

xiii

	PAGE
Mietz and Weiss Type Engine,	171
Oil Engine with Testing Apparatus Applied,	62
Oil-filter,	49
Oil-pump,	144
Oil-supply Pipe,	48
Piston-ring,	35
Piston, Section of,	34
Piston with Piston-rings,	56
Planimeters,	72
Planimeters in Position,	74
Portable Oil Engine,	182
Priestman Engine,	169
Priestman Indicator Diagrams,	170
Priestman Sprayer,	14
Priestman Vaporizer,	13
Self-starter,	106
Silencing Device,	104
Spur-gearing,	44
Starting Cam,	143
Tachometer,	84
Tachometer, portable,	85
Testing Oil-pump,	147
Two-cycle Plan,	17
Two-cylinder Engine,	52
Valve-box,	39
Valve-closing Springs,	40
Valve-levers,	146
Valve Mechanism,	44
Valves, Air and Exhaust,	42
Viscosometer,	94
Water-circulating Pump,	98
Water-cooling Tank and Connections,	97
Worm Gear,	43



CHAPTER I.

INTRODUCTORY.

THE internal combustion engines which are treated of in this work are those using heavy kerosene as fuel, otherwise called petroleum, coal oil or Scotch paraffin, and similar oils having specific gravity varying from .78 to .85 with flashing point of 75° to 300° Fahr.

The use of heavy oil for producing power in internal combustion engines appears to have received the attention of inventors as early as 1790, though no satisfactory practical kerosene or petroleum engine is recorded as having been made until about thirty years ago. Those engines using the lighter grade fuels, such as benzine, or gasoline, or naphtha, were commonly used previous to the invention of the kerosene-oil engine. The problem of efficiently producing a vapor and suitable explosive mixture of air with such vapor from these light oils was comparatively a very simple matter. Such engines are gas engines proper, with simply some form of carburetter added, but they can use only gasoline or naphtha as fuel. These are not treated of in this book, only oil engines proper being

described and discussed. The term oil engine refers to an internal combustion engine so designed as to effectively deal with and convert into power crude petroleum just as it is pumped from the earth, or any of the other fuels already named, without the aid of any outside agency or separate apparatus.

The production of a satisfactory device for properly vaporizing the heavier oils at first offered a problem which it was thought difficult to solve, and remained so for many years before the efficient vaporizing kerosene engines now in use were constructed.

IGNITERS.—The first oil engines built had their charge of vaporized oil and air ignited by means of the flame igniter, which has, however, now entirely given place to the four following means of ignition:

- (a) Hot surface ignition, aided by compression.
- (b) Hot tube.
- (c) Electric igniter.
- (d) High compression only.

The first-named type of igniter is illustrated in Fig. 1. In this instance the heated walls of the vaporizer act as the igniter, aided by the heat generated during compression of the gases. The chamber being first heated, afterward the proper temperature is maintained by the heat caused by the internal combustion of the gases. The best-known vaporizer and igniter of this type is that in the Hornsby-Akroyd Oil Engine. Various other somewhat similar devices in which sufficient heat is maintained to cause ignition automatically are also now being made.

The second type, that of the hot tube, is shown in

Fig. 2 and Fig. 3. This igniter consists of a porcelain,




FIG. I.

nickel or wrought-iron tube, which is maintained at red heat by external heating lamp, and is placed in the end





FIG. 2.



of the combustion chamber space, being always open to the cylinder, as shown.

THE ELECTRICAL IGNITER is made in various forms ;




FIG. 3.

that illustrated in Fig. 4 is of the "jump-spark" type. The current from the battery or other source of energy is connected to the regular induction or Rhumkorff coil

in which there are two windings of wire wound on core of iron wire, the one being made of coarse wire, the other winding being of fine wire. Where a vibrator is used in connection with the coil, the cam-shaft is arranged to close a switch, thus causing a series of sparks to jump across from one terminal to the other in the cylinder and ignite the gases. Other forms of




FIG. 4.

electrical igniters are the New Standard and the Splittdorf jump-spark apparatus.

The fourth-named type of ignition, that due to compression in the cylinder alone, is found only with the Diesel motor. The combustion is one of its unique features. In this type of engine the compression pressure inside the cylinder reaches about 520 pounds per square inch, the compression being arranged to continue until combustion commences to take place.

Advantages are claimed for each of these igniting devices by the various manufacturers using them. The

electrical igniter is easily controlled and is reliable, but the batteries, in unskilled hands, sometimes give trouble, and it is essential that the parts forming the contacts be kept clean and in good condition; otherwise faulty working of the engine will result.

The tube igniter always requires heating by the external heating lamp, upon which it is dependent, like all types of vaporizers which require external heat; so likewise is also the tube dependent entirely upon it. The former difficulty with ignition tubes and their frequent bursting has now been minimized by the use of nickel alloy, porcelain or other material more suitable than wrought iron for this purpose.

The hot surface type of igniter formerly gave trouble caused by its temperature cooling down at light loads. This type, however, which has now been adopted in various forms, has been designed to overcome this difficulty, and can now be relied upon to keep hot when running at light loads.

VAPORIZERS.—As already stated, the problem of efficiently vaporizing petroleum was the most difficult feature to encounter in designing oil engines. This obstacle has been, however, entirely overcome by different methods, and of recent years many types of engines using kerosene as fuel have been designed, and are now working satisfactorily.

The different types of vaporizers have been classified as follows:

1. The vaporizer into which the charge of oil is injected by a spraying nozzle being connected to cylinder through a valve.

2. That into which the oil is injected, together with some air, the larger volume of air, however, entering the cylinder through separate valve.

3. That vaporizer in which the oil and all the air supply (passing over it) is injected, but being without spraying device.

4. The type into which oil is injected directly, air being drawn into the cylinder by means of a separate valve, the explosive mixture being formed only with compression.

With each type of vaporizer some advantage is claimed, but corresponding disadvantage can perhaps be named. For instance, in type 1, though the mixture of oil and air is more complete, and the vaporizing probably greater than in the other types, yet the system of having an explosive mixture at any other place than in the cylinder and at any other period than at the time of actual ignition may be urged as a great disadvantage to this system.

With class 4 the mixture of air and oil may not be so complete, and the initial pressure in the cylinder consequent upon explosion less than the pressure obtained with other types; yet the extreme simplicity of this type is an advantage in daily use which cannot be overestimated.

With class 2 the highest mean effective pressure is obtained and the lowest consumption of oil per H. P. is believed to be recorded, but this type generally requires a heating lamp to maintain the proper temperature, and then on the efficiency of the heating lamp depends the efficiency of the engine itself. There have,

in recent years, been perfected some very simple smokeless kerosene burning lamps, and this previous difficulty has now accordingly been overcome.

One of the chief difficulties in designing a satisfactory vaporizer is that of making it such that at all loads and under all conditions it will vaporize the fuel. The heat of the chamber should be high enough to vaporize the oil, but never hot enough to decompose the oil, or a deposit of carbon will be made which is injurious to the satisfactory working of the vaporizer.

It would, therefore, appear that each type, while possessing features giving it individually an advantage as compared with other types, has some detracting feature also. The following is a description of the various types of vaporizers, showing the four different methods named in detail :

THE HORNSBY-AKROYD vaporizer is shown at Fig. 1, and also as it is at present manufactured in Fig. 76, which illustrates a complete section of this engine. The oil in this method of vaporizing is injected through the spray nipple, as shown in Fig. 5, directly into the vaporizer by the oil-supply pump. The injection of oil into the vaporizer takes place only during the air-suction stroke. The lever which actuates the air-valve also simultaneously operates the oil-pump. When the piston is at the outward end of the cylinder, the suction period being then completed, the cylinder is filled with atmospheric air, and the vaporizing chamber, which is at all times open to the cylinder, is also at the same time filled with oil vapor.

The compression stroke of the piston then com-

mences; the atmospheric air in the cylinder is thus driven through the contracted opening between the cylinder and the vaporizer into the vaporizer itself, already filled with the oil vapor. As compression due to the piston movement proceeds, the mixture which




FIG. 5.

at first is too rich to explode in the vaporizer gradually becomes more diluted with the air, and when the compression stroke is completed the mixture of oil, vapor and air attains proper explosive proportions. The mixture is then ignited simply by the hot walls of this

same vaporizing chamber and also by the heat generated by compression. No other means of ignition is necessary. No heating lamp is required to maintain the necessary temperature of this vaporizer; a lamp is, however, required to heat it for a few minutes before starting.

THE CROSSLEY method of vaporizing. This vaporizer is shown in section in Fig. 2. It consists of three main parts, the body, the passages, and the chimney cover. There are no valves about the vaporizer itself; it is arranged to keep hot, and while not in contact with the cooled cylinder is near to the vapor inlet valve to which it delivers its charges. The passages inside which vaporization of the oil takes place are detachable.

The wrought-iron ignition tube is placed below the vaporizer communicating directly with the cylinder. A heating lamp is always required to heat the vaporizer and maintain the ignition tube at proper red heat. The method of vaporizing is as follows:

When the suction stroke of the piston commences the oil inlet valve is automatically lifted from its seat and allows oil to be drawn into the vaporizer through it. The vaporizer blocks having been heated by the independent lamp, and likewise the chimney being hot also, heated air is drawn in passing first through the apertures in the sides of the chimney communicating with the passages of vaporizer blocks. The air is thus thoroughly heated, and next it passes over the heated cast-iron blocks. To these blocks the oil also flows from the oil measurer. The heated air here mingles with

the oil and vaporizes it, and the two together properly mixed are drawn into the cylinder through the vapor valve. Simultaneously, while the above process of vaporization is proceeding, air is also entering the cylinder through the air-inlet valve on the top of the cylinder. Thus, when the suction stroke of the piston is completed the cylinder is full of heated oil vapor drawn in through the vapor valve, too rich to explode by itself, and also atmospheric air drawn in through the air valve. Both elements are then compressed by the inward stroke of the piston completing the mixture of the oil, vapor and air. When compression is completed, ignition takes place by the gases coming in contact with the red-hot ignition tube.

THE CAMPBELL.—This method of vaporizing differs from those already described in that the whole charge of air to the cylinder is drawn in through the vaporizer. No air whatever enters the cylinder otherwise.

Fig. 3 represents the Campbell vaporizer in section. The fuel oil is fed to the vaporizer by gravitation from the fuel tank placed above the engine-cylinder, and enters the vaporizer with the incoming air. At the beginning of the suction stroke the automatic air-inlet valve is opened by the partial vacuum in the cylinder, and the oil which has entered through the small holes at the inlet valve is drawn through the heated vaporizer into the cylinder. At the compression stroke the mixture of the vapor is completed, and being forced into the ignition tube is ignited in the ordinary way. The ignition tube is heated by heating lamp fed by gravitation from the oil tank. The same lamp also heats the

vaporizer as well as the tube. The governing is effected by allowing the exhaust-valve to remain open when the normal speed is exceeded; consequently no charge is in that case drawn into the cylinder.

The method of vaporizing the oil with the PRIESTMAN engine is as follows:





FIG. 6.

The oil is stored under pressure in the fuel-tank, which pressure is created by the separate air-pump actuated from the cam-shaft. The oil is thus forced to the sprayer, which device is shown in Fig. 7, where it meets a further supply of air. The mixing of the air and oil takes place just as both elements are injected

into the vaporizing chamber, as shown in Fig. 6. The heating of the vaporizer is first accomplished with separate lamp; afterward, when the engine is working, the exhaust gases heat the vaporizer by being carried around in the outside passage of the vaporizer cham-



"A" - AIR PUMP CONNECTION
 "a" AIR PASSAGE TO SPRAYMAKER.
 "O" OIL TANK CONNECTION
 "o" OIL PASSAGE TO SPRAYMAKER.
 "B" SUPPLEMENTARY AIRVALVE.

FIG. 7.

ber, as shown in Fig. 6. On the outward or suction stroke of the piston the mixture of oil vapor and air already formed and heated in the vaporizer is drawn into the cylinder through the automatic inlet-valve shown on the left of Fig. 6. The compression stroke

then takes place in the ordinary course of the Beau de Rochas cycle.

The governing is effected by means of the pendulum or centrifugal governor, shown at Fig. 7, controlling the amount of air entering the vaporizer as well as reducing the supply of oil simultaneously. Thus, the explosive mixture is always composed of the same proportions of air and oil, but as the supply of air is thus curtailed the compression in the cylinder is also necessarily reduced when the engine is working at half or light load. The governor thus varies the pressure of the explosion, reducing it when necessary, but not causing at any time the complete omission of an explosion.


The system of throttling the pressure, somewhat similar to a steam engine, produces very steady running.

By this system a thorough vaporization of the oil takes place.

The ignition of the gases is caused by electric spark-igniter, the spark being timed by contact-pieces actuated from the cam-shaft and horizontal rod actuating the exhaust-valve, and is of the "jump-spark" type as shown in Fig. 4.

The oil engines now in use and herein described are designed with their valve mechanisms arranged to work either on the Beau de Rochas cycle, or on the two-cycle system. These two cycles are variously designated, the former being generally known as the Otto cycle, the four-cycle, and sometimes, but erroneously, the two-cycle. Correctly, it should be named the Beau

de Rochas cycle after its inventor. The other cycle is generally known as the "two-cycle," or sometimes as the "single cycle," the first designation, however, being correct. With those engines working on the Beau de Rochas cycle, which includes now many if not all the leading and best known types of engine,



THE BEAU DE ROCHAS CYCLE.

the cycle of operation of the valves is as follows:

(a) Drawing in the air and fuel during the first outward stroke of the piston at atmospheric pressure.

(b) Compression of the mixture during the first return stroke of the piston.


(c) Ignition of the charge and expansion in the cylinder during second outward stroke of the piston.

(d) Exhausting, the products of combustion being expelled during the second return stroke of the piston.

These operations are clearly shown in the accompanying illustration, and thus, in this system, the one cycle is completed in two revolutions of the crank-

shaft or during four strokes of the piston. The impulse at the piston is obtained only once during the two revolutions.

The second system, named "two-cycle," is com-



THE TWO-CYCLE PLAN.

pleted in one revolution, or every two strokes of the piston, and is also clearly shown by the accompanying illustration. The operation of the valves is as follows:

(a) During the first part of the outward stroke of the piston—that is, until the piston uncovers the exhaust-port—expansion is taking place. When the exhaust-port is opened the products of combustion are expelled; the piston then moves a little farther forward and uncovers the air-inlet port communicating with the crank chamber. The air at slight pressure at once rushes into the cylinder, assisting the expulsion of the burnt gases, and filling the cylinder with air already compressed to five or six pounds in the crank chamber; this completes the first stroke of this cycle.

(b) The next stroke (being the inward stroke of the piston) the supply of incoming air and fuel is first taken in; then compression of the charge takes place. Ignition follows when the piston reaches the back end. These two strokes of the piston, or one revolution of the crank-shaft, completes this cycle of operation.

ADVANTAGES AND DISADVANTAGES OF BOTH CYCLES.

The Beau de Rochas cycle engine, having only one impulse during two revolutions, requires the dimension of the cylinder to be greater in order to obtain a given power than would be required with the two-cycle system. Large and heavy fly-wheels must also be fitted to the engine in order to maintain an even speed of the crank-shaft. On the other hand, this cycle has many advantages. The explosion is controlled more readily. The idle stroke of the inlet air cools the cylinder and allows sufficient time to entirely expel the products of combustion, and with this sys-

tem no outside air-pump is required, nor is there any fear of the compression being irregular by leakage in the crank chamber or otherwise.

With the two-cycle system air must in some way be independently compressed. If this is accomplished in the crank chamber, then leakage may occur and bad combustion follow, with accompanying bad results to valves and piston. More cooling water is also needed to cool the cylinder, and the proper lubrication of the piston may consequently be very difficult to accomplish. With this system steadier running is obtained, nor are the heavy fly-wheels required as with the engines of the Beau de Rochas cycle.

Explosive engines were formerly quite extensively built to work on the two-cycle plan, either with independent air-pump or by compressing the air in the crank chamber, but as soon as the Otto patent expired a large number of engines were changed to that system. The former two-cycle engines were not economical, and when the economy of the Beau de Rochas or Otto cycle was demonstrated its superiority was quickly acknowledged.

Oil engines have more generally been built of the four-cycle than other explosive engines. In this work only one is described, which is operated on the two-cycle system, for which very satisfactory results are claimed.

CHAPTER II.

ON DESIGNING OIL ENGINES.

THE term "oil engine," as already stated in Chapter I., refers here only to those engines using as fuel ordinary kerosene or the crude and inferior heavy grades of petroleum of specific gravity .79 to .85, the power developed being derived from the explosion and combustion of a mixture of hydrocarbon gas and air similar to the impulse obtained in other internal combustion engines. Oil engines are similar in principle to gas engines, but as the liquid fuel must be vaporized or gasefied in an oil engine, an additional apparatus, as already fully described in the last chapter, is necessary to perform this process, which, with a gas engine, is accomplished separately and previously in the gas works or by "producer" gas plant.

The formulæ used for designing gas engines are generally applicable to oil engines also, but a greater factor of safety is sometimes allowed with the oil engine because it is possible, especially with some types of vaporizers, to occasionally have greater pressure of explosion than is ordinarily created chiefly by reason of improper combustion of the previous charge or by the governor having cut out several charges. For this

possible increased pressure, the strength of parts otherwise sufficient if of smaller dimensions are consequently increased. The formulæ herein given are derived chiefly from experience, and are believed to be in accordance with the best modern practice, and are also taken from well-known gas-engine hand-books by kind permission of the authors.

EXPLOSIVE ENGINES are of substantial design in order to withstand the continual shock and vibrations incident thereto, and should pre-eminently be as accessible as possible in the working parts, which may require adjustment from time to time when in actual service. The starting gear and other parts to be handled by the attendant when starting and running the engines incident to their operation should be placed in close proximity to each other.

Simplicity in construction is, in the writer's opinion, the essential feature of an oil engine. Above all other prime movers, the oil engine is a machine intended for use in any part of the world where its fuel is obtainable, and where, perhaps, no mechanic is available. Accordingly, all the valves should be arranged so as to be easily removed for examination and repairs. The spraying and igniting device, as well as the vaporizer, should be so designed as to facilitate removal and repairs. In short, an oil engine, to be successful mechanically and commercially, should be so constructed that it can be successfully worked, cleaned and adjusted by entirely unskilled attendants.

The mean effective pressure evolved in the different types of oil engines now in use varies from 40 to 75

lbs., and is less than the pressure obtained in the cylinder of gas and gasoline engines, which is often as high as 90 lbs. Consequently, to obtain relatively the same power, the dimensions of the oil-engine cylinder will be greater than those of the gas engine.

THE CYLINDER is made in different types, either to bolt up to the bed-plate as shown in Fig. 8, or is made




FIG. 8.

with faced flanges on the sides to be bolted down to the engine bed-plate, as shown in Fig. 9, in both instances being cast all in one piece. The cylinder as manufactured by some European makers is made in two and sometimes three parts, with internal joint. The inner liner being held at the back end only, the front end joint between the liner and the outer cylinder is made with rubber ring. This arrangement leaves the inner sleeve free to expand lengthwise, and

also allows the strain of the explosion to be transmitted only through the outer cylinder. Except for the larger-sized engines of over 40 H. P., the cylinder made in one piece is very satisfactory. The circulating water space around the cylinder is made as is shown in Figs. 8 and 9, being $\frac{3}{4}$ " to $1\frac{1}{2}$ " deep, the water inlet and outer pipes being so arranged as to allow free and efficient circulation of the cooling water around the cylinder. By some manufacturers this space for water is arranged to cool only that part of the cylinder covering the travel of the piston-rings, instead of the whole cylinder, as here shown. Other cylinders are cast in one piece with the frame or bed-plate having internal sleeve. This arrangement has, among other advantages, that of cheapness, but it has the disadvantage that if the cylinder for any reason should require renewing the whole frame must be renewed with it.

The cylinder cover is made in some engines with the valves, air-inlet valve housing or guide inserted into it, and with space also in the larger-sized engines arranged for cooling water-jacket. Other engines have the igniter placed in the cover, while cylinders of the type shown in Fig. 8 require no cover, the vaporizer flange closing the contracted hole in the end of the cylinder.

The cylinder in all cases should have the valves brought as close as possible to the cylinder walls, and all ports or passages so arranged as to offer the minimum amount of internal cooling surface to the hot gases of combustion.

CYLINDER CLEARANCE.—The percentage of clear-




FIG. 9.

ance in the cylinder is ascertained by dividing the total clearance in the cylinder, including all ports or other spaces, by the piston displacement.

The clearance allowed will depend upon the pressure of compression as determined by experiment and by the indicator diagram, producing properly timed ignition and combustion.

This pressure, it will be noted, on referring to the various indicator cards shown herein, now varies in different types of engines from 50 to 70 pounds, which it is believed is representative of present practice, with the exception of the Diesel motor, which engine compresses to over 500 pounds before combustion takes place in the cylinder. This exceedingly high compression is rendered possible by the special Diesel system of injection of the charge of fuel.

The fuel in this case enters the cylinder only at the extreme end of the stroke of the piston, the compression period being then completed.

THE CRANK-SHAFT of an oil engine must be made of sufficient strength not only to withstand the sudden pressure due to ordinary explosion, but also to withstand the strain consequent upon the greater explosive pressure which may possibly be caused by previous missed explosions, as already described. The crankshaft is proportioned in relation to the area of the cylinder and the maximum pressure of explosion and the length of stroke. Oil-engine crankshafts are usually made of the "slab type," as shown in Fig. 10. It has been said with regard to explosive engines that their comparative efficiency may be to a certain extent

gauged by the strength of the crank-shaft, because if the crank-shaft is of too small dimensions, it will spring with each explosion, causing the fly-wheels to run out of truth and also uneven wear of the bearings. Table I. gives a list of dimensions of crank-shafts of both oil and gas engines which are made by some leading manufacturers, together with the dimensions of the cylinder and stroke.

Different formulæ for the dimensions of crank-




FIG. 10.

shafts are given by various writers on this subject. The following, for example (which is recommended by the writer), is given by Mr. William Norris.

$$D = \sqrt[3]{\frac{S \times l}{120}}$$

S = load on piston (area of cylinder in inches \times maximum pressure of explosion.

l = length of stroke in feet.

D = diameter of crank-shaft in inches.

This formula, however, neglects the bending action due to the distance of the centre of crank-pin from the centre of the bearings. The diameter should be thus slightly increased. Mr. Norris also gives a lengthy description, with example, of ascertaining all the dimensions of the crank-shaft by means of the graphic method.

TABLE I.—SIZES OF CRANK-SHAFTS.

Cylinder.		A.	B.	C.	D.	E.	F.		G.
Diam.	Stroke.	in.	in.	in.	i.	in.	ft	in.	in.
5	8	$1\frac{3}{4}$	$1\frac{7}{8}$	4	$1\frac{1}{2}$	2		$6\frac{1}{2}$	$2\frac{1}{2}$
$5\frac{3}{4}$	9	$2\frac{1}{4}$	3	$4\frac{1}{2}$	$2\frac{1}{2}$	$2\frac{5}{8}$		$8\frac{1}{2}$	$3\frac{1}{2}$
$7\frac{1}{2}$	11	$2\frac{3}{4}$	$3\frac{1}{4}$	$5\frac{1}{2}$	$2\frac{3}{8}$	3		$9\frac{1}{2}$	$4\frac{1}{2}$
$8\frac{1}{2}$	15	$3\frac{1}{4}$	4	$7\frac{1}{2}$	$2\frac{7}{8}$	$3\frac{1}{2}$		$12\frac{1}{2}$	5
$8\frac{1}{2}$	18	$3\frac{1}{4}$	4	9	3	$3\frac{1}{4}$	1	2	5
$9\frac{1}{2}$	18	$3\frac{1}{2}$	$4\frac{1}{4}$	9	$3\frac{3}{8}$	$3\frac{1}{4}$	1	3	$5\frac{1}{2}$
12	18	$4\frac{1}{4}$	$4\frac{3}{4}$	9	$3\frac{3}{4}$	$4\frac{1}{2}$	1	$3\frac{1}{4}$	$6\frac{1}{4}$
$11\frac{1}{2}$	21	$4\frac{1}{4}$	$4\frac{3}{4}$	$10\frac{1}{2}$	4	$3\frac{1}{2}$	1	$3\frac{1}{2}$	$6\frac{1}{2}$
14	21	$5\frac{1}{2}$	$5\frac{3}{8}$	$10\frac{1}{2}$	$4\frac{1}{2}$	$4\frac{1}{4}$	1	5	$8\frac{1}{2}$
17	24	7	8	12	$5\frac{3}{4}$	$7\frac{1}{2}$	1	$10\frac{1}{2}$	10
19	30	$7\frac{1}{2}$	8	13	6	9	2	2	11
7	12	$2\frac{7}{16}$	$2\frac{5}{8}$	6	$2\frac{3}{16}$	$2\frac{5}{8}$		$8\frac{3}{4}$	$3\frac{3}{4}$
9	14	$2\frac{15}{16}$	3	7	$2\frac{1}{4}$	$3\frac{3}{8}$			4
11	15	$3\frac{7}{16}$	4	$7\frac{1}{2}$	$2\frac{9}{16}$	$4\frac{1}{8}$		$12\frac{1}{8}$	$4\frac{5}{8}$
$13\frac{1}{2}$	16	$3\frac{15}{16}$	$4\frac{7}{8}$	8	$3\frac{9}{16}$	$4\frac{7}{8}$		$13\frac{3}{8}$	$5\frac{3}{8}$

THE BALANCING of crank-shafts and reciprocating parts is another important feature of an oil engine. With a single-cylinder explosive engine to perfectly accomplish the balancing is impracticable. Most manufacturers, therefore, only balance their engines as far




FIG. II.

as the horizontal movement is concerned. The following formulæ is considered correct, and has proved satisfactory for the horizontal type of engines:

$$w = \frac{(C \times R) + G + (S \times r)}{a}$$

w = weight in lbs. of balance weight.

C = crank-pin and rotating part of connecting-rod in lbs.

R = radius of crank circle in inches.

G = two-thirds weight of all remaining reciprocating parts in lbs.

S = weight of crank-arms in lbs.

r = distance of centre of gravity of crank-arms from centre of rotation.

a = distance of centre of gravity of counterweight from centre of rotation.

Some designers, however, the writer has observed, make the crank balance weights as large as space between bearings and engine bed will allow—that is, when the weights are fastened to the crank-arms, as shown in Fig. 11, thus overbalancing the crank and reciprocating parts. While this would appear bad practice, such engines have been known to run without the slightest vibration. For the vertical type of engines the whole weight of the reciprocating parts, instead of two-thirds weight, has been satisfactorily taken.

Crank-shafts of explosive engines are sometimes balanced by metal suitably placed on the rim or hub of the fly-wheel; otherwise some wheels are made with recess

left in rim placed just in line with crank-pin, so that the metal left out of the rim of the fly-wheel will equalize the metal which is contained in the crank-pin and other parts to be balanced. Balancing by means of the recess at the outer radius of the fly-wheel has the advantage of requiring no extra metal, and is cheaper as regards workmanship as compared with the system as shown in Fig. 11. In each of these methods, however, the fly-wheel itself is out of balance, and when revolving tends to make the crank-shaft run out of truth.

The more expensive method of placing balance weights on the cheek of the crank-shaft itself, as shown in Fig. 11, is considered by the writer the most satisfactory method. In this way the crank-pin and reciprocating parts are themselves separately balanced regardless of the fly-wheels, and the fly-wheel being itself also balanced, when running allows the crank-shaft to remain absolutely true. Further, it is also advantageous to core small recesses in the fly-wheel rim, to be filled up, if required, with lead so as to exactly balance the wheel should it, from inequality in casting, be heavier in one part than in another. This, however, is only requisite in special cases, or where the engine is running at a very high rate of speed.

CONNECTING-RODS are made of various designs in cross-section, but that chiefly used is made of soft steel and circular, with marine type brasses at crank-pin end and similar bearings at the piston or small end. By some makers the latter bearing is made with adjustable wedge and screw, the end of the connecting-rod

then being slotted out, with brass bushes fitted into it, as shown at Fig. 12. For small engines a good and cheap form of connecting-rod is made of phosphor-bronze metal, as shown in Fig. 13.




FIG. 12.

The connecting-rod of a single-acting engine has, chiefly, compression strains to withstand; both the outer end bearings have little or no strain on them, except that due to momentum of the reciprocating parts. The connecting-rod should be from two to

three strokes in length. In computing its strength, the connecting-rod can be taken as a strut supported




FIG. 13.

at either end. The mean diameter when made of mild

steel is arrived at by the following formulæ, as given by authorities on steam-engine design :

$$x = 0.035 \sqrt{D l \sqrt{m}}.$$

x = mean diameter of connecting-rod (half sum of diameter of both ends).

D = diameter of cylinder in inches.

l = distance in inches between centre of connecting-rod.

m = maximum explosive pressure in lbs. per square inch.

This formula, however, is excessive for medium and slow speed engines, and in such instances the writer has used the following formulæ with satisfactory results—namely :

$$0.028 \sqrt{D l \sqrt{m}}.$$

THE PISTON in single-acting engines is generally of the trunk pattern, as shown in Fig. 14, with internal gudgeon-pin placed in the centre of the piston, secured at either end to the piston by set-screws. The steam-engine cross-head and slide-bars are dispensed with, the power being transmitted directly from the gudgeon-pin of the piston to the crank.

The piston is made of hard close-grained iron, and should not be less than 5-16" in thickness for small engines and slightly heavier for the larger sizes. In

each case the metal is thicker at the back, than at the front end. The piston is usually 1.6 diameters in length. Three cast-iron piston-rings, as shown in Fig. 15, are fitted to the smaller engines, four and five rings being required to keep the piston tight in the larger sizes. A single ring is sometimes added, placed in front of the gudgeon-pin, but its use is not recommended. The pressure on the piston, caused by the




FIG. 14.

explosive pressure and due to the angularity of the connecting-rod, should not be greater than 25 lbs. per square inch of rubbing surface.

PISTON SPEED.—The speed of the piston for horizontal oil engines is usually allowed to be not greater than 600 feet per minute; for the vertical type this is somewhat increased. The movement of the valves, oil spraying and vaporizing devices, it is usually assumed, precludes a higher speed. The writer has, however, worked a $1\frac{1}{2}$ B. H. P. vertical oil engine running at

600 revolutions per minute with satisfactory results. Thus, 300 movements of the valves, oil-pump and sprayer were completed per minute.

FLY-WHEELS on explosive engines are made much heavier than in steam engines of the same capacity.




FIG. 15.

The power is generated during only about twenty-five per cent. of the time of working in single-cylinder four-cycle explosive engines, hence the necessity of the very heavy fly-wheels in order to maintain a steady speed of the crank-shaft. The function of the fly-

wheel, it may be said, is to store up the energy imparted during the explosion period and pay it out again during the period of the three idle strokes of compression, suction and exhaust. Two fly-wheels are generally supplied, one placed on each side of the main bearings. Some of the European makers, however,




FIG. 16.

are now building their larger engines provided with one heavy fly-wheel only, a separate outside bearing being fitted in that case.

The diameter of the fly-wheel is usually such that the peripheral speed is from 4000 to 5000 ft. per minute; 6000 ft. is considered the maximum allowable speed.

The hub of the fly-wheel is sometimes split and bolted together. Oil-engine fly-wheels are usually made as shown in Fig. 16. The weight of the rim can be calculated as follows:

$$w = \frac{C \times \text{I. H. P.}}{D^2 \times N^3},$$



where

C = constant.

I. H. P. = indicated horse-power.

D = diameter of fly-wheel in feet.

N = revolutions per minute.

w = weight in lbs. of rim.




FIG. 17.

The constant varies according to the fluctuation in speed permissible; for engines required to run dynamos for electric lighting purposes, $C = 50,846,290,000$. For engines actuating general machinery C is considered sufficient when taken as $30,507,700,000$.

The cams are made of cast iron or steel and are usually designed as shown in Fig. 17. Cast iron is ad-

vantageously "chilled" so as to withstand the wear of the rollers. The cams, it is considered, however, should preferably be designed of larger diameter than they are now made.

The air cam is usually made about $\frac{3}{4}$ " wide. The exhaust cam, which has more work to perform at the period of opening the valve, is made with wider surface than the air cam.

CYLINDER LUBRICATORS.—The lubrication of the piston in explosive engines is of great importance. On those engines where it is convenient to use it, a mechanical type of lubricator is added. This device consists of an oil reservoir into which a wire attached to a revolving spindle is periodically dipped, the wire being also arranged to wipe over a projection which conducts the oil to a receptacle placed above the reservoir and connected to the top of the cylinder. The revolving spindle is driven by belt from the cam-shaft. This lubricator is advantageous because the oil must be always fed to the piston while the engine is working, and the lubricator cannot be left unopened by the attendant, and also because all grit or dirt in the oil is precipitated to the bottom of the reservoir and cannot flow to the piston. Sight-feed lubricators are also now used for the lubrication of the piston, and have proved quite as satisfactory as the mechanical oiler.

VALVES AND VALVE-BOXES.—The dimensions of the air-inlet and exhaust valves are governed by the diameter of the cylinder and the piston speed. The style of the valve-box recommended is that made separate and bolted to the cylinder. The valve-box can then

be entirely renewed if necessary and at small expense. This type of valve-box is shown at Fig. 18, both valves being operated from the cam-shaft. The springs necessary to close air and exhaust valves in engines over 10 brake or actual H. P. are best placed so as not to be in close proximity to the heat. An arrangement of the closing springs of this description, with a type of spring having separate hooks at each end, is shown in Fig. 19.

Where the air-inlet valve is made automatic, it is




FIG. 18.

opened by the partial vacuum in the cylinder during the suction period, and closed by a delicate spring, as shown in Fig. 20. The air and exhaust valves and port openings are usually made of such an area that the velocity of the air inlet as it enters the cylinder is 100 feet per second—the velocity of the exhaust gases through the exhaust or outlet being about 80 feet per second, presuming the exhaust products to be expelled at atmospheric pressure. The air-inlet valve, if automatic, should be so arranged as to allow ingress of air

without choking. In calculating the area of valve ports or passages, allowance must be made for valve




FIG. 19.

guide or other obstruction in the passages. The velocity of the air is found in the following formulæ:

$$V = \frac{a \times P}{a_1}$$

V = velocity of air in ft. per second.

P = piston speed in ft. per second.

a = area of piston in inches.

a_1 = area of valve opening in inches.

THE EXHAUST BENDS close to valve-box should when possible be of not less than 5" radius for the




FIG. 20.

smaller engines, which dimension should be increased for larger-sized engines.

The valves are made of forged steel, either in one piece or with cast-iron valve and wrought-iron or steel stem fitted into it, and are shown in Fig. 21. Some manufacturers prefer the latter on account of cheapness, and also because it is claimed the cast-iron valves will withstand heat better than the forged valve.

THE CRANK-SHAFT bearing should be of such dimensions as to allow a pressure of not more than 400 lbs. per square inch on the projected area, and should be easily adjustable. These bearings are made either of brass or babbitt metal. The maximum pres-




FIG. 21.

sure allowed on the piston-pin should not be more than 1000 lbs. per square inch of projected area.

THE ENGINE FRAME should be of substantial proportions and strongly ribbed to prevent vibration, or what is known as "panting," at each explosion. The frame is shown in section in Fig. 76.

THE CRANK-PIN appears to be made of various

dimensions in different types of engines; a short pin of large diameter is, however, recommended, the diameter being not less than 1.2 times the shaft. (See Table I.) The average pressure allowed is 500 lbs. per square inch on the projected area.

VALVE MECHANISMS.—With the Beau de Rochas or four-cycle engine the valves are only operated during alternate revolutions of the crank-shaft. This necessitates an arrangement of some kind of two-to-one gear. Worm-gear, as shown in Fig. 22, is considered




FIG. 22.

to be well adapted for this work. The power necessary to operate the valves is, in this case, transmitted from the crank-shaft by the worm or skew gearing through the cam-shaft, with separate cams opening the air and exhaust valves by the operating levers, as shown in Fig. 23. Where spur-gearing (Fig. 23a) is used the cam-shaft is mounted in bearings parallel to the crank-shaft, the cams then acting on the horizontal rod working in compression, which opens the valves.

Various other arrangements for reducing the motion are also used, the work accomplished being in each

case the same as with the worm or spur gear, shaft and levers—namely, the opening of the valves during alternate revolutions of the crank-shaft.




FIG. 23.

In the two-cycle engine this valve or valves are operated each revolution of the crank-shaft by eccentric or cams actuated directly from the crank-shaft.




FIG. 23a.

GOVERNING DEVICES.—The governing devices for controlling the speed of oil engines are of two kinds: first, that designed to develop centrifugal force, which

is balanced either by suitable controlling spring or dead weight, as shown in Fig. 24, and, secondly, the inertia or pendulum type of governor, in which a weight is




FIG. 24.

placed on a part of the reciprocating valve motion, and is so arranged as to have its movement controlled by a spring usually having adjustable tension. (See Fig. 26.) The governors regulate the speed of the engine by the following different methods:

- (a) By acting through suitable levers or other mechanism on the valves controlling the fuel supply to the cylinder, either by means of a by-pass valve placed in the oil-supply pipe to vaporizer, thus allowing part of the charge of oil to return to the tank instead of entering the vaporizing chamber or by regulating the amount of oil as well as the air supply.
- (b) Acting directly on the oil-supply pump, length-

ening or shortening the stroke of the pump, as required.

(c) Where the oil vapor is arranged to be drawn into the cylinder with the incoming air the governor




FIG. 25.

acts on the exhaust-valve, holding it open during the suction stroke, thus preventing the inlet of vapor to the cylinder.

(d) By acting on the vapor inlet-valve, allowing this valve to open only when an impulse to the piston is required.

Engines driving dynamos for electric lighting and requiring very close regulation are preferably governed by the system of throttling or reducing the explosive pressures in the cylinder. Thus, when the engine exceeds the standard speed for which the governor is set, only part of the vapor or oil is allowed to enter the

vaporizing chamber or cylinder. The mixture of oil,




FIG. 26.

vapor and air is accordingly regulated, and the mean effective pressure as required is suitably reduced.

The indicator diagram illustrates the variation of the M. E. P. in the cylinder, as shown in Fig. 25, each expansion line registering a different pressure. No explosion is in this case omitted entirely, and conse-




FIG. 27.

quently the running of the engine is even and regular.

The hit-and-miss type of governor is shown in Fig. 26. This device is made in many different forms, the mode of working being similar in them all—namely,

the inertia of a weight controlled by the spring. When the speed of the crank-shaft is increased the weight is moved correspondingly quicker; its inertia is then increased, and the strength of the spring is overcome sufficiently to allow the engaging parts of the valve motion to be disengaged during one or more revolutions, and consequently where this device acts on the oil-pump the charge of oil is missed, and no explosion takes place during the following cycle of operations.

THE OIL-SUPPLY PUMP is placed against the oil-tank and base of engine or on bracket bolted to cylinder. It is usually made of bronze, with steel ball valves. Duplicate suction and discharge valves are advantageous in case one valve on either side should leak. Fig. 27 represents oil-pump as used on the Hornsby-Akroyd oil engine.

THE FUEL OIL-TANK is placed in or bolted against




FIG. 28.

the base of the engine. It is then made of cast iron as part of the base of the engine; otherwise the tank is made of galvanized iron and separate from the engine

base, so that it can be taken out when required for cleaning.

A filter or strainer for cleaning the oil as it passes to the oil-pump is placed in the tank, arranged so as to be easily removed for cleaning, as shown at Fig. 28.

HORIZONTAL AS COMPARED WITH THE VERTICAL TYPE OF OIL ENGINES.

THE accessibility of the piston with the horizontal engine is considered a great advantage. The piston can always be seen and can be drawn out of the cylinder and cleaned and replaced with ease in this style of engine, whereas in a vertical engine it is necessary to remove the cylinder cover, and perhaps other parts, to gain access to the piston, and also it is necessary to have sufficient head room above the top of the cylinder for chain-block to lift the piston and connecting-rod. The lubrication of the piston is also considered more effective in the horizontal than in the vertical type of engine. Furthermore, the connecting-rod is more accessible for adjustment both at the crank-pin end and at the piston end in the horizontal type. This difficulty, however, has been overcome by arranging a removable plug in the cylinder casing, which when taken out allows access for adjustment to the piston end of the connecting-rod. European designers seem much in favor of the horizontal type of engines, and although some leading makers build the vertical type of engines, yet the greater number would appear to be made of the horizontal type.

VERTICAL ENGINES for situations in buildings where space is restricted and where sufficient head room is available have the great advantage of occupying less floor space than the horizontal type. The mechanical efficiency of a vertical engine is somewhat greater, the friction of the piston being less than in the horizontal type of engine.

The vertical type for some special purposes can, of course, only be used, but for ordinary uses the horizontal type of engine at present seems to be most in favor, one consideration being the difficulty of suitably arranging the vaporizing and spraying details in the vertical type of engine, which are usually placed close to the cylinder, and are, therefore, not so fully under the control of the attendant as in the horizontal type.

TWO-CYLINDER ENGINES.—Objection is sometimes made against two-cylinder oil engines because of the increased number of working parts, which may possibly become deranged, and also because of the exact adjustments which are considered necessary.

The oil-supplying apparatus and all the mechanism required with a single-cylinder engine has to be duplicated with the two-cylinder type. In order that the work and wear on all crank-shaft and connecting-rod bearings may be exactly similar the same explosive pressures must be evolved in each cylinder. This necessitates close adjustment of the vapor supply. The governing mechanism (where one governor controls two different oil-supply devices) also requires fine ad-

justment, and provision has to be made for adjusting lost motion due to wear.




FIG. 29.

The two-cylinder engine, however, has many ad-

vantages. In the first place, it receives an impulse each revolution of the crank-shaft, and consequently the energy of the fly-wheel is only required to maintain the normal speed of the crank-shaft during half a revolution, instead of the three strokes as required in the single-cylinder type. To obtain relatively the same power as with one large cylinder, the two smaller cylinders cause less vibration at the foundation. The efficiency, however, of the two small cylinders is reduced as compared with the one large cylinder, on account of the increased surface of cylinder cooling space.

The two-cylinder engine, as shown in Fig. 29, has the oil-supply pump actuated from the crank-shaft instead of, as is usual, from the cam-shaft, an injection of oil thus being given at each revolution. The oil-supply pipe leading to each cylinder or vaporizer is fitted with check-valves, which are alternately opened by the pressure of the pump, being otherwise held closed by the pressure of compression and of explosion alternately in each cylinder.*

ERECTING AND ASSEMBLING OF OIL ENGINES.

The following remarks relating to the erection of oil engines contain a few hints on important points of this work, the information being intended for those

* This method of fuel injection forms the subject-matter of U. S. patent 650,583, granted to the writer May 29, 1900.

readers not sufficiently familiar with the assembling of explosive engines to be cognizant of the parts requiring careful handling and accurate workmanship.

BEARINGS.—In scraping in the crank-shaft bearings of horizontal engines the shaft must bear perfectly on that part of the bearings as shown in Fig. 30, marked




FIG. 30.

A, the greater pressure being on the part of the bearing which is between the centre line of engine drawn through the cylinder and the part through which the vertical centre line of fly-wheel is drawn. A slight play of about $\frac{1}{64}$ " can be given to the crank-shaft sideways in the bearings in smaller-sized engines, and $\frac{1}{32}$ of an inch in the larger sizes is recommended.

In vertical engines the bearings receive both the pressure of explosion and the pressure due to the weight of the fly-wheels in the same part, and these bearings require the same care at those points in the lower half of the bearing—namely, about 45° each side of the centre line drawn vertically through the cylinder and crank-shaft. The bearing surfaces of the caps and of that part where the pressure is not so great do not require such careful scraping as those parts where the pressure is greater.

PISTON AND PISTON-RINGS.—The fitting of piston and piston-rings is very important and requires accurate workmanship. The cylinder and piston are machined to standard ring and gauge, one-thousandth per inch diameter of cylinder play being allowed. The metal of the piston not being of uniform thickness after machining may slightly lose its shape, and sometimes requires slight hand-filing when being fitted to the cylinder. The piston without rings can be moved easily up and down inside the cylinder. If necessary the piston should be eased slightly by hand on the sides, being left a good and close fit at the top and bottom bearing in horizontal engines. The sides should not rub hard in any part. The piston, if the rings are in place, can be fitted to the cylinder from the back end of the cylinder, and can be moved around the front end, being inserted into cylinder as far as the rings.

THE DISTANCE-PIECES or junk-rings should not touch the sides of the cylinder, the bearing of the piston being only on the trunk of the piston itself. The front

part of the piston can also be bevelled for $\frac{3}{4}$ " in length, 1-32" in diameter, as shown in Fig. 14.

THE PISTON-RINGS, if made as in Fig. 15, should have in the smaller sizes 1-32" play, in the larger sizes 1-16", as shown at *A* in Fig. 31. This space allows for expansion when the ring becomes heated in working. It is advantageous to insert dowel-pins in the piston grooves to maintain the rings in the same position, so that the space in each ring is out of line with that in the following ring, as also shown in Fig. 31.




FIG. 31.

THE PISTON is made in one piece, the rings being sprung on over the junk-rings. It should be remembered that with oil engines greater heat is evolved in the cylinder than in steam engines. Consequently the slightest play is allowed to the piston-rings at the sides, and are, therefore, not made so tight a fit as in steam-engine practice.

THE CONNECTING-ROD BEARINGS at piston end are

scraped in the ordinary way, and should be allowed slight play sideways on the gudgeon-pin. In smaller-sized engines 1-64" can be allowed, this amount being slightly increased in the larger-sized engines. The crank-pin bearing of the connecting-rod is usually allowed a very slight play sideways also.

THE AIR AND EXHAUST VALVES should not be a very close fit in their guides. If the fit in these guides is made too close when the valve-box becomes heated the consequent expansion may cause the valve-stem to stick in the guides, and leakage of the valve will result.

The valve-seats are by some considered best left sharp, being not more than 1-32" wide before grinding.

THE WATER-JACKETS of cylinder or valve-boxes should be all tested by hydraulic pressure to at least 120 lbs. pressure per square inch before the piston is put into the cylinder.

THE FLY-WHEELS require careful keying onto crank-shaft. If the keys are not a good fit and not driven home tight the engine may knock when running. Two keys in larger-sized engines are usually supplied, one being a sunk key, which is fitted to keyway in recessed shaft as well as to the keyway cut in the fly-wheel hub, the second key being only recessed in the fly-wheel and being concave on the lower side to fit the shaft.

OIL-SUPPLY PIPES which have to withstand pressure should have the fittings "sweated" on, the unions being screwed into place on the brass or copper pipe while the solder is still in a liquid state.

CYLINDERS made of two or more parts require the joints of internal sleeve to be made with great care.

Asbestos or a copper ring is used to make this joint; sometimes wire gauze with asbestos is used, which has been found to give very good results.

[Tables giving the Calorific Values of Oils, etc., will be found at end of book.]

CHAPTER III.

TESTING ENGINES.

THE chief object in testing explosive engines at the factory is to ascertain that, in actual working at different loads, the several adjustments are correct. In the steam engine a physical process is completed, requiring only the inlet, expansion, and the outlet of the steam to and from the cylinder, whereas in the oil engine a chemical process is gone through consisting of the introduction of the proper mixture of vaporized oil and air into the cylinder, the ignition of this explosive mixture and the consequent combustion. All this must be accomplished before the piston receives an impulse. In order, therefore, that the best results be obtained, the different mechanisms controlling these processes are each set, and record of their performance during the test is taken with the indicator, which results are again verified by some form of brake attached to the fly-wheels or pulley of the engine, and are further checked in an oil engine by the record of the amount of oil which is consumed for the power developed. Where more detailed tests are required, the temperature of the exhaust gases, the amount of air consumed in the cylinder, its temperature and barometrical pres-

sure, together with the amount of cooling water necessary to keep the cylinder to the required temperature, are each noted and recorded. When the test is made with a new engine, it should be first started up and run without any load for a short time. The cams are set as




FIG. 32.

shown in diagram, Fig. 32, for engines having both air and exhaust valves actuated from the crank-shaft. The air-valve closes, as shown, just after the crank-pin has passed the out centre, the exhaust-valve opening at about 85 per cent. of the full stroke and closing just

after the air-valve has opened. Where the air-inlet valve is automatic the exhaust-cam only is set, as shown in the diagram, and the air-valve spring should be adjusted so that the incoming air is not choked in passing the valve during the suction stroke.

The oil-pipes leading to the vaporizer or sprayer should be well washed before starting the engine, as with a new engine grit and filings may get into the pipes, and when the engine is started the oil-valves and valve-seats may be damaged. The oil-filter also must be in proper shape and clean, so that the oil can flow freely to the oil-pipe.

After the vaporizer and igniter has been well heated a little oil should be allowed to enter the vaporizer or combustion chamber; then the fly-wheels can be turned forward a few times, after which the engine should start freely. The method of starting the different types of engines is explained in detail in Chapter VII. An engine is sometimes found difficult to start the first time owing to some defect in the castings or workmanship, and if it fails to start, the engine should be examined in detail to ascertain the cause.

First test the oil-inlet or spraying device by hand; then test the pressure of compression in the cylinder by turning the fly-wheels backward. The relief-cam being out of action, it should not be possible with full compression to turn the fly-wheel past the back centre. If the compression is so slight that the pressure in the cylinder can be overcome and the fly-wheel turned during the compression period by hand, then either the piston-rings are leaking or there is leakage past




FIG. 33.

the air and exhaust valves or through some of the joints or gaskets. Air and exhaust valves and piston-rings should be examined, and any appearance of leakage remedied by refitting the piston-rings, as already explained in Chapter II., and the valves, if necessary, should be reground in. New engines also fail to start at times by reason of the leakage of water from the cooling jacket into the cylinder owing to faulty gaskets or flaws in the castings. This leakage of water may sometimes be ascertained by failure to obtain an explosion in the combustion chamber when all conditions in the cylinder and vaporizer are apparently in good order for the engine to start properly. If leakage of water is suspected but cannot be detected in this way, the water-pressure pump should be attached and the water-jackets tested to a pressure of 120 lbs. The crank-shaft and other bearings require careful oiling at first, and full lubrication should be given to the piston; otherwise it may, perhaps, work dry and cut the cylinder.

After working a few hours, the piston should be withdrawn and examined; any hard places on the sides should be eased either by careful hand filing or otherwise. The junk-rings (or distance-pieces between the rings) should be eased if necessary, so that they do not work hard on the cylinder. The full bearing of the piston should be from about $\frac{1}{2}$ " from rings forward to within $\frac{3}{4}$ " of the front end, as already explained in Chapter II.

The terms "brake," or "developed," or "actual" or "effective" H. P., are synonymous, and are used

to signify the power which an engine is capable of delivering at the fly-wheel or belt-pulley. This power is variously designated, and here we shall use the abbreviation B. H. P. to express it. The indicated H. P. represents the whole power developed by combustion in the cylinder, but it is not considered such a reliable method of measuring the power of explosive engines as that of the dynamometer or brake, because the indicator-card only gives the power developed by one or more explosions, whereas the brake can be applied for any length of time and shows the average performance of the engine for a longer period of time.

Fig. 33 illustrates the engine as arranged for testing in the factory. The fuel tank shown at the left hand is placed there for the purpose of running the oil-consumption test. The fuel pump is connected temporarily to this tank instead of taking its supply of oil from the tank in the base of the engine. The indicator is also shown in place on the top of the cylinder. The device for reducing the stroke of the crank to suitable dimensions for the indicator is also shown in place bolted to the bed-plate of the engine. The brake consists of rope $\frac{1}{2}$ " thick, with wooden guides with balances at each extremity. The upper balance is suspended by adjustable hook suitably arranged for altering the load on the brake.

Various kinds of dynamometer brakes are used for testing; that shown in Fig. 33 is considered by the writer as being satisfactory. The brake should be attached as shown in the illustration, the load being taken as the number of pounds shown on the upper

scale less those shown on the lower scale. Brake or actual H. P. is calculated thus:

$$\text{B. H. P.} = \frac{W \times C \times N}{33,000}.$$

W = net load in pounds.

C = circumference of wheel.

N = number of revolutions per minute.




FIG. 34.

The circumference of the wheel should be measured at the centre of the rope, thus allowing for half the rope thickness.

INDICATORS.—Fig. 34 shows the American Thompson Improved Indicator with $\frac{1}{4}$ " area piston.

THE INDICATOR is attached to the cylinder by first screwing into the cylinder the indicator cock, as shown at Fig. 34*a*, to which the indicator is applied in the ordinary way.

The length of the stroke of the engine must be reduced to suit the dimensions of the diagram, which is




FIG. 34*a*.

usually about 3" long. This is accomplished by the use of a device, as shown in Fig. 35.

Indicated H. P. is calculated thus:

$$\text{I. H. P.} = \frac{P L A E}{33,000}.$$

P = mean effective pressure in lbs.

L = length of stroke in feet.

A = area in inches of piston.

E = number of explosions per minute.

The M. E. P. of indicator-card is obtained by the use of the planimeter, as shown in Fig. 37, or by measuring the card by scale and taking the average pressure.

The illustration (Fig. 36) shows the design and




FIG. 35.

arrangement of the parts of the Crosby gas-engine indicator. The cylinder proper is that in which the movement of the piston takes place. The piston is formed from a solid piece of tool steel, and is hardened to prevent any reduction of its area by wearing. Shal-

low channels in its outer surface provide an air packing, and the moisture and oil which they retain act as lubricants, and prevent undue leakage by the piston.




FIG. 36.

The piston is threaded inside to receive the lower end of the piston-rod and has a longitudinal slot which permits the bottom part of the spring with

its bead to drop on to a concave bearing in the upper end of the piston-screw, which is closely threaded into the lower part of the socket; the head of this screw is hexagonal, and may be turned with a hollow wrench.

The swivel-head is threaded on its lower half to screw into the piston-rod more or less according to the required height of the atmospheric line on the diagram. Its head is pivoted to the piston-rod link of the pencil mechanism. The pencil mechanism is designed to eliminate as far as possible the effect of momentum, which is especially troublesome in high-speed work. The movement of the spring throughout its range bears a constant ratio to the force applied, and the amount of this movement is multiplied six times at the pencil point.

SPRINGS.—In order to obtain a correct diagram, the height of the pencil of the indicator must exactly represent in pounds per square inch the pressure on the piston of the oil engine at every point of the stroke; and the velocity of the surface of the drum must bear at every instant a constant ratio to the velocity of the engine piston.

THE PISTON SPRING is made of a single piece of spring steel wire, wound from the middle into a double coil, the spiral ends of which are screwed into a brass head having four radial wings to hold them securely in place; 80 to 200 lb. spring is a suitable pressure for this work.

This type of indicator is ordinarily made with a drum one and one half inches in diameter, this being

the correct size for high-speed work, and answering equally well for low speeds.

To remove the piston and spring, unscrew the cap; then take hold of the sleeve and lift all the connected parts free from the cylinder. This gives access to all the parts to clean and oil them.

To change the location of the atmospheric line of the diagram.—First, unscrew the cap and lift the sleeve, with its connections, from the cylinder; then turn the piston and connected parts toward the left, and the pencil point will be raised, or to the right and it will be lowered. One complete revolution of the piston will raise or lower the pencil point $\frac{1}{8}$ " , and this should be the guide for whatever amount of elevation or depression of the atmospheric line is needed.

To change to a left-hand instrument.—If it is desired to make this change: First, remove the drum, and then with the hollow wrench remove the hexagonal stop screw in the drum base, and screw it into the vacant hole marked *L* ; next, *reverse* the position of the adjusting handle in the arm; also, the position of the metallic point in the pencil lever; then replace the drum, and the change from right to left will be completed.

The tension on the drum spring may be increased or diminished according to the speed of the engine on which the instrument is to be used, as follows: Remove the drum by a straight upward pull; then raise the *head* of the spring *above* the *square* part of the spindle, and turn it to the right for more or to the left for less tension, as required; then replace the head on the spindle.

Before attaching the indicator to an engine, allow air to blow freely through pipes and cock to remove any particles of dust or grit that may have lodged in them.

The indicator should be attached close to the cylinder whenever practicable, especially on high-speed engines. If pipes must be used they should not be smaller than half an inch in diameter, and as short and direct as possible.

The indicator can be used in a horizontal position, but it is more convenient to take diagrams when it is in a vertical position, and this can generally be obtained, when attaching to a vertical engine, by using a short pipe with a quarter upward bend.

The motion of the paper drum may be derived from any part of the engine, which has a movement coincident with that of the piston. In general practice and in a large majority of cases the piston itself is chosen as being the most reliable and convenient.

When the indicator is in position and the cord-drum or other reducing motion is correctly placed, it is next necessary to adjust the length of the cord, so that the drum will clear the stops at each extreme of its rotation. The engine should be allowed to run for a few minutes to heat up before taking a diagram. The atmospheric line should be drawn by hand, preferably after the diagram has been taken and when the instrument is heated up; the card is then taken with full-rated load on the brake. It is well to allow the pencil to go several times over the paper so as to procure a card showing several explosions, and thus the average pressure can be taken.

The pressure of the pencil on the paper can be adjusted by screwing the handle in or out, so that when it strikes the stop there will be just enough pressure on the pencil to give a distinct fine line. The line should




FIG. 37.

not be heavy, as the friction necessary to draw such a line is sufficient to cause errors in the diagram.

THE PLANIMETER or averaging instrument is shown at Fig. 37. No. 1 planimeter is the simplest form of the instrument, having but one wheel, and is designed to measure areas in square inches and decimals of a

square inch. The figures on the roller wheel *D* represent *units*, the graduations *tenths*, and the vernier *E* gives the *hundredths*. *F* is the tracer and *P* is the pivot.

Fig. 37 represents the No. 2 planimeter, which is the same as the No. 1, with the addition of a counting disc *G*, the figures on which represent *tens* and mark complete revolutions of the roller-wheel. By this means areas greater than ten square inches can be measured with facility. The result is given in square inches and decimals, and the reading from the roller wheel and vernier is the same as with No. 1.

Fig. 37 represents the No. 3 planimeter, which differs somewhat in design from the two previously described. It is capable of measuring larger areas, and by means of the adjustable arm *A* giving the results in various denominations of value, such as square decimeters, square feet and square inches; also of giving the average height of an indicator diagram in fortieths of an inch, which makes it a very useful instrument in connection with indicator work.

DIRECTIONS FOR MEASURING AN INDICATOR DIAGRAM WITH A NO. 1 OR NO. 2 PLANIMETER.

Care should be taken to have a flat, even, unglazed surface for the roller wheel to travel upon. A sheet of dull-finished cardboard serves the purpose very well. Set the weight in position on the pivot end of the bar *P*, and after placing the instrument and the diagram

in about the position shown in Fig. 37a, press down the needle point so that it will hold its place, set the tracer; then at any given point in the outline of the diagram, as at *F*, adjust the roller wheel to zero. Now follow the outline of the diagram carefully with the tracer




FIG. 37a.

point, moving it in the direction indicated by the arrow, or that of the hands of a watch, until it returns to the point of beginning. The result may then be read as follows: Suppose we find that the largest figure on the roller wheel *D* that has passed by zero on the vernier *E* to be 2 (units) and the number of graduations that have also passed zero on the vernier to be 4

(tenths), and the number of graduation on the vernier which exactly coincides with the graduation on the wheel to be 8 (hundredths), then we have 2.48 square inches as the area of the diagram. Divide this by the length of the diagram, which we will call 3 inches, and we have .8266 inch as the average height of the diagram. Multiply this by the scale of the spring used in taking the diagram, which in this case is 40, and we have 33.06 pounds as the mean effective pressure per square inch on the piston of the engine.

DIRECTIONS FOR USING THE No. 3 PLANIMETER.

No. 3 planimeter is somewhat differently manipulated, although the same general principle obtains. The figures on the wheels may represent different quantities and values, according to the particular adjustment of the sliding arm *A*. If it is desired merely to find the area in square inches of an indicator diagram, set the sliding arm so that the 10-square-inch mark will exactly coincide with the vertical mark on the inner end of the sleeve *H* at *K*. The sliding arm is released or made fast by means of the set-screw *S*.

With the wheels at zero and the planimeter and diagram in the proper position, trace the outline carefully and read the result from the roller wheel and vernier, the same as directed for the No. 1 and No. 2 instruments.

THE INDICATOR-CARD shows what is occurring inside the cylinder and combustion chamber during the different periods of the revolution. It gives a record of the

variations in pressure, and also the exact points of the opening and closing of the valves. With the Otto or Beau de Rochas cycle the four strokes are as follows: Suction (*A*), compression (*B*), expansion (*C*), exhaust (*D*). The lines in the diagram are correspondingly lettered (see Fig. 38), and they represent each of these processes.




FIG. 38.

Fig. 39 shows a good working diagram, in which the mixture of air and hydrocarbon gas is correct and where combustion is practically complete. The ignition line in this diagram is nearly perpendicular to the atmospheric line, but inclines slightly toward the right hand at top. The diagram also shows the opening of the exhaust-valve at the proper time—namely, at 85 per cent. of the stroke. The compression line represents the proper pressure, and the air-inlet and exhaust lines indicate correct proportioned valves and inlet and outlet passages.

In considering and analyzing diagrams the following hints will perhaps be of service. If the suction line of the diagram is shown below the atmospheric




FIG. 39.




FIG. 40.

line, as in Fig. 40, then the air-inlet to the cylinder is known to be in some way choked. Where the air-valve is automatic this defect may be caused by the valve-

spring being too strong and it accordingly requires weakening; or the area of the air suction-pipe, if this is used, may be too small or this connection may have too many elbows or bends in it, and should be either of increased diameter or the bends should be eliminated. Again, the valve itself may have too small an area, or if actuated have insufficient lift (the proper lift of a valve is $\frac{1}{4}$ of its diameter), or the period of opening of the valve may not be correct, and the setting of the cams should be carefully examined, and, if necessary, altered in accordance with the diagram of valve opening, as shown at Fig. 32.

If the compression line *B* shows insufficient pressure of compression, this indicates leakage, which is probably due either to leaky piston or valves. If this leakage is past the piston-rings, the escaping air may be heard and the lubricating oil will be seen at each explosion period to be splashing and blown past the rings of the piston. If no signs of piston leakage are noticed, then examine oil-inlet air and exhaust valves and valve-seats very carefully; also note the various joints in the valve-box and otherwise where leakage might possibly occur. In engines without water-jackets around the valve-box the heat of the exhaust gases continually passing through the valve-chamber may sometimes cause the valve-seats to expand unequally when heated, and consequent leakage will occur when working.

If leakage is detected at the valves they must be re-ground, and also any hard places on the valve-stems or guides where they become heated should be eased so that the valves will work easily and efficiently when the

seats and guides are expanded, and, perhaps, slightly distorted, by the heat of working. (It is understood that these remarks refer to new engines solely.) With some engines means of increasing the compression by movable plates on the connecting-rod crank-pin end or other somewhat similar means are provided which can be changed, if necessary, thus decreasing the




FIG. 41.

amount of clearance in the cylinder. If the piston-rings are without leakage and they have worked into their proper bearings in the cylinder, and if all the valves are in perfect order and without leakage, and still the compression pressure, as shown on the diagram and as already explained, requires increasing, then the clearance in the cylinder can be slightly decreased where it is possible to do so. The vertical ignition line shows the timing of the ignition, and also the initial pressure of explosion. If this line is as represented in Fig. 41 the ignition is known to be too early, and should be arranged to occur somewhat later. The

diagrams as shown in Fig. 42 has the ignition line too late.

The timing of the ignition is regulated as follows:
With electric ignition by altering the period of




FIG. 42.

sparkling. Thus, if later ignition is required the igniting device must not be allowed to spark till the crank-pin has travelled nearer to the dead centre. With the hot-tube ignition and no timing valve, the length of the

tube can be changed. For example, to retard the ignition the tube should be lengthened slightly and its temperature somewhat decreased. In engines where neither of these means of ignition is used, but where the ignition is caused by the heat of the vaporizer-chamber or somewhat similar device, the timing of the ignition is controlled by the heat of the vaporizer-chamber and also by the heat generated by the process of compression. Where the ignition in this case is to be retarded, the compression should be reduced slightly and the vaporizer or other igniting device maintained at a less heat. The ignition, however actually caused, is always influenced by the heat of the cylinder walls and the temperature of the incoming air, which correspondingly increases or decreases the heat caused by the compression before explosion takes place. The ignition is usually adjusted when testing engines with the cooling water issuing from the cylinder water-jackets at a temperature of 110° to 130° Fahr.

The expansion line is marked C, as shown in Fig. 38. This line indicates the initial pressure of combustion, and it also shows the developed pressure decreasing as the volume of the cylinder becomes greater with the piston moving forward. The effective pressure developed is measured from this line to the compression line, and varies according to the richness of the explosive mixture. When the engine is in actual use the governor controls this pressure automatically.

The mean effective pressure is greater in some types of engines than it is in others, and varies, as stated in Chapter II., from 40 to 75 lbs. The amount of the



pressure in the cylinder is dependent upon the method of vaporization, upon the proper mixture of the gas




FIG. 43.

and air before explosion, and also upon the pressure of the compression. As in gas engines, the tendency in oil-engine practice is toward higher compression to

increase their efficiency. Where the mean effective pressure is low the relative power of the engine will, of course, also be reduced. The greatest mean effective pressure should be attained when the oil is thoroughly vaporized, is properly mixed with the air and when the compression is as high as practicable without pre-ignition taking place.

Should the exhaust lines *D* appear as in Fig. 43, then it is understood that the discharge of the exhaust gases is in some way choked; this may be caused by the exhaust-valve itself being too small, or to the periods of the opening of the valve being incorrect. (See diagram, Fig. 32.) Again, this defect may be caused by too many sharp bends, too small diameter exhaust-pipe, or possibly too long an exhaust-pipe. Theoretically no back pressure should be allowed during the exhaust period, but usually in practice a slight pressure of about one pound is recorded.

Each pound per square inch of back pressure shown by the exhaust line shows a back pressure in the cylinder, which is negative work to be overcome by the piston, and represents a slight loss of power by the engine.

Care must be taken that the indicator is in proper condition, without any play in the pencil arm, and that the piston is free and well lubricated. Lost motion in the indicator may show peculiarities in the diagram which to an inexperienced manipulator may be the cause of trouble.

TACHOMETERS (Fig. 44).—These instruments have been designed for the purpose of ascertaining at a

glance the number of revolutions made in a given time by rotating shafts. Their construction is based on centrifugal power, and they consist of a case inside of which are mounted a pendulum ring, in connection with a fixed shaft, a sliding rod and an indicating




FIG. 44.

movement. The apparatus is very sensitive, and will indicate the slightest deviation in speed.

PORTABLE TACHOMETER (Fig. 44a).—This instrument is similar in construction to the tachometer for permanent attachment. By applying it by hand to the centre of rotating shafts, it will instantly and correctly indicate the number of revolutions of the shaft per minute.

Fig. 44b illustrates a new form of speed counter, the

invention of Mr. A. J. Hill, of Detroit, Mich., which, besides counting, also registers the number of revolu-






FIG. 44a.

tions of the shaft. This is accomplished by simply punching a continuous slip of paper, as shown in



44b.

Fig. 44c. The watch mechanism in the device also periodically records a detent in the paper slip, thus



44c.

marking the periods of time while the shaft actuates the mechanism of the device, causing a detent for each

revolution. The writer has not yet had an opportunity of testing this interesting and useful invention.

When the full brake H. P. is obtained, which should be developed for at least a period of one hour continuously, the consumption fuel test is made.

THE MECHANICAL EFFICIENCY of oil engines, as shown by records of various tests, should be from 80 per cent. to 88 per cent., although the efficiency is much less than this when the engine has been working only a short time and before the crank-shaft and other bearings and piston are worn in. To ascertain the mechanical efficiency of an engine, first calculate the I. H. P., as already described; then figure the B. H. P., as already shown. Then:

$$\text{Mechanical efficiency} = \frac{\text{B. H. P.}}{\text{I. H. P.}}$$

For instance: If the B. H. P. of an engine = 10 and the I. H. P. = 12.5,

$$\begin{aligned} \text{Mechanical efficiency} &= \frac{10}{12.5} \\ &= 80 \text{ per cent.} \end{aligned}$$

THERMAL EFFICIENCY.—The ratio of the heat utilized by the engine, as shown by the power (B. H. P.) developed, as compared with the total heat contained in the fuel absorbed by the engine, is known as the thermal efficiency. This can be obtained by the following formula:

$$\frac{42.63 \times 60}{C \times X}$$

C = consumption of fuel in pounds per B. H. P. per hour.

X = calorific value of the fuel per pound in heat units.

The thermal efficiency of the oil engine is low as compared with the gas engine. The best gas-engine makers now claim a thermal efficiency for their engines of 27 per cent., whereas it is believed the maximum thermal efficiency recorded by any oil engine now in regular use is 18 per cent.

The following heat table shows the disposition of heat in oil engines as given by Dugeld Clerk:

Heat shown on diagrams per I. H. P...	15.3 per cent.
Heat rejected in water-jackets.....	26.8 per cent.
Heat rejected in exhaust and other losses.....	57.9 per cent.
	—————
	100 per cent.

It may be remarked, however, that this efficiency, though seemingly low, compares well with that of the steam engine, of which the average recorded results show about 11 per cent. thermal efficiency.

FUEL CONSUMPTION TEST.—This is generally made with all new engines before they leave the factory, and is advantageous as a check of the efficiency of the engine as shown by the indicator and the brake tests, and this test is also useful to ascertain the exact consumption of fuel by the engine in actual operation.

The oil is weighed, the amount being gauged by weight of fuel rather than by measuring the oil. The tank or other receptacle from which the fuel is drawn is first filled with kerosene. The tank is then placed on platform scales, and the weight is carefully taken and time noted when the engine is ready to begin this test. The full load required is then adjusted on the brake while the engine is running at its normal speed.

The oil can also be measured by means of a pointer placed in the tank, the tank being filled until the pointer is just visible before the engine is ready for the test to commence. The oil is then weighed in a separate vessel, and a quantity of the fuel is poured into the test tank. When the test is completed, the oil is taken out of the tank until the pointer shows again just as it did at the commencement of the test. The weight of the kerosene remaining in the vessel is deducted from the whole weight as at first recorded, and the difference is the amount consumed by the engine. It is usual to continue this test for at least one hour's duration. During the consumption test, the load on the brake and the number of revolutions per minute are recorded and the average brake horse-power developed is taken. The exact amount of oil consumed per hour being also known, the consumption of oil per H. P. hour is simply ascertained.

Light spring indicator diagrams are taken to ascertain the efficiency of the air and exhaust valves, ports and passages. That shown at Fig. 45 is taken with $\frac{1}{20}$ spring. The indicator must be fitted with special stop arrangement to prevent the pencil going above

the drum of the indicator when taking light spring cards.

It is advantageous to have some method of limiting the supply of oil to the vaporizer arranged so as to prevent the engine from consuming an excess of oil at any time. This gauge should be made immediately after the consumption test has been proved as satisfactory, and to avoid possible mistake by alteration of the oil supply. As already described, if too much oil enters




FIG. 45.

the vaporizer, bad combustion will follow and carbonization will, perhaps, result, thus rendering the piston sticky and gummy, and materially reducing the efficiency of the engine.

The exact periods for the movements of the valve and cams should also be clearly marked on the gearing or elsewhere, so that if at any future time the crankshaft is taken out or the gearing (or other mechanism) between the crankshaft and the camshaft removed,

the relative position of the crank-shaft with the valve mechanism can be readily ascertained and the exact position of the cams again found without difficulty.

EXHAUST GASES.—With an oil engine it is important to note the color of the exhaust gases, which may vary a little according to the weather. Where complete combustion is taking place, the exhaust gases are almost, if not entirely, invisible. When the engine is first started, these gases will, perhaps, be white, gradually getting bluer.

If an oil engine is working well and if the combustion is complete, the exhaust gases will not be seen but only heard, and the piston will also remain clean in working.

TESTING THE FLASH POINT OF KEROSENE.—Fig. 46a shows apparatus for ascertaining the “open fire” test or the temperature at which kerosene will flash or explode. This device consists of a small copper vessel in which the kerosene is placed. This vessel is immersed in a larger vessel containing water, which forms part of the upper part of the apparatus.

A thermometer is suspended with its lower part in the oil. A heating lamp placed under the receptacle containing the water raises the temperature of both water and oil as required. A lighted taper is passed to and fro over the top of the oil as it becomes heated. When the vapor given off by the oil flashes the temperature is noted, and that is termed the “flashing point” of the oil thus tested.

The “Abel” oil-tester is shown at Fig. 46b. This

was originated by Sir Frederick Abel, and hence its name. The tests made with this apparatus are those known as the "Abel closed" test. Such tests are recognized by the law (at the present time) of Great Britain.




FIG. 46.

The device consists of a copper vessel containing water in which is an air-chamber. In the air-chamber is placed an oil-cup made of gun-metal. This oil-cup is supplied with tight-fitting lid, and is provided with gas

or oil lamp suitably arranged to ignite the oil vapor when required.

Two thermometers are required, one immersed in the oil and the other in the water, each having a tight joint around it.

The following are the instructions for performing this test: The heating vessel or water-bath is filled until the water flows out at the spout of the vessel. The temperature of the water at the commencement of the test is 130° Fahrenheit. The water having been raised to the proper temperature, the oil to be tested is poured into the petroleum cup, until the level of the liquid just reaches the point of the gauge which is fixed in the cup. If necessary, the samples to be tested should be cooled down to about 60° . The lid of the cup with the slide closed is then put on, and the oil-cup is placed in the water-bath or heating vessel, the thermometer in the lid of the cup being adjusted so as to have its bulb immersed in the liquid. The test-lamp is then placed in position upon the lid of the cup, the lead line, or pendulum, which has been fixed in a convenient position in front of the operator, is set in motion, and the rise of the thermometer in the petroleum cup is watched. When the temperature has reached about 66° the operation of testing is to be commenced, the test flame being applied at once for every rise of 1° in the following manner:

The slide is slowly drawn open while the pendulum performs three oscillations, and is closed during the fourth oscillation. Thus a flame is made to come in contact with the vapor above the oil. The temperature

at which the vapor flashes is noted, and is called the flashing point of the oil. If it is desired to employ the test apparatus to determine the flashing points of oils of very low volatility, the mode of proceeding is modified as follows:

The air-chamber which surrounds the cup is filled with cold water, to a depth of $1\frac{1}{2}$ inches, and the heating vessel or water-bath is filled with cold water. The lamp is then placed under the apparatus and kept there during the entire operation. If a very heavy oil is being dealt with, the operation commences with water previously heated to 120° instead of with cold water.

VISCOSITY OF OIL.—It is frequently advantageous to ascertain the viscosity of different oils. The device shown at Fig. 46c is manufactured by C. I. Tagliabue especially for this purpose. The viscosity of an oil with this apparatus is found by noticing the number of seconds required for fifty cubic centimetres of oil to pass the open faucet or valve.

To test the viscosity of oil at 212° Fahr. with this apparatus, first pour water into the boiler through opening *A*, unscrew safety-valve until water-gauge shows that the boiler is full, open stop-cock *B*, making a direct connection between the boiler and upper vessel which surrounds the receptacle in which the oil to be tested is placed. Suspend a thermometer so that its bulb will be about $\frac{1}{4}$ inch from the bottom of the oil-bath. After carefully straining 70 cubic centimetres of the oil to be tested, which must be warmed in the case of very heavy oils, pour same into the oil-bath. Close

stop-cocks *D* and *E*. Screw the extension *F* with rubber hose attached into the coupling *G*, and let the open end of the hose be immersed in a vessel of water,




FIG. 46c.

which will prevent too large a loss of steam. Place lamp or Bunsen burner under boiler; screw steel nipple marked 212° on to stop-cock *H*; the apparatus is then ready to use. After steam is generated, wait until the

thermometer in oil-bath shows a temperature of from 209° to 211° ; then place the 50 cubic centimetre glass under stop-cock *H*, so that the stream of oil strikes the side of test-glass, thereby preventing the forming of air-bubbles; and when the thermometer indicates its highest point open the faucet *H* simultaneously with the starting of the timing watch. When the running oil reaches the 50 cubic centimetre mark in the neck of the test-glass the watch is instantly stopped and the number of seconds noted.

To ascertain the viscosity, multiply the number of seconds by two, and the result will be the viscosity of the oil. For example: If 50 cubic centimetres of oil runs through in $101\frac{1}{2}$ seconds, the viscosity will then be 203.

To test the viscosity of oils at 70° Fahr. screw the steel nipple marked 70 on to faucet *H*; close stop-cock *B*, closing communication between boiler and upper vessel; also close stop-cock *E*. Fill upper vessel through opening *G* with water at a temperature as near 70° as possible, also having the oil to be tested at the same temperature; hang the thermometer in position, and after stirring the oil thoroughly, blow through rubber tube at *D* to thoroughly mix the water; should the thermometer show higher or lower than 70° add cold or warm water until the desired temperature is attained. Then proceed as before stated.

[For tables of tests of various oil engines made at Edinburgh, see end of book.]

CHAPTER IV.

COOLING WATER-TANKS, AND OTHER DETAILS.

WATER is always required to keep the cylinders of explosive engines cool, and is necessitated by the great heat evolved in such engines, which heat would, if it were not carried away, prevent the proper working of an engine by too great expansion of the piston and by burning the lubricating oil. Where running water from city main is not available, water-tanks are used. The engine water-jackets are connected to the tanks as shown in Fig. 47. It is important that the water piping rises all the way from the engine to the tanks. The water, when tanks are used, circulates by gravitation—that is, the cold water being slightly heavier than the hot sinks to the bottom of the tank, passes from the tank to the water-jacket, and returns as warm water to the top of the tank to be cooled off and again sink to the bottom of the tank.

The cooling water-tanks must be of not less capacity than 70 gallons of water per brake H. P. of engine. The tanks when installed should preferably be placed in the best location for cold air to circulate around

them, so that the water in the tanks may cool off as quickly as possible.

Where an engine is required to work for more than ten hours per day, the tanks should be of larger capacity than that above stated, or provision should be made




FIG. 47.

to add cold water to the tanks when the water becomes heated above 120° Fahrenheit.

The waste-water drain-pipe from the tanks should be arranged to allow the hot water to run off from the top of the tanks and the cold-water inlet-pipe arranged to enter near the bottom. The circulating-water pipes connecting the tanks to engine water-jacket should be large enough to allow the water to circulate freely. A pipe having $1\frac{1}{2}$ " inside diameter is considered suit-




FIG. 48.

able for the smaller size of engines and 3" diameter pipe is sufficient for engines of 25 B. H. P. and over.

In some installations cooling water is available, but may require pumping to the engine. In such cases a pump capable of delivering more than ten gallons per brake H. P. of engine should be used. This pump can be actuated from the cam-shaft of engine as shown in Fig. 48, or from the crank-shaft by eccentric in the usual way. A rotary pump is sometimes used to accelerate the circulation of water in hot climates with the tank system of cooling water, and can be driven by belting from the crank-shaft of the engine. A by-pass in the water-pipes between the suction-pipe and the discharge-pipe of the water-circulating pump is advantageous, having a regulating valve in the by-pass. If this by-pass is not made, other means should be arranged, so that the supply of cooling water can be regulated to maintain the proper temperature of the cylinder of the engine—namely, 110° to 130° Fahrenheit. This temperature is recommended by the makers of several oil engines.

Where neither pump to lift and circulate cooling water nor water-tanks are necessary and where water is used from the city water-mains, $\frac{3}{4}$ " inside diameter pipe is sufficient for small and moderate-sized engines. The larger size may have 1" diameter pipe connections to cylinder.

In all cases, either with tanks, water-pumps, or where the water is connected direct from the city water-main, provision must be made for emptying the cylinder water-jacket and all the water-pipes in time of

frost. If the water in the water-jacket of the cylinder should be allowed to freeze, the cylinder casting may be cracked, and this may necessitate very expensive repairs.

Salt water can be used for cooling the cylinder. It should, however, be pumped through rapidly, so as not to allow the formation of any deposit inside water-jackets. In southern climates or where the temperature of the water is above 70° Fahrenheit, more water is required than above stated to keep the cylinder (when working at full load) below 130° .

The writer has tested such installations requiring 30 gallons per B. H. P. per hour, the normal temperature of the inlet cooling water in this case being 85° to 90° Fahrenheit.

EXHAUST SILENCERS.—The noise from the exhaust gases is sometimes considered to be a great objection to the use of explosive engines, but this is chiefly due to the fact that the ordinary cast-iron exhaust silencing chamber supplied with engine is not designed to entirely silence the exhaust, but is only regarded as sufficient to partly reduce this noise.

Where it is essential that the exhaust be entirely silenced, this can be easily accomplished in the following way: A brick pit should be built as shown in Fig. 49. The exhaust-pipe from the engine is then connected to the bottom of this pit. The outlet-pipe to the atmosphere is connected to the top of the pit. The space inside the pit should be filled with large stones, as shown in illustration. These stones should be about six inches in size, so that crevices are left

between them through which the gases can penetrate. A drain-pipe should be arranged to allow the water to flow out of the pit. The stone or cast-iron plate covering the pit is securely fastened down to the masonry.

With oil-engine exhaust gases there may be some




FIG. 49.

odor. When it is necessary that both the noise and the odor should be done away with, an exhaust washer should be installed instead of the silencing pit, as already described. This apparatus consists of a tank, to which the water is connected as it issues from the water-jacket of the engine-cylinder, or where cooling




FIG. 50.

tanks are used the water should be taken from the main. About 100 gallons of water are required per hour. The exhaust-pipe from the engine valve-box is also connected directly to this tank. The outlet of the water is connected from the tank to sewer and the outlet exhaust-pipe is also connected in the usual way to the top of the building.

The exhaust gases by this arrangement come in contact with the water and are partly condensed and quite purified. The pressure and noise are eliminated entirely, any deposit of carbon left in the gases after combustion is carried off by the water to the sewer, and there is practically no odor when the gases escape from the exhaust-pipe to the atmosphere at the roof. This device is shown in Fig. 50. The sizes given for piping and tank are those suitable for a 10 to 20 H. P. oil engine. The internal piping in the tank is so placed to avoid any pressure which is created inside the tank due to the exhaust gases of the engine from entering the sewer. If any water is blown out at the top of the exhaust-pipe, a steam exhaust-head is used for obviating this. This apparatus is the same as used on steam exhaust-pipes.

Sizes for piping and tank for a 10 to 20 H. P. oil engine:

Pipe from engine, 3" diameter.

Pipe of water inlet, $\frac{3}{4}$ " diameter.

Pipe to atmosphere, 3" diameter.

Pipe to water outlet, 2" diameter.

Size of tank, 2' in diameter by 4' high.

When it is required to partly silence the noise of exhaust only part or all of the water from the cooling jacket can be turned into the exhaust-pipe directly from the water-jacket. The water is allowed to run to waste again at the silencer. (See Fig. 51.) Wherever water is connected to the exhaust-pipe, care must be taken that none can under any condition enter through




FIG. 51.

the exhaust valve-box into the cylinder or vaporizer of the engine. Where water enters the silencer or the piping under pressure from the city main or otherwise, it is necessary that the area of the outlet-pipe be large enough to allow the water to drain freely at atmospheric pressure. If the water is not allowed free drainage, it may quickly fill up the silencer, and perhaps enter the valve-box of the engine, causing the engine to stop working.

SELF-STARTERS.—Engines of 25 H. P. and over should be provided with separate means of starting besides the relief-cam for reducing the pressure of compression as usually provided with the smaller sizes of engines. The weight of the fly-wheels and reciprocating parts on the larger engines which are to be put in motion when being started necessarily entails considerable exertion, and the strength of two men is required to do this work where no other means is provided for this purpose.

There are several different self-starting devices made for gas engines, and it is much easier to accomplish this work with a gas than with an oil engine, since with the former gas only has to be dealt with and can be readily diluted with air and an explosive mixture formed, whereas with the oil engine the fuel must be vaporized first and then mixed with the air before an explosive mixture is available to be ignited and the impulse on the piston obtained. In order, therefore, to accomplish these various operations necessary in the oil engine, sufficient power must be independently provided to turn the engine crank-shaft over two or three revolutions so that the different mechanisms can work, the fuel be injected or inducted into the cylinder or vaporizer, become mixed with the incoming air and an explosion obtained, thus giving the required impulse. This power is usually derived from a separate air reservoir charged during the previous running of the engine or from a small air-compressor operated by hand.

The self-starter used with the Hornsby-Akroyd type

of oil engine is shown in Fig. 52. The reservoir is connected to air and exhaust valve-box of engine through a supplementary valve-box containing two check-valves. These check-valves are arranged to be lifted from their seats by means of the hand-lever as shown.

The following are the instructions in detail for starting these engines by means of this device. (These re-




FIG. 52.

marks are generally applicable to all types of engines provided with starting devices of this principle.)

See that the valve *A* on the steel receiver is open, and also the cock *B* on the pipe leading from the hand air-pump. Put the starting lever in the quadrant at the position marked "Running and when charged," and pin it there. Then screw down the valve *C* on the double valve-box, and pump air into the receiver by the

air-pump up to a pressure of say 60 or 70 lbs. to the square inch as shown on the gauge. Then close the cock *B* on the air-pump pipe, withdraw the pin in the starting lever, and put it in the hole by the side of the lever to act as a stop; then place the engine ready for starting as elsewhere described. Place the crank a little over the dead centre in whichever direction the engine is intended to run, unscrew the valve *C* in double valve-box, and then suddenly push the starting lever forward to the end of the quadrant, and the engine will start. Pull the lever back immediately against the pin, and screw down the valves on the double valve-box and on the receiver. Before stopping the engine at any time, pull the lever back and pin it in hole marked "To charge;" unscrew the valves on the double valve-box and receiver, and allow the engine to pump air into the receiver again to 80 or 100 lbs. pressure; put the lever to the centre hole marked "When running, and when charged," and pin it there; screw down the valves on the receiver and valve-box, and the air pressure in the receiver will be retained in readiness to start the engine the next time it is required. If an air-pump is not provided, the engine must be started in the usual way the first time, by pulling round the fly-wheel, and the receiver afterward filled each time before stopping.

UTILIZATION OF WASTE HEAT.—It is frequently advantageous to utilize the heat of exhaust gases and also the heat taken up by the cooling water as it issues from the cylinder water-jacket to heat the rooms of a building or workshop. Sixty per cent. at least of the total

heat evolved from the fuel used in the engine is lost in the exhaust gases and to the cooling water around the cylinder-jacket. This represents a great waste, which can be partly saved in any installations where heat is required for outside purposes.

In instances where this heat can be utilized, the water-pipes should be connected to the cylinder water-jacket outlet and inlet, and arranged to be carried to




FIG. 53.

supply heat to the building, as shown in Fig. 53. The hot water issues from the cylinder at not less than 110° Fahrenheit temperature, and will heat the piping as shown. With a 10 to 20 brake H. P. oil engine, 200 feet of 2-inch piping can be suitably warmed.

The heat from the exhaust gases can be similarly utilized, the exhaust-pipe being connected and carried along inside the building. In this case the standard size of piping should be slightly increased to avoid choking of exhaust gases, and care should be taken that the piping is not placed within 12 inches of timber.




FIG. 54.

The heat in the exhaust gases can also be extracted by the exhaust-pipes being passed through the device, as shown in Fig. 54. Here the water is heated to nearly boiling-point, and will maintain a considerable length of piping at the required heat. With an engine of 15 brake H. P. 200 feet of piping can thus be heated. The heat obtained in these instances is assumed with the engine working at full load or nearly so.

Fig. 54. This apparatus consists of an ordinary feed-water heater, with a number of "U"-shaped internal tubes, through which the exhaust gases pass. The cold water flows in at the lower connection and circulates around the heated tubes, flowing out at the connection on the top of the apparatus, and passes in the piping around the building to be heated in the usual way, and returns by gravitation again to the lower connection.

EXHAUST TEMPERATURE.—The temperature of the exhaust gases is difficult to ascertain correctly. The temperature of the exhaust from the Diesel engine is recorded by Professor Denton as being approximately 740° Fahr. The temperature of different oil-engine exhaust gases varies, and it is probably considerably above that figure. This temperature varies also, of course, according to the size of the engine, and also according to the power that the engine is developing. The heat is greatest at full load and on the largest engines.

CHAPTER V:

OIL ENGINES DRIVING DYNAMOS.

OIL ENGINES for many reasons are well adapted for driving dynamos generating electric current in isolated lighting plants. A large number of such installations have been made in recent years. The oil engine is self-contained, and, unlike a gas engine, is independent of gas works or gas-producer plant for its supply of fuel. Small power installations with oil engines as prime movers should require also less attention than a plant equipped with steam engine and boilers. There is probably not the danger there is with a steam engine of explosion, and as the fuel used is ordinary kerosene of a safe flashing point, there can be little or no fear of destruction by fire. Practically, no hauling of fuel is required, nor is there, with an oil engine, any consumption of water if storage tanks are installed. Further, an oil engine does not deteriorate if only required for part of the year and left standing idle for the remainder of the time. With these and, perhaps, other advantages possessed by oil engines, their adaptability for driving dynamos in isolated electric-lighting and power plants may be understood. Fig. 55 illustrates an oil




FIG. 55.

engine driving dynamo with link belt. The dynamo is placed close to the engine to economize floor space.

This plant is arranged with the cams having been set for the engine to run backwards.

INSTALLATION.—In order that the plant may be entirely satisfactory and give the best results, it is very essential that the engine and dynamo be correctly located with regard to each other and properly installed at the outset.

THE FOUNDATIONS both for the engine and for the dynamo should be built of good cement concrete, and should be placed on solid ground, so that they are steady and without vibration. The engine foundation can be made as shown at Fig. 56. When, however, the ground that the foundation is built upon is not solid, it is preferred to build the foundation more tapered than shown toward the bottom, thus increasing the surface that the concrete rests on. The weight of the foundation is considered sufficient allowing about 5 cubic feet per I. H. P. for engines under 50 H. P. for concrete. For engines over 50 I. H. P. the foundation can be reduced per I. H. P. If the foundation is built of brickwork, its dimensions should be somewhat greater than those given for concrete. The ingredients of the best concrete are broken stone, Portland cement and sharp sand. The following proportions form a good mixture:

Portland cement.....	1
Sand	3
Broken stone.....	4




FIG. 56.

When driving by belt the distance between the centres of the dynamo and the engine-shafts is an important feature. Where space is restricted and it becomes essential that the dynamo be placed as close as possible to the engine, it is advantageous to use a link leather belt, allowed to run quite loose, the part of the belt in tension being underneath, the loose part being on top, so that the arc of contact made on the smaller pulley of the dynamo is as great as possible. This arrangement with loose belt lessens the friction on the bearings, which would be occasioned if the belt were made tight, as required at short centres with ordinary leather belt. When using link leather belt, the distance between the centres should be with the usual standard size of fly-wheels 2 to 2.5 diameters of the engine fly-wheels—that is, the distance should not be less than 7 ft. for wheels of 3' 6" diameter and not greater than 15 ft. for wheels of 6 ft. diameter. Where ordinary leather belt is used instead of link belt, this distance should be increased to 3 diameters of fly-wheel, but in any case this dimension should not exceed 18 ft. for driving wheels 6 ft. in diameter. To obtain absolutely steady light, it is sometimes advantageous to place a balance-wheel on the armature shaft of the dynamo. This wheel if used should weigh about 15 lbs. per K. W. of dynamo, and be of such diameter that at the maximum speed of dynamo its peripheral speed will not exceed 6000 ft. per minute. This wheel must be accurately balanced, and is usually cast in one piece with pulley, as shown in Fig. 57. The

necessary width of belt to transmit the H. P. may be calculated as follows:

$$\text{H. P.} = \frac{V \times w}{800}.$$

H. P. = the actual horse-power.

V = velocity of belt in feet per minute.

w = width of belt in inches.




FIG. 57.

The maximum number of incandescent lights available from the dynamo per brake or actual H. P. of engine varies according to the efficiency of the dynamo, and the efficiency of the means of transmission as well as to the efficiency of the electrical installation. Lack of

power as recorded by the electrical instruments is not necessarily due only to defects of the engine, as leakage of power may occur in various ways, as above stated. Usually ten 16 candle-power lights per Brake H. P. are calculated as being a fair load for the engine. With arc lamps of 2000 candle-power, the B. H. P. of engine for each lamp required is approximately .75. It is advisable to have spare power with an explosive engine above that required to run all the lights. Losses of power should be allowed for in the belt, which vary from 10 to 15 per cent.

The regulation of explosive engines for electric lighting must necessarily be such that there is no flicker in the incandescent lights. A speed variation of 2 per cent. is now guaranteed with several oil engines. This regulation gives a very good light and equals that developed with many steam engines.

When space is not available to permit the use of belt transmission, the dynamo is connected directly on to the shaft of the engine, as in Figs. 58 and 58a. The coupling between engine-shaft and dynamo is usually flexible to allow of dynamo bearings and the engine-shaft bearings remaining in alignment when they become worn. In direct-connected plants the loss due to the belt transmission is avoided, and a saving is thus effected; but, on the other hand, the first cost of the dynamo is very much greater, running, as it does, at a slower speed than the belt-driven machine, and therefore is of larger dimensions, and consequently more costly.

Fig. 58 illustrates a Hornsby-Akroyd engine of the




Fig. 58.

two-cylinder vertical type, coupled direct to the shaft of the dynamo, all placed on one bed-plate.

The cranks of the engine are placed in line, and accordingly an impulse at each revolution of the crank-shaft is obtained. The method of working and the details of the vertical type of these engines are very similar to those of the horizontal type elsewhere described. This outfit has given very satisfactory results with incandescent lamp service, the variation in speed being less than 2 per cent. with varying loads, and a large number of these outfits are in use.

Fig. 58*a* illustrates the Mietz & Weiss horizontal type of engine directly connected to dynamo through flexible coupling. This engine, being of the two-cycle type, receives an impulse at each revolution of the crank-shaft, and it runs very regularly and at a high rotative speed—namely, 400 revolutions per minute. The method of working of the Mietz & Weiss engine is fully described in Chapter IX.

The fly-wheels of explosive engines intended for driving dynamos are usually made heavier than when the engines are required for other purposes. (See Chapter II.)

Notwithstanding the special design of engines for electric-lighting purposes and apparent correct adjustment of the governing mechanism, the lights may sometimes be seen to flicker. Flickering in the incandescent lights can be easily located by close inspection of the engine and dynamo, and may be due either to the fly-wheels, the governor, the belt, or the dynamo itself. To precisely locate this defect and remedy it,




FIG. 58a.

notice the lamps carefully. If the variations in the light are due to want of fly-wheel momentum, such variations will be seen to coincide with the number of revolutions of the engine. Again, if the variation in the lights is only periodical, then this defect should be remedied by adjustment of the governor. Examine carefully the governing mechanism of the engine. If the variation is caused by the governor acting too slowly, then adjust so as to cause more rapid contact with the valve or other controlling mechanism.

The cause of the trouble may not be, as already suggested, in the fly-wheel momentum or in the adjustment of the governor, but in the belt, which is frequently the sole cause of unsatisfactory lighting. The engine and dynamo pulleys over which the belt runs must be exactly in line with each other. The belt should be endless, or if jointed such joints should be very carefully made. A thick, uneven joint in the belt will cause a flicker in the lights each time it passes over the dynamo pulley. The belt should be allowed to run as loose as possible. The writer has seen belts running quite slack and most satisfactorily when the pulleys have been covered with specially prepared pulley-covering material. In some instances in the dynamo itself may be found the cause of the variation in the voltage. If the commutator becomes unevenly worn, or if the brushes are not properly adjusted, unsteady lights will result, and then the commutator should be made of even surface and the brushes correctly adjusted.

Oil engines can be stopped if desired by pressing button in the dwelling-house, an attachment being

added to some engines which automatically turns the stopping handle. This is an advantage where the light is required late at night, and allows the attendant to leave the engine early, at the same time providing requisite illumination as long as required.

AIR SUCTION.—The noise created by the air being drawn into the cylinder has, in some cases, to be silenced. This can be accomplished by connecting the air-inlet pipe to wooden box containing space at least five times as great as the volume of the cylinder—the sides of the box having holes which are lined with rubber. The total area of all these small inlet air holes should be at least three times the area of the air-inlet pipe to the engine.

CHAPTER VI.

OIL ENGINES CONNECTED TO AIR-COMPRESSORS, PUMPS, ETC.

THE use of compressed air is now being extensively applied as a means of power transmission, and it is coming more and more into favor in this connection also for actuating pneumatic tools, and for other purposes too numerous to mention. Many advantages are claimed for the combination of explosive engines connected to air-compressors as a motive power.

Fig. 59 illustrates an oil engine direct-connected to a high-speed, single-acting air-compressor placed on the same base plate with the engine, the compressor being actuated from the crank-disc keyed directly on to the engine crank-shaft. This outfit consists of seven H. P. engine and $8\frac{1}{2}$ " diameter and $8\frac{1}{2}$ " stroke single-acting air-compressor running at 230 revolutions per minute, and delivering 65 cubic ft. of free air per minute at 30 lbs. pressure.

Fig. 60 shows an oil engine geared to air-compressor of the ordinary double-acting type. In this outfit the power necessary to actuate the compressor is transmitted by gearing from the engine crank-shaft to the compressor-shaft, which then revolves at a slower speed than the engine-shaft. This arrangement is con-




FIG. 50.

sidered advantageous, because of the slower motion of the air-compressor valves as compared with the direct-connected outfit. In each of the illustrations the air-compressor cylinder is water-jacketed, the circulating water being supplied by the small pump actuated from the engine cam-shaft, the water being first delivered to the compressor cylinder, and thence to the oil engine cylinder. This outfit consists of 13 B. H. P. oil engine and "Ingersoll-Sargent" double acting air-compressor having cylinder 8" diameter and 8" stroke, and running at 150 revolutions per minute, delivering 70 cubic ft. of free air per minute at 70 to 80 lbs. pressure.

To calculate the H. P. required to actuate an air-compressor, the diameter of compressor cylinder and length of stroke being given as well as the required gauge pressure, then the mean pressure in the cylinder must be ascertained from the table given on page 126 corresponding with gauge pressure required. The power necessary is then found by means of the following formulæ:

$$\text{H. P.} = \frac{P L A N}{33,000} .$$

P = mean effective pressure in pounds per square inch in cylinder as given in table.

L = length of stroke in feet.

A = area in cylinder in inches.

N = number of revolutions per minute with single-acting compressor if double-acting x 2.

TABLE II.—VARIOUS AIR PRESSURES.—RICHARDS'.

Gauge Pressure.	Absolute Pressure.	Pressure in Atmospheres.	Volume with Air at Constant Temperature.	Volume with Air Not Cooled.	Mean Pressure per Stroke, Air Constant Temperature.	Mean Pressure per Stroke, Air Not Cooled.	Mean Pressure during Compression only, Air Constant Temperature.	Mean Pressure during Compression only, Air Not Cooled.	Final Temperatures, Air Not Cooled.	Gauge Pressure.
0	14.7	1	1	1	0	0	0	0	60	0
1	15.7	1.068	.9363	.95	.96	.975	.43	.44	71	1
2	16.7	1.136	.8803	.91	1.87	1.91	.95	.96	80.4	2
3	17.7	1.204	.8305	.876	2.72	2.8	1.4	1.41	88.9	3
4	18.7	1.272	.7861	.84	3.53	3.67	1.84	1.86	98	4
5	19.7	1.34	.7462	.81	4.3	4.5	2.22	2.26	106	5
10	24.7	1.68	.5952	.69	7.62	8.27	4.14	4.26	145	10
15	29.7	2.02	.495	.606	10.33	11.51	5.77	5.99	178	15
20	34.7	2.36	.4237	.543	12.62	14.4	7.2	7.58	207	20
25	39.7	2.7	.3703	.494	14.59	17.01	8.49	9.05	234	25
30	44.7	3.04	.3289	.4638	16.34	19.4	9.66	10.39	255	30

OIL ENGINES CONNECTED TO AIR-COMPRESSORS. 127

35	49.7	3.381	.2957	.42	17.92	21.6	10.72	11.59	281	35
40	54.7	3.721	.2687	.393	19.32	23.66	11.7	12.8	302	40
45	59.7	4.061	.2462	.37	20.52	25.59	12.62	13.95	321	45
50	64.7	4.401	.2272	.35	21.79	27.39	13.48	15.05	339	50
55	69.7	4.741	.2109	.331	22.77	29.11	14.3	15.98	357	55
60	74.7	5.081	.1968	.3144	23.84	30.75	15.05	16.89	375	60
65	79.7	5.423	.1844	.301	24.77	31.69	15.76	17.88	389	65
70	84.7	5.762	.1735	.288	26.	33.73	16.43	18.74	405	70
75	89.7	6.102	.1639	.276	26.65	35.23	17.09	19.54	420	75
80	94.7	6.442	.1552	.267	27.33	36.6	17.7	20.5	432	80
85	99.7	6.782	.1474	.2566	28.05	37.94	18.3	21.22	447	85
90	104.7	7.122	.1404	.248	28.78	39.18	18.87	22.	459	90
95	109.7	7.462	.134	.24	29.53	40.4	19.4	22.77	472	95
100	114.7	7.802	.1281	.232	30.07	41.6	19.92	23.43	485	100
105	119.7	8.142	.1228	.2254	30.81	42.78	20.43	24.17	496	105
110	124.7	8.483	.1178	.2189	31.39	43.91	20.9	24.85	507	110
115	129.7	8.823	.1133	.2129	31.98	44.98	21.39	25.54	518	115
120	134.7	9.163	.1091	.2073	32.54	46.04	21.84	26.2	529	120
125	139.7	9.503	.1052	.202	33.07	47.06	22.26	26.81	540	125
130	144.7	9.843	.1015	.1969	33.57	48.1	22.69	27.42	550	130
135	149.7	10.183	.0981	.1922	34.05	49.1	23.08	28.05	560	135
140	154.7	10.523	.095	.1878	34.57	50.02	23.41	28.66	570	140
145	159.7	10.864	.0921	.1837	35.09	51.	23.97	29.26	580	145
150	164.7	11.204	.0892	.1796	35.48	51.89	24.28	29.82	589	150
160	174.7	11.88	.0841	.1722	36.29	53.65	24.97	30.91	607	160
170	184.7	12.56	.0796	.1657	37.2	55.39	25.71	32.03	624	170
180	194.7	13.24	.0755	.1595	37.96	57.01	26.36	33.04	640	180
190	204.7	13.92	.0718	.154	38.68	58.57	27.02	34.06	657	190
200	214.7	14.6	.0685	.149	39.42	60.14	27.71	35.02	672	200




FIG. 60.

For example, in the $8\frac{1}{2} \times 8\frac{1}{2}$ inch single-acting direct-connected plant (Fig. 59), the theoretical power required to actuate the compressor is as follows:

$$\text{H. P.} = \frac{19.4 \times .78 \times 56.7 \times 230}{33,000}$$

$$\text{H. P.} = 5.98.$$

As this represents only the power required to compress the air, additional power must also be provided sufficient to overcome the friction of the compressor. In this case it will be noted that approximately 15 per cent. is allowed.

TABLE III.—EFFICIENCIES OF AIR-COMPRESSORS AT DIFFERENT ALTITUDES.

Altitude, feet.	Barometric, Pressure.		Volumetric Efficiency of Compressor, Per Cent.	Loss of Capacity, Per Cent.	Decreased Power Required, Per Cent.
	Inches, Mercury.	Pounds Per Square Inch.			
0	30.00	14.75	100.	0.	0.
1000	28.88	14.20	97.	3.	1.8
2000	27.80	13.67	93.	7.	3.5
3000	26.76	13.16	90.	10.	5.2
4000	25.76	12.67	87.	13.	6.9
5000	24.79	12.20	84.	16.	8.5
6000	23.86	11.73	81.	19.	10.1
7000	22.97	11.30	78.	22.	11.6
8000	22.11	10.87	76.	24.	13.1
9000	21.29	10.46	73.	27.	14.6
10000	20.49	10.07	70.	30.	16.1
11000	19.72	9.70	68.	32.	17.6
12000	18.98	9.34	65.	35.	19.1
13000	18.27	8.98	63.	37.	20.6
14000	17.59	8.65	60.	40.	22.1
15000	16.93	8.32	58.	42.	23.5




FIG. 61.

The efficiency of an air compressor is reduced when working at high altitudes. Table III. gives such depreciation in efficiency at the different altitudes.

OIL-ENGINE PUMPING PLANTS.—Fig. 61 represents an oil-engine pumping plant as installed for supplying




FIG. 62.

town or village water-supply. This outfit consists of 13 H. P. oil engine connected by friction-clutch to the shaft of a triplex pump having cylinders $6\frac{1}{2}$ " diameter and 8" stroke.

The amount of water delivered by this outfit is approximately 165 gallons per minute, with total average lift of 195 ft. The cost of fuel for running is

about 13 cents per hour. Practically, no attention is required beyond starting the engine and occasional lubrication.

Fig. 62 shows a small outfit suitable for supplying water to a country-house, and consists of $1\frac{1}{2}$ H. P. engine and pump capable of delivering 1200 gallons of water with 150 ft. total lift.

To calculate the theoretical H. P. required to raise a




FIG. 63.

given amount of water, multiply the number of gallons to be delivered per minute by 8.3, which gives the weight; again, multiply by the total required lift in feet, and divide the result by 33,000, thus:

$$\text{H. P.} = \frac{\text{Number of gallons} \times 8.3 \times \text{height of lift}}{33,000}$$

Example: 165 gallons 195 feet lift

$$\frac{165 \times 8.3 \times 195}{33,000}$$

= 8 H. P. actually required to lift water.

The friction of the moving parts of the pump has to be overcome, and for this and other losses allowance is usually made by figuring the efficiency of the pump (in the smaller size) at 60 per cent. to 70 per cent.

OIL ENGINES DRIVING ICE AND REFRIGERATING MACHINES.

Oil engines are now being used in connection with small ice and refrigerating machines.

Fig. 63 represents a plant of this description, consisting of an oil engine belted direct to a refrigerating machine used in this instance for cooling a butcher's cold-storage box.

The refrigerating machines are rated according to the amount of ice they are assumed to displace. A one-ton machine is one which will effect the same cooling in twenty-four hours which a ton of ice would do in melting. The chief advantage of the refrigerating machine is that while the ice can only produce a temperature of 35° Fahr. and upward, the refrigerating machine can be operated to produce any temperature which may be desired.

In the process of refrigeration, the work which the

oil engine has to do is to drive a compressor, and therefore the same principles may be applied to this machine as to the ordinary air-compressor already discussed. We need only to know how much gas has to be compressed and the conditions upon which to base the calculation for the work done in the compressor. It is the practice of refrigerating-machine makers to allow about 4.5 cubic ft. displacement per ton of refrigeration—that is to say, a 10-ton machine is one having capacity of pumping 45 cubic ft. of gas per minute.

In the case of the ordinary compressor, we have only to consider the final pressure, since the initial pressure is always that of the atmosphere. In the case of the refrigerating machine, however, this is not the case, for the gas being circulated in a closed circuit may have not only a varying final pressure, but also a varying suction pressure. These pressures depend upon the temperatures obtaining in the cold room and in the condenser in a manner which it is not necessary to consider in detail. The initial pressure and the final pressure being known, the mean pressure may be calculated in the ordinary way.

To facilitate this calculation, table No. IV. may be consulted. The vertical left-hand column gives the initial pressure corresponding to the temperatures named in the second column, these being the temperatures *inside* the cooling pipes. The top horizontal line gives the pressure corresponding to the temperatures in the second horizontal line. These temperatures are those obtaining in the condenser.

TABLE IV. — MEAN PRESSURE OF DIAGRAM OF GAS (AMMONIA) COMPRESSOR.

Refrigerator Pressure and Temperature.		Condenser Pressure and Temperature.									
		103	115	127	139	153	168	184	200	218	
		65°	70°	75°	80°	85°	90°	95°	100°	105°	
4	— 20°	41.46	43.91	46.34	48.77	51.23	53.68	56.11	58.54	60.99	
6	— 15°	42.72	45.38	47.90	50.74	53.40	56.08	58.86	61.40	64.08	
9	— 10°	44.40	47.38	50.33	53.29	56.25	59.20	62.16	65.14	68.09	
13	— 5°	45.86	49.15	52.42	55.70	58.97	62.25	65.53	68.81	72.08	
16	0°	46.94	50.56	54.16	57.78	61.40	65.00	68.62	72.22	75.84	
20	5°	47.74	51.73	55.70	59.68	63.67	67.66	71.62	75.61	79.61	
24	10°	48.04	52.40	56.77	61.13	65.51	69.86	74.24	78.59	82.97	
28	15°	47.88	52.67	57.44	62.23	67.02	71.81	76.60	81.39	86.18	
33	20°	47.08	52.30	57.53	62.75	67.98	73.23	78.46	83.68	88.91	
39	25°	45.06	51.34	57.05	62.75	68.46	74.17	79.88	85.58	91.29	
45	30°	43.16	49.71	55.92	62.14	68.35	74.56	80.77	86.98	93.19	
51	35°	40.52	47.26	54.02	60.76	67.52	74.28	81.02	87.78	94.52	

The mean pressure corresponding to any two known conditions may therefore be taken from the table; for example, with a suction pressure of 28 and a condenser pressure of 153, the mean pressure is 67.02 pounds. The work required to produce a ton of refrigeration, therefore, would be

$$\text{H. P.} = \frac{P L A N}{33,000},$$

in which

$$P = 67.02 \text{ pounds.}$$

$$L = 4.5 \text{ feet.}$$

$$A = 144 \text{ square inches} = 1 \text{ sq. ft.}$$

$$N = 1.$$

Substituting these values, the horse-power is 1.32. No allowance is here made for friction, and in small refrigerating machines this should be extremely liberal.

Moreover, on reference to the table it will be seen that the machine may happen to be called upon to work under conditions where the mean pressure will be very much increased; such, for example, when the back pressure is 51 lbs. and the high pressure is 218 lbs. Under these circumstances the mean pressure will be 94.52 instead of 67.02. For these reasons it is not safe to provide for a refrigerating machine of small dimensions a power much less than about 3 H. P. per ton of refrigeration. Under ordinary conditions of running, less than this, and frequently only one-half of this will be required, but provision should be made for taking care of extreme conditions.

FRICTION-CLUTCHES.—Where engines of 10 H. P. or over are installed, it is a great advantage to have a friction-clutch pulley added. This can be attached either to the engine crank-shaft or to the intermediate or main shaft. Fast-and-loose pulleys are sometimes substituted for the friction-clutch.

With either friction-clutch or fast-and-loose pulleys the advantages gained are, first, the ease with which the engine can be started, the loose or friction-clutch pulley only instead of the whole shaft has to be turned when the plant is started, and, secondly, in case of accident or other emergency necessitating the quick cessation of the revolving machinery, this can be accomplished at once by simply moving over the handle of the friction-clutch and pulley. Otherwise without the clutch the heavy fly-wheels of the engine remain revolving for a minute or so after the fuel of the engine is turned off, and being directly connected by belt to the shafting and machinery, the whole plant is in motion while the momentum of the fly-wheels exists.

Friction-clutches are made of various designs by several manufacturers. That shown in Fig. 63a is especially adapted for explosive engines. It consists of a carrier which bolts to the regular bosses on the fly-wheel of the engine, this carrier acting as the journal of the pulley, and the mechanism of the clutch is enclosed in the same. The clutch has a side grip. The pulley, otherwise loose, is thrown into connection with the engine fly-wheel by simply pushing in a spindle on which a hand-wheel revolves loosely. Two rollers are mounted on the end of the spindle, and bearing on

these rollers are the levers which in turn are pivoted to the gripping plate and a lug on the levers abuts against the adjusting screw. The inward movement of the spindle forces these levers apart and draws the gripping plate in, thus gripping the pulley in a circular vise




FIG. 63a.

between the flange on the carrier and the gripping plate. To release the clutch the spindle is pulled out, and thereby the strain on the levers is removed, thus allowing the pulley to run loose. This clutch is known as the B and C Friction Clutch Pulley.

CHAPTER VII.

INSTRUCTIONS FOR RUNNING OIL ENGINES.

THE attendant, in order to obtain the best results from an engine, should first fully understand the principle by which the engine he is running works and the conditions which it is essential should exist in the cylinder to procure proper explosion and combustion. These conditions are practically the same in all types of oil engines. The explosive mixture consists of hydrocarbon gas and atmospheric air, the gas being formed from kerosene oil previously gasefied or vaporized and properly mixed with air by one or other of the different methods, as described in Chapter I. This mixture is then compressed by the inward stroke of the piston before ignition with the two-cycle type of engine. The mixture is afterward ignited by hot tube, electricity, heated surfaces, or otherwise, as also described in Chapter I., and the required impulse is then obtained at the piston. If for any reason these conditions are not existing, proper explosion and combustion will not follow. The several reasons which prevent proper explosions being obtained are very fully described in Chapter III. on "Testing."

The conditions necessary to insure proper working are as follows:

(a) Oil supply to the vaporizer or combustion chamber delivered at the correct time, and in such quantity as to form proper explosive mixture. Efficient supply of air.

(b) Sufficient pressure in the cylinder by compression before ignition.

(c) Correct ignition of the gases, the ignition taking place at the proper time.

CYLINDER LUBRICATING OIL.—It is essential that a suitable lubricating oil be used for the piston. The great heat evolved in the cylinders of explosive engines renders this essential.

The lubricating oil recommended for this purpose is a light mineral oil having a flash point of not less than 360° Fahr. and fire test 420° Fahr. Gravity test 25.8, and having a viscosity of 175 (Saybold test). If waste-oil filter is used, the oil filtered must not be employed for lubricating the piston at any time.

The following are instructions as formulated by the makers of the different engines, each of the four types of vaporizers being here represented, as well as the different kinds of igniting devices.

HORNSBY-AKROYD TYPE.

The method of working is explained in Chapter IX., giving general description of these engines. The oil-tank in the base of the engine should be filled

and the oil pumped up by hand until it passes the overflow pipe. The water-tanks if used must also be filled to the top and the cylinder water-jacket also be full of water before starting.

PREPARING TO START THE ENGINE.—On those engines in which the vaporizer is partially water-jacketed, the valve on the inlet water-pipe should be closed before commencing to heat the vaporizer for starting, and opened, or partially opened, when running.

TO HEAT THE VAPORIZER.—A coil lamp is used (see illustration, Fig. 64) for this purpose; the lamp reservoir should be nearly filled with oil. A little kerosene should then be poured into the cup containing asbestos wick under the coil and lighted. When this has nearly burnt out, pump up the reservoir with air by the air-pump, when oil vapor will issue from the small nipple, and on being lighted will give a clear flame. When it is required to stop the lamp, turn the little thumb-screw on the reservoir-filling nozzle and let the air out, and remove the lamp from the bracket. The nipple at any time can be cleaned with the small prickers which are supplied for this purpose. Should the U-tubes get choked up, the lower one can be gotten at by unscrewing the joint just below it, and the other one by screwing out the nipple from which the oil vapor issues. The heating of the vaporizer is one of the most important duties to be attended to, and care must be taken that it is made hot enough before starting. The attendant must see that the lamp is burning properly for five or ten minutes, or sometimes a little longer, according to the size of the engine. If, however, the

lamp is burning badly, it may take longer to get the proper heat. It is most important that the lamp should be carefully attended to.




FIG. 64.

TO START THE ENGINE.—Place the starting handle to position “Shut,” and work the pump-lever up and down until the oil is seen to pass the overflow-valve.

Then turn the handle to position "Open," work the pump-lever up and down again, one or two strokes, then give the fly-wheel one or two turns, and the engine will start readily. There is also a handle upon the cam-shaft, which, when starting the engine, must be placed in the position marked "To Start," and immediately the engine has gotten up speed this handle should be placed in position marked "To Work."




FIG. 65.

(See Fig. 65.) When it is required to stop the engine, turn the starting handle to the position marked "Shut." If too much oil is pumped into vaporizer before starting it will be difficult to start up.

OILING ENGINE.—See that the oil-cups on the main crank-shaft bearings are fitted with proper wicks and with other oil-cups are filled with oil. Oil the

small end of the connecting-rod which is inside the piston, also the bearings on horizontal shaft and the skew-gearing, the rollers at the ends of the valve-levers and their pins, and the pins on which the levers rock, the governor spindle and joints, the bevel-wheels which drive same, and the joints that connect the governor




FIG. 66.

to the small relief-valve on the vaporizer valve-box. For such purposes, none but the best engine oil should be used.

OIL-PUMP.—When the engine is working at its full power the distance between the two round flanges *A* and *B* on the pump-plunger should be such that the gauge “1” will just fit in between the flanges. (See

Fig. 66.) The other lengths on the hand-gauge marked "2" and "3" are useful for adjusting the pump to economize oil when running on a medium or a light load. Do not screw down the pump packing tight enough to interfere with the free working of the plunger.

RUNNING ENGINES LIGHT OR NEARLY SO.—When engines are required to run with light or no load, it is best to alter the stroke of the pump to supply only sufficient oil to keep the engine running at full speed, so that the governor occasionally reduces the oil. The inlet water-pipe to the vaporizer-jacket should be closed when running light also.

AIR-INLET AND EXHAUST VALVES.—See that the air-inlet and exhaust valves are working properly and drop onto their seats. They can at any time, if required, be made tight by grinding in with a little flour of emery and water. The set-screws at the ends of the levers that open these valves must not be screwed up so high that the valves cannot close; this can be ascertained by seeing that the rollers at the other end of the levers are just clear of the cams when the projecting part of the cams is not touching them. (See Fig. 67.)

VAPORIZER VALVE-BOX.—In this box there are two valves. The vertical one is regulated by the governor, and when the engine runs too fast the governor pushes it down, thus opening it and allowing some oil to overflow into the by-pass, which should only allow oil to pass when the governor presses it down, or when the starting handle is turned to "Shut." The horizontal

valve in this box is a back-pressure valve, and should a leakage occur it may be discovered by slightly opening the overflow-valve (by pressing it down with the hand), when, if there is a leakage, vapor will issue from the overflow-pipe, and in that case the valve should be examined, and, if necessary, be taken out for inspection and ground on its seat with a little emery flour and water. If the horizontal valve and sleeve are taken out, care should be taken, in replacing them, to use the same thickness of jointing material as before.

OIL-PIPES.—The pipe from the pump to the vaporizer valve-box has a gradual rise from the pump; if




FIG. 67.

otherwise, an air-pocket would be formed in which air would be compressed upon each stroke of the pump, and thus allow the oil to enter slowly and not as it should do, suddenly. If the oil gets below the filter at any time, work the pump by hand a few minutes, holding open the overflow-valve in the vaporizing valve-box, so as to get the air well out of the pipes. The oil-filter should be taken out and cleaned occasionally.

SPRAY HOLES.—It may be desirable to take off the vaporizer valve-box and clean the little hole or holes through which the oil issues. The reamers, or small wires supplied, are not for increasing the size of the hole, but are simply for cleaning it at any time.

TESTING OIL-PUMP.—See that the pump gets its proper oil supply. Disconnect the oil-supply pipe union attached to vaporizer valve-box, and give the




FIG. 68.

pump two or three strokes so as to pump oil up; then press the thumb firmly on the end of the pipe, as shown in illustration, Fig. 68. Pump both by a sudden jerk, and afterward by a steady pressure. If the plunger yields to a sudden jerk and no oil has gotten past the thumb over the top of the delivery-pipe, then the pump or the pipes contain air. If the plunger does not yield to a sudden jerk, but slowly falls under a constant pressure, then the suction-valves of pump are

not tight. If necessary, the valve-seats can be renewed by lightly driving the cast-steel ball valves onto their seats with a small copper punch. If it is required to see that the vaporizer valve-box is in order, take off the vaporizer valve-box body and sleeve, and connect them to the oil-supply pipe from the pump, so that the jet from the spraying hole can be directed where it can be seen. Work the pump by hand, when the jet produced should be clear, with distinct and abrupt pauses between each delivery.

THE GOVERNOR "HUNTING."—This may be caused by the joints or spindle of the governor becoming bent, dirty, or sticky, and requiring cleaning. If the pump is not giving a regular supply of oil, it may sometimes cause the governor to hunt, and the engine would run irregularly. This may occur when the engine is first started.

THE CROSSLEY PATENT TYPE.

STARTING.—Heat the ignition-tube by means of the lamp in the usual way. The pressure (about 60 lbs.) necessary to raise the oil to the lamp in this engine is taken from the oil-tank, the air pressure before starting being created by hand. This lamp heats both the ignition-tube to a good red heat and vaporizer blocks to less heat simultaneously. The necessary pressure to raise the oil to the lamp is maintained by the pump actuated from the cam-shaft when the engine is running.

PRIMING CUP.—Fill the little brass priming cup on

the top of the vaporizer cover with oil; open the valve and let the oil pass through into the vaporizer, and then shut it again. Leave the wire on the chain out of the measurer. Place the exhaust roller over to engage with the one-half compression cam; turn the fly-wheel until the crank-pin is about one inch above the horizontal (both valves being closed); open the stop-valve on the end of air-receiver; connect up the oil-pump by replacing the back-pin, having first made a few strokes with the hand-pump until the oil-pipe is full up to the measurer, and turn the quadrant on air-throttle valve. The engine is now ready to start, and the air under pressure from receiver may be let in. Loosen the screw of starter valve; open the valve by means of the loose lever, and hold open until the crank has just passed the vertical position. This impulse will be sufficient to turn the fly-wheel a few times, during which the piston will receive regular impulses. The exhaust roller may then be moved off the one-half compression, when full speed will be steadily attained.

As soon as convenient the screw on the starting valve may be unscrewed to allow the receiver to become recharged again. Should the engine miss explosions and fail to attain full speed, then turn the lid of measurer partly around and give a little extra supply of oil from a hand-can.

AIR SUPPLY.—At full speed the air-throttle must be opened to admit more air, and the amount must be judged as to whether the engine ignites its charges or not; too much air will cause it to miss fire—too little air causes too sharp firing. If the receiver is not

charged, and it is required to start engine by hand, pull around the fly-wheel and get up as much speed as possible before putting the governor blade in position for engaging with the governor mechanism which opens the gas-valve.

VAPORIZER BLOCK.—The vaporizer block must be well heated previous to starting; otherwise unvaporized oil will be carried over into cylinder, and thus make starting uncertain until the oil has all passed away in evaporation. This may also cause puffs of vapor to rush out of the air inlet at the top of the chimney, preceded by a slight explosion in the vaporizer block. This is caused by late ignition in cylinder, and is due to insufficient vaporization or to the ignition-tube not being hot enough.

VAPOR VALVE.—If small puffs of vapor issues out of the air-pipe of the chimney every other revolution while the engine is running, it is a proof that the vapor-valve is not tight and must be cleaned and ground on its seating.

CAMPBELL OIL ENGINE.

STARTING.—Before starting the engine, see that the vaporizer is thoroughly well heated. The lamp under the vaporizer should burn with a long, bright flame. When the vaporizer is sufficiently heated, throw the governor drop-lever down, thus holding the exhaust-valve open and relieving the compression. While this lever is held down, give a quarter or a half turn of the

oil-cock; then turn the fly-wheel quickly four or five revolutions, and allow the governor drop-lever to be free. It will swing up clear of the exhaust-lever and allow a charge of air and oil to be driven into the vaporizer; the engine should then commence working. After the engine has started, turn on a little more oil. If the oil taken into the vaporizer should not explode properly, the oil-cock must be shut and opened again quickly to allow any superfluous oil which has lodged in the vaporizer to be drawn out of it and vaporized. When using a heavy oil, open the inlet-valve to allow more air to flow into the vaporizer.

AIR AND OIL SUPPLY.—Too much oil passing to the vaporizer will cause the engine to miss exploding or to explode irregularly. To increase the air supply, slacken the nuts and tension of air-inlet valve; by tightening the nuts and spring, the air supply is decreased.

IGNITION-TUBE.—See that the inside of the ignition-tube is kept clear from oil, and keep all the valves clean and the governors free from oil and dirt. When the engine is running properly, the quantity of oil required is the same, whether the engine is running at light or heavy load.

GOVERNORS.—The governors cut out some of the charges at light loads and admit more charges of oil at heavy loads; each charge, however, has the same composition of vapor and air.

THE PRIESTMAN TYPE.

STARTING.—Open the drain-cock in the vaporizer and see that the vaporizer contains no oil; then close the cock. Fill the oil-tank to the small upper-pet cock, through the strainer provided and screw down the relief air-valve. Lubricate the piston wrist-pin and the crank-bearing between the fly-wheels. Drop a little oil on the pump-piston and in the oil holes of the bearings of the large gear-wheels, the eccentric, and all other bearings. Mineral oil must not be used on the governor oil spindle which projects into the spray-maker.

ELECTRIC IGNITER.—Raise the electric fork-handle slightly. This is done in order to produce the igniting spark somewhat later for starting than is required when the engine is running at full speed. Turn the fly-wheels forward until the small knob on the cam-shaft has just passed the contact with the forks, and the crank-pin is then just clear of the large gear-wheel.

HEATING VAPORIZER.—Heat the vaporizer until the lower part of the feed-pipe leading to the inlet-valve is too hot to be comfortably held by hand. When the vaporizer is sufficiently heated, pump up 6 or 8 lbs. gauge air pressure in the oil-tank with the hand-pump; open the oil-cock, and then give the fly-wheels a few turns with the starting handle. After starting, move the electric fork-handle down as far as it will go.

AIR SUPPLY.—Set the air-relief valves for giving about 8 to 10 lbs. air pressure in the oil-tank. The most suitable running pressure in a given locality as indi-

cated by the gauge, has to be determined by experiment. With the air pressure too low or too high, the engine may miss explosions. The best test for this is the color of the ignition-plug. When the pressure is right, the plug will be perfectly clean. If the plug is coated with an oily black substance, it is a sign of too much oil—that is, too high a pressure. To stop the engine, turn off the oil-cock. When stopped, see that the electric circuit is not closed, or the battery energy will be wasted.

GENERAL REMARKS.—If an oil engine is working properly and efficiently, it should run smoothly to the eye, without knocking either in the cylinder or bearings. The piston should continue to work clean and be well lubricated, without any apparent carbon or gummy deposit. The exhaust gases at the outlet-pipe should be invisible or nearly so. The explosion should be regular and should be only reduced in pressure when the governor is reducing the explosive charge and allowing only part or none of the charge of oil to enter the cylinder.

If the piston is black and gummy, or if the exhaust gases are like smoke, then the combustion inside the cylinder is recognized as being incomplete, and the cause should at once be ascertained and remedied.

Bad combustion may be due to several reasons, but is chiefly caused by improper mixture of air and gases in the cylinder, due either to too much oil entering into the vaporizer or to insufficient amount of air being drawn in mixed with the hydrocarbon gas. To remedy this defect, examine the oil-inlet valves or spraying de-

vice carefully; also see that air and exhaust valves are allowed to drop freely on their seats, and that springs or other mechanism for closing the valves are in good shape. Examine piston-rings and ascertain that the rings are in good order and are not allowing leakage of air to pass them.

REGULATION OF SPEED.—To alter speed of the engine with the hit-and-miss type of governor, the spring is strengthened or the weight reduced to increase speed. The weight is effectively increased by moving it toward the end of the lever away from the fulcrum-pin, and *vice versa* to reduce speed. The strength of the spring is increased by tightening down the thumb-screw nut. With the Porter type of governor where counterbalance with movable counterweight is provided, the speed is accelerated by increasing the supplementary weight, or by placing it nearer the end of the lever. If the centrifugal force of the revolving weights is controlled by a spring instead of weight, then the speed is increased by strengthening the spring.

REVERSING DIRECTION OF ROTATION.—In order to reverse the direction of rotation of an explosive engine, it is necessary to change the relative position of the cams actuating the air and exhaust valves and fuel supply so as to alter the periods of opening and closing of these valves, and also to change the period of fuel supply. In those engines in which one cam controls both the air-inlet valve and the fuel supply, the shifting of this one cam alone effects the change necessary. Where the fuel supply is operated separately, the cam

or eccentric controlling this mechanism must be moved correspondingly with the air-valve cam.

The following diagrams give the correct positions




FIG. 69.

of the opening and closing of the valves when the engine is running in each direction, and the cams as set for each case are shown in Fig. 69, the slot for key-way in the air-inlet cam having been changed only.

Where the air-inlet valve is automatic and the exhaust-valve only is actuated from the crank-shaft, then, to reverse the direction of rotation of the crank-shaft, the position of the exhaust-cam only is changed, corresponding to the position as marked for the exhaust-valve in diagram shown in Fig. 69.



CHAPTER VIII.

REPAIRS.

OIL ENGINES as made by most of the makers are of substantial construction, with ample bearing surfaces, and consequently require few repairs. The lower initial pressures of explosion evolved in oil engines as compared with some gas and gasoline engines considerably lessens the severe shock to the piston and to the crankshaft bearings and connecting-rod bearings. All machinery requires repairs more or less according to the care that it receives, and oil engines are not an exception to this rule.

THE PISTON should be drawn out occasionally; this is done by uncoupling the connecting-rod crank end bearings and pulling the piston out. Chain-block is sometimes added to the installation of large engines, and it is a very useful adjunct when it is required to take out the piston or when other repairs have to be made. Where no arrangement of this kind is available when the piston is to be taken out, wooden packing is placed in the engine-bed, on which the piston can rest as it is drawn out. Care should be taken that the weight of the piston as it is drawn from the cylinder does not fall on the piston-rings or they may thus be broken.

With the vertical type of engine the piston is taken out from the top, the cylinder head and other parts having been removed.

The piston should be washed with kerosene and well cleaned. When putting piston back in place, each ring should be put separately in exact position in its groove as regards the dowel-pin in piston groove before the ring enters the cylinder. The piston, the rings, and the inside of the cylinder must all be carefully cleaned and well lubricated with proper oil before being again put in place. Where the rings require cleaning, this can be accomplished by washing with kerosene. If, however, the piston-rings are to be taken off the piston, they must be separately sprung open by having pieces of sheet metal about 1-16" thick and about $\frac{1}{2}$ " wide inserted between ring and body of piston.

Air and exhaust valves should also be periodically taken out, cleaned and examined, and, if necessary, re-ground in. Powdered emery or glass powder is considered satisfactory to grind the valves in with.

Care should be taken, in replacing valves, that they are clean and free from rust or carbon, and are allowed to drop on their seats freely and do not stick in their guides.

The crank-shaft bearings will periodically require taking up as they show signs of wear and commence to knock or pound. Usually, for this adjustment, liners are left between the cap and the lower half of bearings. These liners can be occasionally reduced in thickness, so that the cap is allowed to come down close on to the shaft. Great care must be taken, in

tightening down the bearing again after adjustment, that it is not bolted down too tight on the shaft bearings; otherwise heating will result and the bearings and journal may be cut and damaged in running.

The connecting-rod bearings will require adjustment more often than the crank-shaft or main bearings.




FIG. 70.

When this is necessary, the engine will be heard to knock at each revolution, and then the bearing should be taken apart at the crank-pin bearing and about $1/64$ " filed off. (See *A*, Fig. 70.) As with the crank-shaft bearings, great care, in putting bearing back in place, must be exercised, first to see that it is thoroughly clean and free from dirt, and also, when readjusted, that it has a slight motion sideways and can thus be moved by hand.

When fitting new piston-ring, it is well to place the

ring in the cylinder correctly; it should have slight space, about $1/64$ " left for the expansion between the joint which will take place when heated in working.

After fitting new worm or spur gearing to the valve motion, the positions of the cams should be tested by turning the fly-wheel over by hand. The correct positions of the cams are shown on diagram, Fig. 32.

The oil-filter requires occasional renewing; this can be made of muslin placed between wire gauze, as shown in Fig. 28. The oil-supply pump-valves, if they consist of steel balls, can be refitted to their seats by being tapped when in place with copper plug or piece of wood. When renewing governor parts, care must be taken that the new part is free and works without friction; this is very essential where close regulation of speed is required.

CHAPTER IX.

VARIOUS ENGINES DESCRIBED.

THE CROSSLEY OIL ENGINES.

FIGURE 71 represents recent design of high-speed electric-light oil engine of 25 effective or brake H. P. This special type of engine is fitted with one heavy fly-wheel on extended shaft and outside bearing instead of the two fly-wheels, one on each side of the engine, as arranged in the smaller sizes. The method of vaporizing and igniting used with the Crossley engine is fully described in Chapter I. devoted to that subject.

The fuel oil-tank is placed against the cast-iron base of the engine, and the oil is pumped to the vaporizer in the usual way by an oil-pump actuated by the cam-shaft and in regular fixed quantities, but the fuel is allowed to enter the vaporizer only in exactly the proper quantity, the oil supply being controlled by the special measuring device, which consists of an inlet automatic valve leading to the vaporizer and an overflow-pipe leading back to the oil-tank. If the oil supply from the pump at any time is greater than the amount of oil which should enter the vaporizer, the fuel is re-




FIG. 71.

jected by the oil-measuring device, which is actuated by the partial vacuum in the cylinder during the air-




Diagram from the Crossley Engine: Revolutions per minute, 180; M. E. P., 69 lbs.; compression pressure, 48 lbs.; maximum pressure, 240 lbs.




Diagram from Crossley Engine: Revolutions per minute, 180; M. E. P., 50 lbs.; compression pressure, 50 lbs.; maximum pressure, 180 lbs.

suction period. The oil then returns through the overflow-pipe to the tank.

The centrifugal governor is actuated by separate gearing and horizontal shaft direct from the crank-




FIG. 72.

shaft, and the governor regulates the speed of the engine by acting on the hit-and-miss system, and con-

trols the vapor inlet-valve to the cylinder. Thus, if the required speed of the engine is exceeded, the vapor-valve is not opened, and accordingly only air is drawn into the cylinder through the air-inlet valve on the top of the cylinder, which is actuated by eccentric from the cam-shaft. No oil vapor is drawn into the cylinder, and the next explosion is missed. The lamp for heating the vaporizer receives its supply from the oil-tank placed against the base of the engine. The oil for the lamp is supplied by a separate pump, both oil-pumps being actuated from the same eccentric.

THE CUNDALL OIL ENGINE.

This oil engine is illustrated in Fig. 72, and it has oil-tank in the cast-iron base of engine, the fuel being pumped to the vaporizer in the usual way, the oil supply being regulated by a small adjustable thimble inside the cup on the vaporizer. The vaporizer and tube are heated by separate lamp supplied from oil-tank placed above the engine by gravity feed. Both air and exhaust valves are actuated from the horizontal cam-shaft in the usual way. The centrifugal governor is operated by bevel-gearing from the cam-shaft and controls the speed by acting on the oil-inlet valve.

THE CAMPBELL OIL ENGINE.

Fig. 73 illustrates larger-sized engine fitted with one fly-wheel only and outside bearing suitable for electric-






FIG. 73.

lighting purposes. The vaporizing and igniting apparatus of this type is described in Chapter I. The fuel



Light-load diagram taken from Campbell engine: Cylinder, 9.5" in diameter; stroke, 18"; revolutions per minute, 210; M. E. P., 55.9 lbs.



Full-load diagram from Campbell Engine: Cylinder, 9.5" in diameter; 18" stroke; revolutions per minute, 210; M. E. P., 69.25; compression pressure, 55 lbs.; maximum pressure, 232 lbs.

oil-tank is placed on the top of the cylinder and the

fuel is fed by gravitation to the vaporizer and to the heating lamp, there being no oil-pumps. There are only two valves—the air-inlet valve, which is automatic, and the exhaust-valve, which is operated by the cam, which is actuated by spur-gearing from the crank-shaft, the necessary power to open the valve being transmitted through the horizontal rod in compression. The centrifugal governor is mounted on separate horizontal shaft, and is actuated by separate gearing from the crank-shaft. The speed of the engine is controlled by suitable device which is inserted by the action of the governor between the exhaust-lever and the stationary bracket when the normal speed is exceeded, thus holding open the exhaust-valve and preventing any of the oil vapor and air from entering the cylinder during the suction period.

PRIESTMAN OIL ENGINE.

Fig. 74 represents this type of engine as made by Messrs. Priestman in the United States.

The design of this engine is upon the “straight line” principle, and differs from the other engines herein described. In this engine, both the fly-wheels are arranged to be inside of the main shaft bearings instead of at each side of the frame, as is usual. The makers claim great advantages for this design, inasmuch as the strain on the bearings is minimized. The crank-pin is placed between the two fly-wheels, the hub of each fly-

wheel becoming the cheek of the crank. The oil-tank is placed in the bed of the engine; an air pressure of five or six pounds is always maintained in this tank by means of the separate air-pump actuated from the cam-shaft by eccentric. The vaporizer spraying and igniting devices are fully described in Chapter I.

The governor is driven by belt from the crank-shaft





FIG. 74.

and is of the centrifugal or pendulum type. The speed of the engine is controlled by suitable mechanism acting on the throttle-valve regulating the supply of oil and air entering the vaporizer. The air-inlet valve to the cylinder is automatic, the exhaust-valve being actuated by horizontal rod operated from a cam placed

on the cam-shaft. This engine, it is claimed, requires little or no lubrication for the piston.

THE MIETZ & WEISS ENGINE

This engine is illustrated in Fig. 75. It works not, as all other engines described herein, on the Beau de



INDICATOR CARD OF THE PRIESTMAN ENGINE.

Rochas cycle, but on the two-cycle principle—that is, an explosion is obtained in the cylinder at each revolution of the crank-shaft. The oil-tank is placed above the cylinder, and fuel is supplied to the engine partly by gravitation—the quantity injected, however, into the

cylinder being regulated by small oil-supply pump. The governor is of the inertia type, and acts directly on the pump on the hit-and-miss principle. If the speed of the engine exceeds the standard number of revolutions, the governor causes the charge of oil which otherwise would enter the combustion chamber or cylinder to be





FIG. 75.

missed, and no explosion follows. The governor itself is actuated from the crank-shaft by eccentric and bell crank direct. The oil is vaporized in a hot chamber placed at the back of the cylinder, which is heated for a few minutes in starting by independent lamp; afterward the heat created by constant compression maintains the igniter at proper temperature automatically.

The compression of the air is generated in the crank-chamber and the air is drawn into the cylinder at a slight pressure during each outstroke of the piston. The exhaust opening is automatically uncovered by the piston, the exhaust passage being made in the cylinder wall. As the piston travels toward the end of the



Indicator diagram taken from the Mietz & Weiss Engine: diameter of cylinder, 12"; stroke, 12"; revolutions per minute, 300; scale, 100; B. H. P., 20.

stroke, this passage is uncovered, and the products of combustion are free to pass to the exhaust-pipe, while the piston travels to the end of the stroke and the first part of the return stroke until the port is again covered, when the compression period commences for the next explosion. These engines are now being made of from 1 to 40 H. P.

HORNSBY-AKROYD OIL ENGINE.

Fig. 76 shows this engine as made by the De La Vergne Refrigerating Company, of New York. It is also made by the patentees at Grantham, England, and in France and Germany.

The Hornsby-Akroyd engine is made in sizes of $1\frac{1}{2}$ to 50 H. P., all sizes being made of the horizontal type. The smaller sizes are made of the vertical type also, as shown at Fig. 77. The fuel oil-tank is placed in the base of the engine and the fuel is delivered to the vaporizer by the small pump actuated from the cam-shaft by the lever which also actuates the air-inlet valve. The oil supply is raised to the vaporizer valve-box in regular quantities, but the oil is only allowed to enter the vaporizer to the required amount, the remainder of the oil flowing back to the tank through the by-pass valve which is regulated by the governor. Thus, if the speed of the fly-wheel exceeds the normal number of revolutions for which the engine is set, the governor mechanism opens the by-pass oil-valve, allowing part of the oil to flow back to the oil-tank, and accordingly reduces the charge entering the vaporizer, and consequently the mean pressure for one or more explosions is reduced in the cylinder. The governor is of the Porter type, actuated by gearing from the cam-shaft. The method of vaporizing and igniting is fully described in Chapter I. Both air-inlet and exhaust




FIG. 76.

valves are actuated from the cam-shaft, these valves




FIG. 77.

being placed on the side of the engine. The air inlet in this type is different from the other engines de-

scribed. In this case the air enters not through the vaporizer, but by means of separate valve-chamber.




Diagram taken from Hornsby-Akroyd Engine: M. E. P., 48 lbs.; compression pressure, 50 lbs.; maximum pressure, 160 lbs.; revolutions per minute, 185; cylinder, 18.5" diameter; 24" stroke; full load.




Diagram taken from Hornsby-Akroyd Engine: Diameter of cylinder, 11"; stroke, 15"; M. E. P., 49.5 lbs.; compression pressure, 60 lbs.; revolutions per minute, 230; consumption of oil W. W., 150° F. 0.8 lbs. per B. H. P. per hour.

THE DIESEL MOTOR.

Fig. 78 represents the Diesel motor as it is being built in the United States. It is of the vertical type, and is designed with closed crank-chamber, which forms the bed of the engine and to which the cylinder is bolted. The air-pumps which compress the air for the purpose of injecting the fuel at a greater pressure than that of compression in the main cylinder are placed inside of the crank-chamber and are actuated by rods from the main piston. The fuel oil-tank is placed at the bottom of the base on the one side and the air-pressure tanks are placed in the base plate. The air-inlet valve to the cylinder is automatic. The exhaust-valve, the fuel inlet-valve and the starting-valve are each actuated from gearing on a horizontal shaft, which is actuated by two sets of bevel-gearing and spur-gearing from the crank-shaft, at half speed.

The operation of the engine is on the ordinary Beau de Rochas or four-cycle principle, and is as follows:

The receiver is charged with air at the desired maximum pressure (about 600 pounds per square inch). This is accomplished the first time of starting by connecting the receiver to a tank of liquid carbonic acid gas, from which the necessary pressure is obtained. The reservoir being once charged, the receiver is maintained afterward constantly at a maximum pressure by the auxiliary air-pumps.

To start the engine the piston is placed at the top of

its stroke. The hand-starting lever is set so that the valve gear is on the two-cycle and the starting-valve





FIG. 78.

is opened at each revolution. The oil-pump is operated a few strokes by hand, whereby the space around the

stem of the fuel-valve is supplied with oil, this space being connected to the receiver by a small pipe. When communication between the starting-valve and the receiver is made, by opening a cock by hand, the pressure from the receiver acts upon the piston and starts the latter downward. After several down strokes the operator shifts the lever and throws the fuel-valve into gear on the four-cycle. The momentum acquired carries the piston through an up stroke, and compresses the contents of the main cylinder to about 520 pounds per square inch, whereby they are heated to a temperature of upward of 1000° Fahr. As the piston starts to make another down stroke by momentum, the fuel-valve opens, and the 600 pounds of air pressure in the receiver acting upon the fuel forces the latter into the heated contents of the cylinder, thereby causing combustion to occur, and power to be developed throughout the second down stroke; the fuel-valve closes at about one-tenth of the stroke of the piston, so that the heat developed is applied with a high degree of expansion. On the next up stroke the exhaust-valve is opened, permitting the cylinder to exhaust itself against the atmosphere. During the next down stroke of the piston the inlet-valve connecting with the atmosphere supplies the cylinder with air. This is compressed on the return stroke, and oil again introduced, and thence the operation of the engine proceeds regularly, the air-pump constantly supplying compressed air through the pipe to the space about the stem of the fuel-valve, which, being constantly connected to the

receiver, maintains the latter at the maximum pressure. The main cylinder and air-pumps are water-jacketed, and both the head of the main cylinder and those of the air pumps have cooling water circulating through them. Both the main and air cylinders are lubricated by splashing from the crank pit. The speed of the engine is governed by an ordinary centrifugal governor, which controls the length of the stroke of



INDICATOR CARD FROM THE DIESEL MOTOR.

the fuel-pump. The engine is provided with two heavy fly-wheels placed each side of the main bearings. The distinctive feature of the Diesel engine is its high thermal efficiency, which is caused partly by the high pressure of compression of the air in the cylinder, but mainly by its slow and controlled combustion. When the fuel is injected, the cylinder volume is decreased to about one-fifteenth of the total volume.

This allows of a very much larger expansion of the heated gases as compared with engines of the explosive type. The Diesel engine has created great interest in engineering circles the world over, and many tests have been made of it. Professor Denton, of the Stevens Institute, Hoboken, N. J., in 1898 conducted a series of tests on this engine, and according to his report of those tests the consumption of fuel was 0.534 pounds per B. H. P. per hour at full load, and at less than half load 0.72 pounds per B. H. P. per hour. This is equivalent to a thermal efficiency (on the I. H. P.) of 37.7 per cent.

The following is the heat-balance table as shown by Professor Denton:

	PER CENT.
Heat of combustion accounted for by indicated power.....	37.2
Removed by jacket.....	35.4
Remainder.....	27.4
	<hr/>
Total heat of combustion.....	100.0

The Diesel engine has just received the Grand Prix at the Paris World's Fair.

PORTABLE ENGINES.

Oil engines of the portable type are made by nearly all the makers of the fixed horizontal types herein mentioned.

The chief advantage of the portable oil engine as compared with the steam engine is the small bulk of fuel used and the small quantity of water required.

The portable type, as to its method of working and its details, is usually made similar to the fixed type of engine, with the exception that it is constructed of lighter material. One of the most important features




FIG. 79.

in the portable type is that of the cooling-water apparatus.

This device is differently constructed by the various makers. Fig. 79 illustrates the Hornsby-Akroyd type; in this the circulating water is pumped rapidly from tank placed under the engine-bed through the cylinder water-jacket, and thence to the top of a vertical gradier work formed of wooden slats or boards, down which

the water trickles. Air is drawn upward through these wooden slats simultaneously; this draft of air is caused by the exhaust gases which are discharged to the atmosphere above the gradier work, thus inducing a current of air through the gradier work in a way somewhat similar to the arrangement of the steam exhaust of a locomotive. With this arrangement, only about 50 gallons of water are required to maintain the proper temperature of the cylinder.

With other types of portable engines the water is cooled by being conducted over a series of horizontal trays, a current of cooling air being induced to pass over each of these horizontal trays.

TABLE V.—TESTS OF VARIOUS OIL ENGINES MADE IN EDINBURGH.

ENGINES.	Crossley Bros., Ltd.	Campbell Gas Engine Co.	Campbell Gas Engine Co.	R. Stephenson & Co.	Blackstone & Co.	Blackstone & Co.	Blackstone & Co.	Tangyes, Ltd.	Pollock, Whyte and Waddell.	R. Candall & Son.
Diameter of cylinder, inches	10	9½	12½	7	6	7	9½	11	10	8¾
Stroke, inches.....	18	18	21	12	12	14	18	16	18	15
Price of oil per gal. delivered Edin., pence.....	6½	6½	6½	6½	6½	6½	6½	6½	6½	6½
FULL POWER TRIAL:										
Brake horsepower.....	15.5	13.87	18.93	3.14	5.21	8.13	12.6	18.06	10.64	8.77
Total oil used per hour, lb.	12.29	14.74	22.74	5.13	4.34	6.78	9.40	14.56	12.31	8.43
Oil per BHP per hour, lb.	.793	1.06	1.20	1.63	.833	.836	.746	.806	1.15	.962
Cost per hour (total), pence	10.08	11.60	17.88	4.20	3.42	5.35	7.42	11.50	10.05	6.86
“ per BHP per hour, pence	.65	.83	.94	1.33	.656	.658	.588	.636	.938	.782
HALF POWER TRIAL:										
Brake horsepower.....	7.71	6.73	10.59	1.31	2.84	4.84	6.59	9.95	4.69	4.35
Total oil used per hour, lb.	8.00	7.985	15.52	3.78	3.125	4.975	6.75	9.35	10.75	6.496
Oil per BHP per hour, lb.	1.037	1.186	1.466	2.88	1.099	1.03	1.024	.939	2.23	1.57
Cost per hour (total), pence	6.56	6.28	12.22	3.08	2.46	3.92	5.32	7.38	8.77	5.27
“ per BHP per hour, pence	.85	.933	1.152	2.35	.865	.812	.807	.741	1.82	1.275
LIGHT POWER TRIAL:										
Total oil used per hour, lb.	4.03	3.8	8.23	4.43	1.69	2.75	3.4	3.375	5.375	4.24
Cost per hour, pence.....	3.30	2.99	6.47	3.62	1.33	2.17	2.68	2.67	4.38	3.44
MAXIMUM POWER TRIAL:										
Brake horsepower.....	18.01	14.89	25.55	3.14	6.68	10.66	19.7	20.66	19.85	16.54

TABLE VI.—TESTS OF VARIOUS OIL ENGINES MADE IN EDINBURGH.

ENGINES.	Crossley Bros., Ltd.		Campbell Gas Engine Co.		Campbell Gas Engine Co.		R. Stephenson & Co.		Blackstone & Co.		Blackstone & Co.		Blackstone & Co.		Tangyes, Ltd.		Pollock, White and Waddell.		R. Cundall & Sons.		
	Royal Daylight	Russolene	Russolene	Russolene	Royal Daylight	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Royal Daylight	Russolene	Royal Daylight	Russolene	
Duration of trial hours.	3.762	—	4	4	1.266	4	4	4	4	4	4	4	4	4	4	4	4	4	2	2	
Time taken to start full load, minutes.	18¼	31	14	14	10	11	10	10	10	10	10	10	10	10	10	10	10	10	11	11	
BRAKE HORSEPOWER :																					
Circumference of flywheel, effective, ft.	11.322	17.586	15.952	15.952	14.214	10.936	10.936	14.040	17.529	16.022	15.845	15.845	16.022	15.845	16.022	15.845	16.022	15.845	14.372	14.372	
Load on brake, lb.	224.5	204	147	147	41	70	70	98	168	204.75	204.75	204.75	204.75	204.75	204.75	204.75	204.75	204.75	96.25	96.25	
Spring balance reading, lb.	3	15	11.37	11.37	12	8.55	8.55	10.3	43.4	18.82	11.5	11.5	18.82	11.5	18.82	11.5	18.82	11.5	7.54	7.54	
Net load on brake, lb.	221.5	189	135.63	135.63	29	61.45	61.45	87.7	124.6	185.93	100.5	100.5	185.93	100.5	185.93	100.5	185.93	100.5	88.71	88.71	
Revolutions per minute, mean.	204	188	210	210	252	256	256	218	190.3	200.1	220.5	220.5	200.1	220.5	200.1	220.5	200.1	220.5	227.7	227.7	
Brake horsepower.	15.5	18.93	13.87	13.87	3.14	5.21	5.21	8.13	12.6	18.06	10.64	10.64	18.06	10.64	18.06	10.64	18.06	10.64	8.77	8.77	
INDICATED HORSEPOWER :																					
Diameter of cylinder, inches.	10	12.5	9.5	9.5	7	6	6	7	9.5	11	10	10	11	10	11	10	11	10	8.75	8.75	
Stroke, inches.	18	21	18	18	12	12	12	14	18	16	18	18	16	18	16	18	16	18	15	15	
Mean effective pressure, lb. per sq. in.	64.52	49.5	—	—	39	—	—	—	56	62.2	—	—	62.2	—	62.2	—	—	—	—	—	
Explosions per minute, mean.	87.25	76	—	—	118.5	—	—	—	81.4	89.75	—	—	89.75	—	89.75	—	—	—	—	—	
Indicated horsepower.	20.09	24.48	—	—	5.39	—	—	—	14.68	21.43	—	—	21.43	—	21.43	—	—	—	—	—	
Mechanical efficiency.771	.773	—	—	.582	—	—	—	.858	.842	—	—	.842	—	.842	—	—	—	—	—	
OIL CONSUMPTION :																					
Description of oil used in trial.	Royal Daylight	Russolene	Russolene	Russolene	Royal Daylight	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Russolene	Royal Daylight	Russolene	Royal Daylight	
Specific gravity.793	.826	.826	.826	.796	.825	.825	.825	.825	.825	.825	.825	.825	.825	.825	.825	.825	.797	.800	.800	
Total oil used, engine and lamps, lb.	46.25	90.97	58.99	58.99	6.5	17.375	17.375	27.125	37.625	58.25	49.25	49.25	58.25	49.25	58.25	49.25	58.25	49.25	16.875	16.875	
Oil per I.H.P. per hour, lb.611	.928	—	—	.952	—	—	—	.640	.679	—	—	.640	.679	.679	—	.679	—	—	—	
“ “ B.H.P. “ “ “ “793	1.200	1.200	1.200	1.63	.833	.833	.836	.746	.806	—	—	.806	—	.806	—	.806	—	—	—	

TABLE VII.—CALORIFIC POWER OF VARIOUS DESCRIPTIONS OF PETROLEUM, ETC. (B. REDWOOD.)

Description of Oil.	Specific Grav- ity at ° C.	Chemical Com- position.			Coefficient of Expansion.	Am't of Water Evaporated Per Unit of Fuel.	Effect in Heat Units.
		Carbon.	Hydro- gen.	Oxygen.			
Heavy Petroleum from West Virginia.....	0.873	83.5	13.3	3.2	0.00072	14.58	10,180
Light Petroleum from West Virginia.....	0.8412	84.3	14.1	1.6	0.000839	14.55	10,223
Light Petroleum from Pennsylvania.....	0.816	82.0	14.8	3.2	0.00084	14.05	9,963
Heavy Petroleum from Pennsylvania.....	0.886	84.9	13.7	1.04	0.000721	15.30	10,672
American Petroleum..	0.820	83.4	14.7	1.9	0.000868	14.14	9,771
Petroleum from Parma	0.786	84.0	13.4	1.8	0.000706	13.96	10,121
Petroleum from Pech- elbronn.....	0.912	86.9	11.8	1.3	0.000767	14.30	9,708
Petroleum from Pech- elbronn.....	0.892	85.7	12.0	2.3	0.000793	14.48	10,020
Petroleum from Schwabweiler.....	0.861	86.2	13.3	0.5	0.000858	15.36	10,458
Petroleum from Schwabweiler.....	0.829	79.5	13.6	6.9	0.000843
Petroleum from Han- over.....	0.892	80.4	12.7	6.9	0.000772
Petroleum from Han- over.....	0.955	86.2	11.4	2.4	0.000641
Petroleum from East Galicia.....	0.870	82.2	12.1	5.7	0.000813	14.23	10,085
Petroleum from West Galicia.....	0.885	85.3	12.6	2.1 (N. O.)	0.000775	14.79	10,231
Shale Oil from Ardèche	0.911	80.3	11.5	8.2	0.000896	12.24	9,046
Coal Tar from Paris Gasworks.....	1.044	82.0	7.6	10.4 (O. S. N.)	0.000743	12.77	8,916
Petroleum from Balak- hany.....	0.822	87.4	12.5	0.1	0.000817	11,700
Light Petroleum from Baku.....	0.844	86.3	13.6	0.1	0.000724	16.40	11,460
Heavy Petroleum from Baku.....	0.938	86.6	12.3	1.1	0.000681	15.55	10,800
Petroleum residues from Baku Factories	0.928	87.1	11.7	1.2	0.00091	10,700
Petroleum from Java..	0.923	87.1	12.0	0.9	0.000769	15.02	10,831
Heavy Oil from Ogaio	0.985	87.1	10.4	2.5	0.0008685	14.75	10,081

TABLE IX.—OIL FUEL. (B. REDWOOD.)

Locality.	Fuel.	Sp. Gr. at ° C.	Chemical Composition.			Heating Power.	
			Carbon.	Hydrogen.	Oxygen.	Actual Calorimetric (lb. C. Units.)	Calculated (lb. C. Heat Units.)
Russian.....	Petrol. refuse	0.928	87.1	11.7	1.2	11,018
"	Astatki	0.9	84.94	13.96	1.2	10,340	11,626
Caucasian.....	Heavy Crude	0.938	86.6	12.3	1.1	10,800	11,200
" (Novorossisk)	" "	84.9	11.63	1.458	10,328
Pennsylvanian.....	" "	0.886	84.9	13.7	1.4	10,672
American.....	" "	86.894	13.107	10,912
"	Refined	85.491	14.216	0.293	11,045
"	Double "	80.583	15.101	4.316	11,086
"	Crude "	83.012	13.889	3.099	11,094

TABLE X.—CALORIFIC POWER OF CRUDE PETROLEUM. (B. REDWOOD.)

	Sp. Gr.	Calories.
Heavy Lubricating Oil, White Oak, } Western Virginia	0.873	10,180
Light Illuminating Oil, Oil Creek, Pa.	0.816	9,963
Oil from Dandang, Leo Rembang, } Java.	0.923	10,831
Light Oil from Baku.....	0.884	11,460
Oil from Western Galicia.....	0.885	10,231
" " Eastern "	0.870	10,005
" " Parma.....	0.786	10,121
" " Schwabweiler	0.861	10,458

INDEX.

PAGE	PAGE		
ABEL oil-tester.....	90	Balancing formula.....	29
Actual horse-power.....	63	Bearings caps.....	55
Air compressing, horse-		Bearings, crank-shaft..	42, 158
power required.....	125	Bearings, outside.....	161, 165
Air-compressor at differ-		Bearings, pressure on...	42, 43
ent altitudes.....	131	Bearings, scraping in....	54
Air-compressors	123	Beau de Rochas Cycle,	
Air inlet choked.....	77	15, 16, 76, 177	
Air-inlet valve..	12, 23, 39,	Belt centres.....	115
57, 61, 78, 145, 165, 168		Belt, link.....	113, 115
Air-inlet valve, auto-		Belt, loose.....	115
matic.....	12, 77, 156	Belt, size of.....	116
Air-pump.....	13	Benzine.....	1
Air-receiver	177	B. H. P., to calculate....	65
Air suction, noise of.....	122	Brake, attaching.....	64
Air-suction pipe.....	78	Brake, horse-power....	63, 64
Air-supply (Campbell)...	151	CAMPBELL, governing,	
Air-supply (Crossley)...	149	13, 151, 168	
Air-supply (Priestman)...	152	Campbell oil engine de-	
Asbestos.....	58	scribed.....	165
Assembling oil engines... 53		Campbell starting.....	150
Atmospheric line.....	70, 71	Cams.....	37
BALANCE weights.....	30	Cams, setting.....	60
Balancing crank-shaft....	27	Circulating water-pipes... 97	
Balancing fly-wheel.....	30	Clerk, Dugeld.....	87

PAGE	PAGE
Clutches, friction.....137	Cycles, different, discussed 18
Clutches, friction, advantages of.....137	Cylinder clearance..... 23
Clutches, friction, B and C type.....138	Cylinder cover..... 23
Coal oil..... I	Cylinder lubricating oil...140
Combustion, bad.....89, 153	Cylinder lubricators..... 38
Combustion, complete..... 90	Cylinder, two or more parts..... 57
Compression (Diesel)...6, 25	Cylinders, different types. 22
Compression in crank-chamber.....172	DENTON, Prof.....181
Compression, increasing... 79	Developed horse-power... 63
Compression, irregular... 19	Diagram, analyzing..... 77
Compression line.....76, 78	Diagram, good working.. 76
Compression pressure.... 25	Diesel governing..... 180
Connecting-rod bearings.. 56	Diesel heat balance..... 181
Connecting-rods..... 30	Diesel motor.....6, 177
Connecting-rods, diameter 33	Diesel starting.....177
Connecting-rods, phosphor bronze..... 31	Direct-connected engine and dynamo.....117
Cooling surface..... 23	Direction of rotation, reversing..... 154
Cooling water.....19, 183	Distance-pieces..... 55
Cooling water-tanks..... 96	Draining, water.....104
Copper ring..... 58	Dynamo fly-wheel.....115
Crank-pin.....42, 168	Dynamometer or brake.... 64
Crank-pin dimensions 42	EFFECTIVE horse-power.... 63
Crank-pin, size of..... 26	Efficiencies, thermal, compared..... 87
Crank-shaft..... 25	Efficiency, increase of.... 83
Crank-shaft, balancing.... 27	Efficiency, mechanical..51, 86
Crank-shaft bearings..42, 158	Efficiency, thermal..... 86
Crank-shaft, strength of.. 26	Electric igniter....5, 15, 152
Crossley engine described.161	Electric lighting plant, installation of.....113
Crossley governing.....164	Engine (Campbell).....165
Crossley measuring device.161	
Crossley starting.....148	
Cundall engine described..165	

PAGE	PAGE		
Engine (Cundall).....	165	Fly-wheels for dynamo..	115
Engine frame.....	42	Fly-wheels, formula for...	37
Engine (Hornsby-Akroyd)	140	Fly-wheels, keying on....	57
Engine (Mietz and Weiss)	170	Fly-wheels, peripheral	
Engine, portable.....	181	speed.....	36
Engine (Priestman).....	168	Formulæ.....	20, 21,
Engines (Crossley).....	161	26, 29, 33, 37, 40, 86, 125	
Engines driving dynamos.	111	Foundations.....	113
Engines, electric lighting..	46	Four-cycle.....	15
Engines, knocking.....	159	Frame, engine.....	42
Engines, regulation of.....	117	Friction-clutches	137
Engines, running, general		Friction-clutches, advan-	
remarks.....	153	tages of.....	137
Engines, running, light...	145	Friction-clutches, B and	
Erecting oil engines.....	53	C type.....	138
Exhaust bends.....	41	Frost, provision for.....	99
Exhaust, choked.....	83	Fuel consumption. See	
Exhaust gases.....	90, 153	Tables.	
Exhaust line.....	76, 83	Fuel-consumption test....	87
Exhaust silencers.....	100	Fuel injection.....	9, 180
Exhaust temperature.....	110	Fuel oil-tank.....	13, 49, 161
Exhaust valve.....	13	165, 167, 169, 170, 173, 177	
Exhaust valve, opening of.	76	GASES, exhaust.....	90
Exhaust washer.....	101	Gear, skew.....	43
Expansion line.....	76, 81	Gear, spur.....	43, 160
Explosion.....	20	Gear, starting.....	21
Explosive mixture.....	10, 15	Governing (Campbell),	
		13, 151, 168	
FILTER oil.....	49, 146, 160	Governing (centrifugal),	
Flashing point of oil.....	1	15, 164, 165, 168	
Flashing point to test.....	90	Governing (Crossley)....	164
Flickering of incandescent		Governing devices.....	44
lights.....	119	Governing (Diesel).....	180
Fluctuation in speed.....	37	Governing (Mietz and	
Fly-wheels.....	35, 119	Weiss).....	171
Fly-wheels, energy of.....	53		

	PAGE		PAGE
Governing (Priestman),		Ignition (electric).....	2, 7
15, 169		Ignition (high compression).....	2
Governor, hit-and-miss		Ignition (hot surface)	2, 7, 10
type.....	48	Ignition (hot tube),	
Governor, hunting.....	148	2, 7, 11, 148, 151	
Governor parts, renewing.	160	Ignition line.....	76
Governor, pendulum type..	45	Ignition line, late.....	80
Governor, Porter type....	173	Ignition line, too early...	79
Gravitation (fuel)....	12, 168	Ignition, regulating.....	80
Gravitation system.....	96	Ignition, retarding.....	81
		Impulse on piston.....	17
HEAT, utilization of waste.	107	Incandescent lights.....	116
Heated air.....	11	Incandescent lights, flick-	
Heat balance.....	87	ering of.....	119
Heat balance (Diesel)...	181	Indicated horse-power....	66
Heating lamp.....	8, 11, 12	Indicator attaching to en-	
Heating lamp instructions.	141	gine.....	71
Horizontal and vertical		Indicator cock.....	66
types.....	50	Indicator, Crosby.....	67
Hornsby-Akroyd, instruc-		Indicator diagram.....	48, 75
tions for running....	140	Indicator diagram, light	
Hornsby-Akroyd, method		spring.....	88
of vaporizing.....	9	Indicator, diagram meas-	
Hornsby-Akroyd oil sup-		uring.....	73
ply	173	Indicator in place.....	64
Horse-power.....	63, 66	Indicator, left or right	
		hand.....	70
ICE and refrigerating ma-		Indicator reducing motion.	71
chines.....	133	Indicator springs.....	69
Igniter, electric.....	5, 15, 152	Ingredients for founda-	
Igniter (Hornsby-Akroyd)	2	tions.....	113
Igniters.....	2, 23	Instructions for running	
Igniters (flame).....	2	Hornsby-Akroyd....	140
Igniters, heating.....	61	Instructions for running	
Ignition	140	oil engines.....	139

PAGE	PAGE
JUNK rings..... 55	Method of governing (Campbell).....168
KNOCKING in engine.....159	Method of governing (Diesel).....180
LEAKAGE in crank-chamber 19	Method of governing (Mietz and Weiss)...171
Leakage of piston-rings.61, 78	Method of governing (Priestman).....169
Leakage of valves..... 78	Mietz and Weiss engine described.....170
Leakage of water into cyl- inder..... 63	Mietz and Weiss engine governing.....171
Lights, incandescent.....116	Mixture oil, vapor and air. 14
Line, atmospheric.....70, 71	Motor, Diesel.....6, 177
Line, compression.....76, 78	
Line, exhaust.....76, 83	
Line, expansion.....76, 81	
Link belt.....113, 115	
Loose belt.....115	NORRIS, William..... 26
Lubricating cylinder oil...140	
Lubricators, cylinder..... 38	OIL cylinder, lubricating..140
Lubricators, sight feed... 38	Oil engines, driving dy- namos.....111
MEASURING device (Cross- ley).....161	Oil engines, instructions for running.....139
Mechanical efficiency...51, 86	Oil filter.....49, 146, 160
M. E. P.....21, 67, 81	Oil injection..... 9
M. E. P. gas and gasoline engines..... 22	Oil inlet..... 12
M. E. P. regulated..... 47	Oil measurer (Crossley).. 11
Method of vaporizing (Crossley)..... 11	Oil-pump.....9, 143, 165
Method of vaporizing (Campbell)..... 12	Oil-pump, testing.....147
Method of vaporizing (Hornsby-Akroyd)... 9	Oil supply (Campbell)...151
Method of vaporizing (Priestman)..... 13	Oil supply (Crossley)...164
	Oil supply (Diesel).....177
	Oil supply (Hornsby-Ak- royd).....173
	Oil supply, limiting..... 89

	PAGE		PAGE
Oil supply (Mietz and Weiss).....	170	Priestman, governing..	15, 169
Oil-supply pipes...57, 61, 146		Priestman, starting.....	152
Oil supply (Priestman)...	15	Priming cup (Crossley)..	148
Oil-supply pump.....	171	Processes in cylinder.....	59
Oil-supplying apparatus... 51		Producer gas plant.....	20
Oil, viscosity of.....	93	Products of combustion... 18	
Otto cycle.....	15, 76	Pump, oil-supply.....	49
Otto patent.....	19	Pump, water-circulating..	99
		Pumping plants.....	131
PARAFFIN (Scotch).....	1	Pumps, efficiency of.....	133
Petroleum.....	1	Pumps, horse-power re-	132
Petroleum (crude).....	2, 20	quired.....	
Petroleum. See Tables.		REFRIGERATING machines...133	
Pipe, air-suction.....	78	Refrigerating machines,	
Piston.....	33, 153	horse-power required..	136
Piston, fitting.....	55	Refrigerating machines,	
Piston lubrication,		rating of.....	133
50, 158, 170, 180		Regulation of engines.....	117
Piston-rings,		Reversing direction of ro-	
34, 55, 56, 154, 158, 159		tation.....	154
Piston speed.....	34	Rhunkorff coil.....	5
Piston, taking out.....	158	Rings, junk.....	55
Planimeters.....	72	Rings, piston,	
Planimeters, directions for		34, 55, 56, 154, 158, 159	
using.....	74	Running oil engines.....	139
Plants, pumping.....	131		
Portable engines.....	181	SALT WATER, cooling.....	100
Portable engines, construc-		Self-starter	105
tion of.....	182	Self-starter (Hornsby-Ak-	
Portable engines (Horns-		royd).....	105
by-Akroyd).....	182	Silencers, exhaust.....	100
Port openings.....	39	Simplicity of construction. 21	
Pressure of explosion.....	20	Single cycle.....	16
Pressure on bearings...42, 43		Skew gear.....	43
Priestman engine.....	168	Specific gravity.....	1

PAGE	PAGE		
Speed counter (Hill).....	85	Two-cylinder engines.....	51
Speed, regulation of.....	154	VALVE, air and exhaust.	
Sprayer (Priestman).....	13	39, 57, 145, 158, 177	
Spray holes.....	147	Valve, back pressure.....	146
Spur gear.....	43, 160	Valve by-pass.....	45, 173
Starting.....	11	Valve closing-springs.....	39
Starting (Campbell type)..	150	Valve exhaust opening....	60
Starting (Crossley type)..	148	Valve, lift of.....	78
Starting (Diesel motor)..	177	Valve mechanisms.....	43
Starting, difficulties of..	61, 143	Valve, overflow, oil.....	146
Starting gear.....	21	Valve starting.....	179
Starting (Hornsby-Ak- royd).....	142	Valves.....	21, 41
Starting (Priestman type)..	152	Valves and valve-boxes...	38
Starting valve.....	179	Vapor inlet-valve..	11, 12, 150
Straight line principle....	168	Vaporizer, advantages of..	8
Suction line.....	76	Vaporizer (Campbell)....	5
TACHOMETERS.....	83	Vaporizer (Crossley)..	11, 150
Tachometers, portable....	84	Vaporizer, difficulties of..	9
Tank.....	49	Vaporizer heated by ex- haust.....	14
Tank, fuel consumption..	64	Vaporizer, heating....	61, 152
Tank, water.....	141	Vaporizer (Hornsby-Ak- royd).....	9
Temperature of cooling water.....	81, 100	Vaporizer (Priestman)...	13
Temperature, exhaust....	110	Vaporizer.....	7
Testing compression.....	61	Vaporizer, to heat.....	141
Testing flash-point.....	90	Vaporizer valve-box.....	145
Testing fuel consumption.	87	Vaporizer, water-jacketed.	141
Testing new engine:.....	59	Vertical engines.....	51
Testing, object of.....	59	Vibrator.....	6
Testing oil-pump.....	147	Viscosity of oil.....	93
Testing sprayer.....	61	WASHER, exhaust.....	101
Testing water-jackets....	63	Waste heat, utilization of..	107
Thermal efficiency....	86, 180	Water-circulating pipes...	97
Two-cycle system..	15, 44, 170		


	PAGE		PAGE
Water-circulating pump...	99	Water, salt, cooling.....	100
Water cooling.....	183	Water space.....	23
Water draining.....	104	Water-tanks, capacity of..	96
Water in exhaust-pipe....	104	Water-tanks, cooling..	96, 141
Water-jackets.....	57, 180	Worm-gear.....	43, 160



LUNKENHEIMER OIL-MIXER OR GENERATOR VALVE.

This oil-feeder, applicable alike to both kerosene and gasoline, is quite simple and readily attached to engine. It is automatic, and feeds the oil in a thoroughly atomized state, but does not heat same to the vaporizing point. If the engine is to operate with gasoline, warming the in-coming air is advisable.



If kerosene or heavy oils are used, the mixer should be arranged so that the fresh air drawn in through opening *C* (see cuts) opens disc *E*. This allows oil to flow in through passage *K*, where, meeting the rapidly entering air, it is thoroughly broken up into a spray, and passing on enters the heater or vaporizer, and from thence to cylinder.



Disc *E* is closed by spring *M*, the seat being very wide, it covers passage-way *K*, automatically shutting off the oil.

The regulation is adjusted by means of the needle-valve *F* and pointer *G*.

The mixer, while one of the newest, seems to embody every requirement of a device for this purpose, and could no doubt be profitably employed by many more builders of engines of this class.



The Lunkenheimer Co.

General Offices and Factory
CINCINNATI, O., U. S. A.

BRANCHES
New York London
26 Cortlandt St. 35 Great Dover St.

MANUFACTURE A COMPLETE LINE OF

ACCESSORIES


FOR

Oil Engines

- Generator Valves
- Globe Angle and Cross,
Stop and Needle Valves
- Check Valves
- Stop Cocks
- Water and Oil Gauges
- Cylinder Lubricators
- Drain Cocks
- Special Fittings
- Bearing Oilers, Single or
Multiple
- Grease Cups, etc.

Special Fittings made to order for
Engine Builders.

Send for Complete Catalogue



Lubrication



Proper lubrication is one of the most vital points in the operation of any piece of machinery, and particularly so with the Gas or Oil Engine. There are special requirements to be considered, and too much care cannot be exercised in the selection of an oil to meet them. An oil which has been adapted and found satisfactory for other kinds of engines may not be at all suited for the Oil Engine.

The action of heat on the lubricating oil must be taken into consideration, and the burning point of the oil be high enough to withstand the heat generated under the highest speed. The viscosity should be such that so great a reduction will not take place under heat as to impair the lubrication. Inasmuch as most animal oils contain matter which liberates injurious acids under the action of heat, it is essential that compounded oils be avoided as dangerous.

The Columbia Lubricants Company have made a special study of the requirements of the Gas and Oil Engines and have been able to meet them in every detail. They have prepared a special oil which among other essential tests has a burning point of 525 degrees Fahrenheit. The use of this oil will insure perfect lubrication under all conditions and an economy in the amount used.

For further information on this and other specially adapted oils, we invite correspondence.



Columbia Lubricants Company

121 Maiden Lane

-

-

New York City

OVER SIX THOUSAND
IN ACTUAL OPERATION

SIZES:
2 TO 50 BRAKE H. P.

USED BY THE
UNITED STATES,
BRITISH, AND
SEVEN
OTHER
GOVERN-
MENTS

The "HORNSBY-AKROYD"
OIL ENGINE

NO
ELECTRIC
SPARK

NO TUBE
IGNITION

ALWAYS SAFE
AND RELIABLE

STARTS WITH-
OUT DIFFICULTY

WORKS
AUTOMATICALLY

Sole Manufacturers in the United States

The De La Vergne Refrigerating Machine Co.,

Foot East 138th Street, New York.

Ice and Refrigeration

ILLUSTRATED

A Monthly Review of the Ice, Ice Making, Refrigerating,
Cold Storage and kindred trades * * * * *

SUBSCRIPTION PRICE :

In United States, Canada and Mexico, \$2.00 per year; in all other countries, \$3.00 per year.

ICE AND REFRIGERATION is the only journal in the world which furnishes a complete and reliable record of the scientific, experimental and practical progress made in the manufacture of ice, as well as a thorough exposition of the various methods adopted in all parts of the world to produce low temperatures for preserving perishable goods in store. The paper is superbly illustrated with views of new ice making, cold storage and refrigerating plants, together with detailed drawings for the construction of same, engravings of new and patented appliances, etc.

H. S. RICH & CO., Publishers

206 Broadway, New York

177 La Salle St., Chicago

Also publishers of the following standard books on ice making, cold storage and refrigeration, which will be sent to any address on receipt of price.

Compend of Mechanical Refrigeration

By Prof. J. E. SIEBEL. Price, prepaid, Cloth, \$3.00; Morocco, \$3.50. Third Edition. The only work treating of all the various branches of theoretical and applied refrigeration, and will be found to contain a large amount of information which would be looked for in vain elsewhere.

Machinery for Refrigeration

By NORMAN SELFE. Price, prepaid, Cloth, \$3.50; Morocco, \$4.50. To the ice or cold storage man who wants to produce the best results with the least primary investment of capital, the smallest cost of maintenance and the lowest working expenses, this work will prove of great value.

Practical Ice Making and Refrigerating

By EUGENE T. SKINKLE. Price, prepaid, Cloth, \$1.50; Morocco, \$2.00. Every branch of ice making and refrigerating is handled in this work, with a view of setting out the best and most economical practice in the construction and operation of the plant.

Indicating the Refrigerating Machine

By GARDNER T. VOORHEES. Price, prepaid, Cloth, \$1.00; Morocco, \$1.50. Treats of the application of the indicator to the ammonia compressor and steam engine, with practical instructions relating to the construction and use of the indicator and reading and computing indicator cards.

HAVE YOU TRIED **LAVA**

Insulating Washers, etc.

for **ELECTRIC IGNITION**


D. M. STEWARD MFG. CO.

107 Chambers St.
New York

Chattanooga
Tenn., U. S. A.

A machine is only as strong as its weakest part

An explosive engine is reliable only so far as the positive ignition at the proper time of the charge is assured.



The H. C.


Magneto Igniter


**IS THE BEST DEVICE FOR THIS
WORK ON THE MARKET**

Send for bulletin giving full description. Special design for automobiles and launches.

We make a full line of "up-to-date" electrical machinery for all purposes, and will be pleased to send descriptive matter to those interested.

The Holtzer-Cabot Electric Co.
BROOKLINE, MASS.





A Large Number of
C & C
Dynamos


are in constant and satisfactory use in connection with oil engines. If you want the **Most Efficient Dynamo** built, either for belting or direct-connecting, address

The **C & C Electric Company**

SALES DEPARTMENT
 143 Liberty Street, New York, N. Y.

Or, C. R. HEAP, 47 Victoria St., Westminster, London, Eng.

THE PRIESTMAN



Safety Oil Engine


—HAS—

Three acknowledged requisites of an ideal internal-combustion engine—

- Straight-Line Design
- Jump-Spark Ignition
- Graduated-Charge Regulation

WE STARTED—OTHERS FOLLOW

PRIESTMAN & CO., INC.
 PHILADELPHIA, PA.



The ORIGINAL and only
 Genuine THOMPSON INDICATOR

The AMERICAN THOMPSON IMPROVED INDICATOR

is especially adapted for use on Oil, Gas and Gasolene Engines. It is made with small $1\frac{1}{2}$ in. drum and extra $\frac{1}{4}$ in. area piston, making it suitable for the high speed and high pressure. The most Simple, Accurate and Durable Indicator ever Produced.

Send for Illustrated Catalogue.

MANUFACTURED ONLY BY


AMERICAN STEAM GAUGE CO.
 JAMAICA PLAIN, BOSTON, MASS.

AIR COMPRESSORS

Driven by Belt, Rope, or connected directly
with Oil Engines

Light
Transportation

Economy
of
Power



No
Boilers

Economy
of
Space

The OIL ENGINE, through its economies, opens up great possibilities in the use of Compressed Air Power.

The **INGERSOLL-SERGEANT** DRILL COMPANY
26 CORTLANDT STREET, NEW YORK




We make a specialty of

Gas and Gasolene Engine Furnishings

viz.:

Cylinder
Lubricators,


Both Glass and Brass,
Crank Pin Oilers, Slide Oilers, Indi-
cator Cocks, Relief Cocks, etc.—All of
genuine merit and fully warranted. Send for our
catalogue.




THE WM. POWELL CO.
CINCINNATI, OHIO

The E. G. Bernard Company, Troy, N. Y.

Makers of High Grade Specially Balanced Oil and Gas Engine Dynamos
Write for circular, prices, etc.



ROTH DYNAMOS



FOR
PRIVATE OR ISOLATED
LIGHTING PLANTS

In sizes of 15, 25, 30, 50, 80 and 110
Light Capacity, 16 C. P.

Small first-class Dynamos a Specialty. Fully Guaranteed

Send for Descriptive Bulletin,

ROTH BROS. & CO.

98 West Jackson Boulevard, Chicago, Ill.

NEW STANDARD Oil, Gas and Gasolene Engine Outfit

CONSISTING OF

New Standard "Autogas" Dry Battery	\$5.00
New Standard Jump Spark Coil.	12.00
New Standard Insulated Cam-Contact Key	3.50
New Standard Double Porcelain Insulated Ignition Plug	6.00

If you are interested, write for descriptive pamphlet.

WILLIAM ROCHE


Inventor and Sole Mfr.

42 Vesey Street - New York City

We also manufacture other good and useful appliances to be operated with dry cells.

"HOT
STUFF"

JUMP SPARK COILS




For
Igniting
the Charge
in Cylinders of Gas,
Gasolene
or Oil
Engines.

Simple, Durable and
Reliable.

Send for prices

C. F. SPLITDORF, Manufacturer of Electric Specialties, 17 Vandewater St., New York.



**THE
MIETZ & WEISS
GAS OR
KEROSENE
ENGINE**

Automatic, Simple and Reliable
Safest and Cheapest Power
Known

From 1 to 40 H. P. Send for Catalogue.

A. MIETZ
128-138 Mott St. New York

MARKT & CO., LTD.,
LONDON, PARIS, HAMBURG AND BERLIN.

USEFUL BOOKS


WATSON—How to Run Engines and Boilers, - - -	\$1.00
REDWOOD—Theoretical and Practical Ammonia Refrigeration, - - - - -	1.00
REDWOOD—Lubricants, Oils and Greases, - - -	1.50
DAHLSTROM—The Fireman's Guide to Care of Steam Boilers, - - - - -	.50
HENTHORN—Care and Management of Corliss Engines, - - -	1.00
HIGGS—Algebra Self Taught for Engineers, - - -	.60
MARSHALL—Small Accumulators and How to Make Them, - - - - -	.50

Books mailed postpaid on receipt of price.

SPON & CHAMBERLAIN, Publishers
12 Cortlandt Street, N. Y., U. S. A.

The P. T. Motor Company

P. T. Motors will run on the vapors of any of the products of petroleum.



Complete Motors & Castings and Parts


Send stamp for circulars.

Our motors are the smallest and lightest per horse power in the world. Our 1 H. P. Bicycle Motor is only $12\frac{1}{2} \times 6 \times 4$ inches; weight, $20\frac{1}{2}$ pounds; speed, 1000 R. per minute.

Address all communications to

2312 Broadway, or 230 Avenue B
New York City

Hill's Speed Recorder



REGISTERS TIME
and
REVOLUTIONS
on
PAPER TAPE

Accurate and Reliable

Size, $4\frac{1}{2} \times 2\frac{1}{2} \times 1\frac{1}{4}$ inches

ALVA T. HILL

432 4th Ave.,

- -

Detroit, MICHIGAN

THE "B & C" FRICTION CLUTCH PULLEY

SPECIALLY DESIGNED FOR

GAS, GASOLENE AND OIL ENGINES

(PATENTED)

Bolts directly on engine fly wheel.

A powerful grip, combined with a positive release.

A simple mechanism enclosed in a dust proof case.

The greatest ease of operation and adjustment.


MADE BY

WHITMAN MFG. CO.

39 Cortlandt Street - New York

Also manufacturers of the B & C Line Shaft Clutches, and Clutch Couplings.

Write for Catalogue and Prices.



"B & C" Gas Engine Clutch Pulley

CROSS SECTION PAPER.

Scale EIGHT to ONE Inch.

THE HANDY SKETCHING PAD.

Printed on one side, in blue ink, all the lines being of equal thickness with useful tables. Size 8 x 10 inches. Price, 25c. each. Per dozen pads, \$2.50.

THE HANDY SKETCHING BOOK.

Made from this paper but printed on both sides. Size of book 5 x 8 inches, stiff board covers. Price, 25c. each; per dozen books, \$2 50.

Scale EIGHT to ONE Inch.

A large sheet with heavy inch lines and half inch lines, printed in blue ink. Size of sheet, 17 x 22 inches. Per quire (24 sheets), 75c.

Scale TEN to ONE Inch.

Size 17 x 22 inches, printed in blue ink, with heavy inch lines and half inch lines. Per quire (24 sheets), 75c.

The Electrician's Sketching Book.

Made from this paper. Scale 10 to 1 inch. Size of book 5 x 8 inches, with stiff card board covers. Price, 25c. each; per dozen, \$2.50.

The Electrician's Plotting Pad.

Same paper, only printed on one side, size of pad, 8 x 10 inches, 25c ; per dozen, \$2 50.

Any Books and Pads Assorted, per dozen, \$2 50.

ANY QUANTITY MAILED TO ANY PART OF THE WORLD
POST-PAID ON RECEIPT OF PRICE.

This paper is *Printed from plates*. Try it and you will find it

GOOD, ACCURATE AND CHEAP.

SPON & CHAMBERLAIN,

12 CORTLANDT STREET, NEW YORK, U. S. A.

AUTHORIZED AMERICAN EDITION OF

POLYPHASE ELECTRIC CURRENTS

AND

ALTERNATE-CURRENT MOTORS

By **S. P. THOMPSON, D.Sc., B.A., F.R.S.**

Second and Enlarged Edition, with Twenty-four Colored Illustrations and Eight Folding Plates.

CONTENTS OF CHAPTERS.

- I. Alternating Currents in General.
- II. Polyphase Currents.
- III. Combination of Polyphase Circuits and Economy of Copper.
- IV. Polyphase Generators.
- V. Examples of Polyphase Generators.
- VI. Structure of Polyphase Motors.
- VII-VIII. Graphic Theory of Polyphase Motors.
- IX. Analytical Theory of Polyphase Motors.
- X. Examples of Modern Polyphase Motors.
- XI. Hints on Design.
- XII. Mechanical Performance of Polyphase Motors.
- XIII. Single-Phase Motors.
- XIV. Polyphase Transformers and Phase Transformation.
- XV. Measurement of Polyphase Power.
- XVI. Polyphase Equipment of Factories.
- XVII. Distribution of Polyphase Currents from Central Stations.
- XVIII. Polyphase Electric Railways.
- XIX. Properties of Rotating Magnetic Fields.
- XX. Early Development of the Polyphase Motor.

APPENDIX.—I. Alternate Current Calculations: the Symbolic Method. II. Schedule of Polyphase Patents. Index

LIST OF PLATES:—
I. Two-phase Generator at Chevres. II. Three-phase Inductor Alternator. III. Two-phase Motor of Six Horse-power. IV. Three-phase Motor of One Hundred Horse-power. V. Three-phase Motor of Twenty Horse-power. VI. Core-Disks of Three-Phase Motor. VII. Two phase Motor of One Thousand Horse power. VIII. Locomotive of the Jungfrau Railway.

508 Pages, 358 Illus., 8vo, Cloth, \$5.00†

INDUCTION COILS.

THEIR CONSTRUCTION, OPERATION AND APPLICATIONS, WITH
CHAPTERS, ON

Batteries, Tesla Coils and Roentgen Radiography.


By **H. S. NORRIE.**

CONTENTS OF CHAPTERS.

Chapter I.—Coil Construction. II.—Contact Breakers. III.—Insulations and Cements. IV.—Condensers. V.—Experiments. VI.—Spectrum Analysis. VII.—Currents in Vacuo. VIII.—Rotating Effects. IX.—Gas Lighting and Ozone Production. X.—Primary Batteries and Electric Light Currents. XI.—Storage Batteries. XII.—Tesla and Hertz Effects. XIII.—Roentgen Rays and Radiography. With 57 new illustrations.

LIST OF ILLUSTRATIONS.

Fig. 1. Section of Coil. 2. Insulating Tube Ends. 3. Sectional Winding. 4. Section Winding First Method. 5. Section Winding Second Method. 6. Proportional Diagram of Coil. 7. Section Winder, End View. 8. Section Winder, Face View. 9. Assembly of Coils. 10. Polechanging Switch. 11. Contact Breaker, Simple. 12. Contact Breaker, Imperfect Form. 13. Contact Breaker, Superior Form. 14. Spottiswoode Breaker. 15. Polechanging. 16. Leyden Jar. 17. Plate Condenser. 18. Arrangement of Condenser Plates. 19. Condenser Charging, First Method. 20. Condenser Charging, Second Method. 21. Spark between Balls. 22. Short Spark between Balls. 23. Sparking Pane. 24. Luminous Design. 25. Electric Brush. 26. Spectrum—Solar. 27. Spectroscope and Coil. 28. Simple Air Pump. 29. Geissler Air Pump. 30. Sprengel Air Pump. 31. Fluorescent Bulbs. 32. Solution Tube. 33. Ruby Tube—Crookes. 34. Iridio-platinum Tube—Crookes. 35. Revolving Wheel. 36. Tube Holder. 37. Side View of Wheel. 38. Geissler Tubes. 39. Triangle on Disc. 40. Maltese Cross on Disc. 41. Gas Lighting Circuit. 42. Ozone. 43. Grenet Cell. 44. Fuller. 45. Gethin's Cell. 46. Lead Plate. 47. Wooden Separator. 48. Charging with Rheostat. 49. Charging with Lamps. 50. Hydrometer. 51. Hertz Resonator. 52. Tesla Circuit. 53. Tesla Cut Out. 54. Tesla Cut Out Top Plan. 55. Tesla Coil. 56. Crookes Tube. 57. Roentgen Circuit.



UNIVERSITY OF CALIFORNIA LIBRARY
BERKELEY

**THIS BOOK IS DUE ON THE LAST DATE
STAMPED BELOW**

Books not returned on time are subject to a fine of 50c per volume after the third day overdue, increasing to \$1.00 per volume after the sixth day. Books not in demand may be renewed if application is made before expiration of loan period.

FEB 23 1920

DEC 15 1922

2 Aug '55 WS

JUL 5 1955 LM

TJ 785
G6

82934

